

BG95&BG77&BG600L Series

AT Commands Manual

LPWA Module Series

Version: 2.1

Date: 2025-03-20

Status: Released



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local offices. For more information, please visit:

<http://www.quectel.com/support/sales.htm>.

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>.

Or email us at: support@quectel.com.

Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

Use and Disclosure Restrictions

License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

Copyright © Quectel Wireless Solutions Co., Ltd. 2025. All rights reserved.

About the Document

Revision History

Version	Date	Author	Description
1.0	2019-08-31	Ethan YAN/ Hyman DING	Initial
2.0	2020-09-18	Ethan YAN/ Hyman DING	- Added the applicable module BG600L-M3 and removed BG95-N1. - Deleted AT+CIND, AT+QSPN, AT+CUSD, AT+QGMR and AT+QAPPVER. - Added AT+QADC, AT+QPTWEDRXS and AT+QCSCON. - Added the list of CoAP and LwM2M related AT commands as well as extended configuration commands.
2.1	2025-03-20	Hal FU/ Jude ZHANG	- Added the applicable module models BG95-M8 and BG95-M9. - Added the declaration of AT command examples (Chapter 1.5). - Added a supported value "dam" of <URC_port> and related example (Chapter 2.25). - Added the supported baud rates 4800 bps and 2000000 bps (Chapter 3.5). - Added an URC type "ccinfo" (Chapter 4.2). - Added a note for AT+COPS (Chapter 6.2). - Updated the note for AT+CSQ (Chapter 6.3). - Added a note for AT+QPSMS (Chapter 6.8). - Updated <early_wake_up_time> to <eMTC_early_wake_up_time>; updated the example of AT+QPSMEXTCFG and added a note for AT+QPSMEXTCFG (Chapter 6.10). - Updated the IP address in the example of AT+QCSCON (Chapter 6.17). - Added the following commands:

-
- AT+QCOPS (Chapter 6.19)
 - AT+QSMSCONCAS (Chapter 8.18)
 - AT+QCTEMP (Chapter 10.6)
 - AT+QVBATT (Chapter 10.7)
12. Modified the maximum response time of AT+CMGS (Chapter 8.8).
 13. Updated the note for AT+CGREG (Chapter 9.5)
 14. Added a note about the pin number for AT+QADC (Chapter 10.3).
 15. Deleted the chapter of "Supplementary Service Commands".
 16. Deleted AT+QPOWD (See document [1] for details about the command).
 17. Updated the description of the following commands:
 - AT+CGREG (Chapter 9.5)
 - AT+QTEMP (Chapter 10.5)
 18. Added the AT+IFC in Table 19 (Chapter 22.3)
-

Contents

About the Document.....	3
Contents	5
Table Index.....	9
1 Introduction	10
1.1. Scope of the Document	10
1.2. Definitions	11
1.3. AT Command Syntax.....	11
1.4. AT Command Responses.....	12
1.5. Declaration of AT Command Examples	13
1.6. Supported Character Sets	13
1.7. AT Command Interface.....	13
1.8. Unsolicited Result Code.....	13
1.9. Turn off Procedure	14
2 General Commands	15
2.1. ATI Display Product Identification Information.....	15
2.2. AT+GMI Request Manufacturer Identification.....	16
2.3. AT+GMM Request Model Identification	16
2.4. AT+GMR Request Firmware Version Identification.....	17
2.5. AT+CGMI Request Manufacturer Identification.....	17
2.6. AT+CGMM Request Model Identification.....	18
2.7. AT+CGMR Request Firmware Version Identification	18
2.8. AT+GSN Request International Mobile Equipment Identity (IMEI).....	19
2.9. AT+CGSN Request International Mobile Equipment Identity (IMEI)	20
2.10. AT&F Reset All AT Command Settings to Factory Settings.....	21
2.11. AT&V Display Current Configuration.....	21
2.12. AT&W Store Current AT Command Settings to User-defined Profile	22
2.13. ATZ Restore All AT Command Settings from User-defined Profile	23
2.14. ATQ Set Result Code Presentation Mode	23
2.15. ATV TA Response Format	24
2.16. ATE Set Command Echo Mode	25
2.17. A/ Repeat Previous Command Line.....	26
2.18. ATS3 Set Command Line Termination Character	27
2.19. ATS4 Set Response Formatting Character	27
2.20. ATS5 Set Command Line Editing Character	28
2.21. ATX Set CONNECT Result Code Format and Monitor Call Progress	28
2.22. AT+CFUN Set UE Functionality	29
2.23. AT+CMEE Error Message Format	31
2.24. AT+CSCS Select TE Character Set.....	32
2.25. AT+QURCCFG Configure URC Indication Option.....	33
3 Serial Interface Control Commands	35

3.1.	AT&C	Set DCD Behavior	35
3.2.	AT&D	Set DTR Behavior.....	35
3.3.	AT+IFC	Set TE-TA Local Flow Control	36
3.4.	AT+ICF	Set TE-TA Character Framing.....	37
3.5.	AT+IPR	Set TE-TA Fixed Local Rate.....	38
3.6.	AT+QIR	Restore MAIN_RI Behavior to Inactive	40
4	Status Control Commands		41
4.1.	AT+CPAS	Query ME Activity Status.....	41
4.2.	AT+QINDCFG	URC Indication Configuration	42
5	(U)SIM Related Commands		45
5.1.	AT+CIMI	Request International Mobile Subscriber Identity (IMSI).....	45
5.2.	AT+CLCK	Facility Lock	46
5.3.	AT+CPIN	Enter PIN.....	48
5.4.	AT+CPWD	Change Password	50
5.5.	AT+CRSM	Restricted (U)SIM Access.....	52
5.6.	AT+QCCID	Show ICCID	53
5.7.	AT+QPINC	Display PIN Remainder Counter.....	54
5.8.	AT+QINISTAT	Query Initialization Status of (U)SIM Card	55
5.9.	AT+QSIMDET	(U)SIM Card Detection.....	55
5.10.	AT+QSIMSTAT	(U)SIM Card Insertion Status Report.....	57
6	Network Service Commands		59
6.1.	AT+CREG	Network Registration Status	59
6.2.	AT+COPS	Operator Selection	60
6.3.	AT+CSQ	Signal Quality Report.....	62
6.4.	AT+CPOL	Preferred Operator List.....	64
6.5.	AT+COPN	Read Operator Names.....	65
6.6.	AT+CTZU	Automatic Time Zone Update	66
6.7.	AT+CPSMS	Power Saving Mode Setting	67
6.8.	AT+QPSMS	Power Saving Mode Setting	69
6.9.	AT+QPSMCFG	PSM Feature and Minimum Threshold Value Setting	72
6.10.	AT+QPSMEXTCFG	Modem Optimization	73
6.11.	AT+CEDRXS	e-I-DRX Setting	75
6.12.	AT+QPTWEDRXS	Paging Time Window Value and eDRX Setting.....	78
6.13.	AT+CEDRXRDP	Read Dynamic Parameters.....	82
6.14.	AT+CTZR	Time Zone Reporting	85
6.15.	AT+QNWINFO	Query Network Information.....	86
6.16.	AT+QCSQ	Query and Report Signal Strength	87
6.17.	AT+QCSCON	Signaling Connection Status	88
6.18.	AT+QLTS	Obtain the Latest Time Synchronized Through Network.....	90
6.19.	AT+QCOPS	Scan Current Available Networks	92
7	Call Related Commands*		96
7.1.	ATD	Mobile Originated Call to Dial a Number	96

7.2.	ATH	Disconnect Existing Connection	98
7.3.	AT+CVHU	Voice Hang up Control	98
7.4.	AT+CHUP	Hang up a Call.....	99
7.5.	+++	Switch from Data Mode to Command Mode.....	99
7.6.	ATO	Switch from Command Mode to Data Mode	100
7.7.	ATS0	Set Number of Rings before Automatic Answering	101
7.8.	ATS6	Set Pause before Blind Dialing	102
7.9.	ATS7	Set the Time to Wait for Connection Completion.....	102
7.10.	ATS8	Set the Time to Wait for Comma Dial Modifier	103
7.11.	ATS10	Set Disconnection Delay after Indicating the Absence of Data Carrier	104
7.12.	AT+CRC	Set Cellular Result Codes for Incoming Call Indication	104
8	Short Message Service Commands.....		107
8.1.	AT+CSMS	Select Message Service	107
8.2.	AT+CMGF	Message Format.....	108
8.3.	AT+CSCA	Service Center Address	109
8.4.	AT+CPMS	Preferred Message Storage.....	110
8.5.	AT+CMGD	Delete Messages.....	112
8.6.	AT+CMGL	List Messages	113
8.7.	AT+CMGR	Read Messages.....	117
8.8.	AT+CMGS	Send Messages	121
8.9.	AT+CMMS	Send More Messages	123
8.10.	AT+CMGW	Write Messages to Memory.....	124
8.11.	AT+CMSS	Send Messages from Storage	126
8.12.	AT+CNMA	New Message Acknowledgement to UE/TE.....	128
8.13.	AT+CNMI	New Message Indications to TE	129
8.14.	AT+CSDH	Show Text Mode Parameters.....	132
8.15.	AT+CSMP	Set Text Mode Parameters	133
8.16.	AT+QCMGS	Send Concatenated Messages	134
8.17.	AT+QCMGR	Read Concatenated Messages	135
8.18.	AT+QSMSCONCAS	Send Long Messages	137
9	Packet Domain Commands		140
9.1.	AT+CGATT	PS Attach or Detach.....	140
9.2.	AT+CGDCONT	Define PDP Context	141
9.3.	AT+CGACT	PDP Context Activate or Deactivate.....	142
9.4.	AT+CGPADDR	Show PDP Addresses	144
9.5.	AT+CGREG	EGPRS Network Registration Status.....	145
9.6.	AT+CGEREP	Packet Domain Event Reporting.....	147
9.7.	AT+CGSMS	Select Service for MO SMS Messages.....	150
9.8.	AT+CEREG	EPS Network Registration Status.....	151
10	Hardware Related Commands.....		154
10.1.	AT+CCLK	Clock	154
10.2.	AT+CBC	Battery Charge.....	155
10.3.	AT+QADC	Read ADC Value.....	156

10.4.	AT+QSCLK	Configure Whether or Not to Enter Sleep Mode	156
10.5.	AT+QTEMP	Read Temperature.....	157
10.6.	AT+QCTEMP	Configure the Temperature Threshold	158
10.7.	AT+QVBATT	Configure the Voltage Threshold	160
11	DFOTA Related AT Command		164
12	FTP(S) Related AT Commands		165
13	HTTP(S) Related AT Commands		166
14	TCP/IP) Related AT Commands		167
15	GNSS Related AT Commands		168
16	SSL Related AT Commands		169
17	FILE Related AT Commands.....		170
18	MQTT Related AT Commands		171
19	CoAP Related AT Commands.....		172
20	LwM2M Related AT Commands		173
21	Extended Configuration Commands		174
22	Appendix.....		177
22.1.	References.....		177
22.2.	Factory Default Settings Restorable with AT&F		180
22.3.	AT Command Settings Storable with AT&W		181
22.4.	AT Command Settings Restorable with ATZ.....		182
22.5.	Summary of CME ERROR Codes		183
22.6.	Summary of CMS ERROR Codes		185
22.7.	Summary of URC		186
22.8.	SMS Character Sets Conversions		188

Table Index

Table 1: Applicable Modules	10
Table 2: Types of AT Commands	12
Table 3: AT&V Response	21
Table 4: The Numeric Equivalents and Brief Description of ATV0 and ATV1 Result Codes	25
Table 5: DFOTA Related AT Command	164
Table 6: FTP(S) Related AT Commands	165
Table 7: HTTP(S) Related AT Commands	166
Table 8: TCP/IP Related AT Commands	167
Table 9: GNSS Related AT Commands	168
Table 10: SSL Related AT Commands	169
Table 11: FILE Related AT Commands	170
Table 12: MQTT Related AT Commands	171
Table 13: CoAP Related AT Commands	172
Table 14: LwM2M Related AT Commands	173
Table 15: Extended Configuration Commands	174
Table 16: Related Documents	177
Table 17: Terms and Abbreviations	178
Table 18: Factory Default Settings Restorable with AT&F	180
Table 19: AT Command Settings Storable with AT&W	181
Table 20: AT Command Settings Restorable with ATZ	182
Table 21: Different Coding Schemes of +CME ERROR: <err>	183
Table 22: Different Coding Schemes of +CMS ERROR: <err>	185
Table 23: Summary of URC	186
Table 24: The Way of SMS Text Input or Output	188
Table 25: The Input Conversions Table (DCS=GSM 7 bit and AT+CSCS="GSM")	189
Table 26: The Output Conversions Table (DCS=GSM 7 bit and AT+CSCS="GSM")	189
Table 27: GSM Extended Characters (GSM Encode)	190
Table 28: The Input Conversions Table (DCS=GSM 7 bit and AT+CSCS="IRA")	191
Table 29: IRA Extended Characters	192
Table 30: The Output Conversions Table (DCS=GSM 7 bit and AT+CSCS="IRA")	192
Table 31: GSM Extended Characters (ISO-8859-1/Unicode)	193

1 Introduction

1.1. Scope of the Document

This document presents the AT commands set supported by the following Quectel eMTC/NB-IoT modules:

Table 1: Applicable Modules

Module Series	Model	Description
BG95	BG95-M1	Cat M1
	BG95-M2	Cat M1/Cat NB2
	BG95-M3	Cat M1/Cat NB2/EGPRS
	BG95-M4	Cat M1/Cat NB2, 450 MHz Supported
	BG95-M5	Cat M1/Cat NB2/EGPRS, Power Class 3
	BG95-M6	Cat M1/Cat NB2, Power Class 3
	BG95-MF	Cat M1/Cat NB2, Wi-Fi Positioning
	BG95-M8	Cat M1/Cat NB2/EGPRS, 450 MHz Supported
	BG95-M9	Cat M1/Cat NB2, 450 MHz Supported, Power Class 2@ B31/B72/B73, Power Class 3@other LTE bands
BG77	BG77	Cat M1/Cat NB2
BG600L	BG600L-M3	Cat M1/Cat NB2/EGPRS

NOTE

1. “*” means under development.
2. Hereinafter, BG95 series is collectively called BG95 unless otherwise specified.

1.2. Definitions

- **<CR>** Carriage return character.
- **<LF>** Line feed character.
- **<...>** Parameter name. Angle brackets do not appear on command line.
- **[...]** Optional parameter of a command or an optional part of TA information response. Square brackets do not appear on command line. When an optional parameter is omitted, the new value equals its previous value or its default setting, unless otherwise specified.
- **Underline** Default setting of a parameter.

1.3. AT Command Syntax

All command lines must start with **AT** or **at** and end with **<CR>**. Information responses and result codes always start and end with a carriage return character and a line feed character: **<CR><LF><response><CR><LF>**. In tables presenting commands and responses throughout this document, only the commands and responses are presented, and **<CR>** and **<LF>** are deliberately omitted.

The AT command set implemented by BG95/BG77/BG600L-M3 is a combination of *3GPP TS 27.007*, *3GPP TS 27.005* and *ITU-T recommendation V.25ter* as well as the AT Commands developed by Quectel.

All these AT commands can be split into three categories syntactically: “Basic”, “S parameter”, and “Extended”. They are listed as follows:

- **Basic syntax**

These AT commands have the format of **AT<x><n>**, or **AT&<x><n>**, where **<x>** is the command, and **<n>** is/are the argument(s) for that command. An example of this is **ATE<n>**, which tells the DCE whether received characters should be echoed back to the DTE according to the value of **<n>**. **<n>** is optional and a default will be used if it is null.

- **S parameter syntax**

These AT commands have the format of **ATS<n>=<m>**, where **<n>** is the index of the **S** register to set, and **<m>** is the value to assign to it.

- **Extended syntax**

These commands can be operated in several modes, as shown in the following table:

Table 2: Types of AT Commands

Command Type	Syntax	Description
Test Command	AT+<cmd>=?	Test the existence of the corresponding command and return information about the type, value, or range of its parameter.
Read Command	AT+<cmd>?	Check the current parameter value of the corresponding command.
Write Command	AT+<cmd>=<p1>[,<p2>[,<p3> [...]]]	Set user-definable parameter value.
Execution Command	AT+<cmd>	Return a specific information parameter or perform a specific action.

Multiple commands can be placed on a single line using a semi-colon (;) between commands. Only the first command should have **AT** prefix. Commands can be in upper or lower case.

When entering AT commands, spaces are ignored except the following cases:

- Within quoted strings, where they are preserved;
- Within an unquoted string or numeric parameter;
- Within an IP address;
- Within the AT command name up to and including a =, ? or =?.

On input, at least a carriage return is required. A newline character is ignored so it is permissible to use carriage return/line feed pairs on the input.

If no command is entered after the **AT** token, **OK** will be returned. If an invalid command is entered, **ERROR** will be returned.

Optional parameters, unless explicitly stated, need to be provided up to the last parameter being entered.

1.4. AT Command Responses

When the AT command processor has finished processing a line, it will output **OK**, **ERROR** or **+CME ERROR: <err>** to indicate that it is ready to accept a new command. Solicited informational responses are sent before the final **OK**, **ERROR** or **+CME ERROR: <err>**.

Responses will be in the format of:

<CR><LF>+CMD1:<parameters><CR><LF>

<CR><LF>OK<CR><LF>

Or

```
<CR><LF><parameters><CR><LF>  
<CR><LF>OK<CR><LF>
```

1.5. Declaration of AT Command Examples

The AT command examples in this document are provided to help you learn about the use of the AT commands introduced herein. The examples, however, should not be taken as Quectel's recommendations or suggestions about how to design a program flow or what status to set the module into. Sometimes multiple examples may be provided for one AT command. However, this does not mean that there is a correlation among these examples, or that they should be executed in a given sequence. The URLs, domain names, IP addresses, usernames/accounts, and passwords (if any) in the AT command examples are provided for illustrative and explanatory purposes only, and they should be modified to reflect your actual usage and specific needs.

1.6. Supported Character Sets

BG95/BG77/BG600L-M3 AT command interface uses the GSM character set by default. BG95/BG77/BG600L-M3 module supports the following character sets:

- GSM format
- UCS2
- IRA

The character set can be configured and interrogated by using the **AT+CSCS** command (3GPP TS 27.007) and it is defined in 3GPP TS 27.005. The character set affects transmission and reception of SMS and SMS Cell Broadcast Messages, as well as the entry and display of phone book entries text field.

1.7. AT Command Interface

BG95/BG77/BG600L-M3 AT command interface includes one USB MODEM port and one main UART port. The main UART port and the USB MODEM port support AT command communication and data transfer.

1.8. Unsolicited Result Code

As an Unsolicited Result Code and a report message, URC is not issued as part of the response related to an executed AT command. URC is issued by BG95/BG77/BG600L-M3 without being requested by the

TE and it is issued automatically when a certain event occurs. Typical events leading to URCs are incoming calls (**RING**), received short messages, high/low voltage alarm, high/low temperature alarm, etc.

1.9. Turn off Procedure

It is recommended to execute **AT+QPOWD** (see *document [1]* for details) to power off the module, as it is the safest and best way. This procedure is realized by letting the module log off from the network and allowing the software to enter a secure and safe data state before disconnecting the power supply.

After sending **AT+QPOWD**, do not enter any other AT commands. When the command is executed successfully, the module will output **POWERED DOWN** and set the STATUS pin as low to enter power-off state. In order to avoid data loss, it is suggested to wait for 1s at least to disconnect the power supply after the STATUS pin is set as low and the URC **POWERED DOWN** is outputted. If **POWERED DOWN** cannot be received within 65 s, the power supply shall be disconnected compulsorily.

2 General Commands

2.1. ATI Display Product Identification Information

This command delivers the product identification information text.

ATI Display Product Identification Information	
Execution Command ATI	Response Quectel <objectID> Revision: <revision> OK
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

Parameter

<objectID>	Identifier of product type.
<revision>	Identification text of product firmware version

Example

```

ATI
Quectel
BG95M2
Revision: BG95M2LAR01A01

OK

```


2.2. AT+GMI Request Manufacturer Identification

This command returns the manufacturer identification text. It is identical with **AT+CGMI** in *Chapter 2.5*.

AT+GMI Request Manufacturer Identification	
Test Command AT+GMI=?	Response OK
Execution Command AT+GMI	Response TA reports one or more lines of information text which permits the user to identify the manufacturer. Quectel OK
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

2.3. AT+GMM Request Model Identification

This command returns the product model identification text. It is identical with **AT+CGMM** in *Chapter 2.6*.

AT+GMM Request Model Identification	
Test Command AT+GMM=?	Response OK
Execution Command AT+GMM	Response <objectID> OK
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

Parameter

<objectID> Identifier of product type.

2.4. AT+GMR Request Firmware Version Identification

This command returns the identification text of product firmware version. It is identical with **AT+CGMR** in *Chapter 2.7*.

AT+GMR Request Firmware Version Identification	
Test Command AT+GMR=?	Response OK
Execution Command AT+GMR	Response TA reports one line of information text which permits the user to identify the firmware version. <revision> OK
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

Parameter

<revision> Identification text of product firmware version.

Example

```
AT+GMR
BG95M2LAR01A01

OK
```

2.5. AT+CGMI Request Manufacturer Identification

This command returns the manufacturer identification text. It is identical with **AT+GMI** in *Chapter 2.2*.

AT+CGMI Request Manufacturer Identification	
Test Command AT+CGMI=?	Response OK
Execution Command AT+CGMI	Response Quectel

	OK
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.007	

2.6. AT+CGMM Request Model Identification

This command returns the model identification text of the product. It is identical with **AT+GMM** in *Chapter 2.3*.

AT+CGMM Request Model Identification	
Test Command AT+CGMM=?	Response OK
Execution Command AT+CGMM	Response <objectID> OK
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<objectID> Identifier of product type.

2.7. AT+CGMR Request Firmware Version Identification

This command returns the identification text of the product firmware version. It is identical with **AT+GMR** in *Chapter 2.4*.

AT+CGMR Request Firmware Version Identification	
Test Command AT+CGMR=?	Response OK

Execution Command AT+CGMR	Response <revision> OK
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<revision> Identification text of product firmware version.

2.8. AT+GSN Request International Mobile Equipment Identity (IMEI)

This command returns the International Mobile Equipment Identity (IMEI) number of the product in information text which permits the user to identify the individual ME device. It is identical with **AT+CGSN** in **Chapter 2.9**.

AT+GSN Request International Mobile Equipment Identity (IMEI)	
Test Command AT+GSN=?	Response OK
Execution Command AT+GSN	Response <IMEI> OK
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

Parameter

<IMEI> IMEI number of the ME.

NOTE

The IMEI can be used to identify ME since it is unique to each ME.

2.9. AT+CGSN Request International Mobile Equipment Identity (IMEI)

This command returns the International Mobile Equipment Identity (IMEI) of the ME. It is identical with **AT+GSN** above.

AT+CGSN Request International Mobile Equipment Identity (IMEI)	
Test Command AT+CGSN=?	Response OK
Execution Command AT+CGSN	Response <IMEI> OK
Maximum Response Time	300 ms
Characteristics	-
Reference <i>3GPP TS 27.007</i>	

Parameter

<IMEI> IMEI number of the ME.

NOTE

The IMEI can be used to identify ME since it is unique to each ME.

2.10. AT&F Reset All AT Command Settings to Factory Settings

This command resets all current AT command settings to the default values specified by the manufacturer. Refer to **Table 18** for the list of supported AT commands.

AT&F Reset All AT Command Settings to Factory Settings	
Execution Command AT&F[<value>]	Response OK
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

Parameter

<value>	Integer type.
<u>0</u>	Set all current AT command settings to factory setting

2.11. AT&V Display Current Configuration

This command displays the current settings of some AT command parameters (see **Table 2**), including the single-letter AT command parameters which are not readable otherwise.

AT&V Display Current Configuration	
Execution Command AT&V	Response OK
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

Table 3: AT&V Response

AT&V
&C: 1
&D: 2
&F: 0

```
&W: 0
Q: 0
V: 1
X: 4
Z: 0
E: 1
S0: 0
S4: 10
S5: 8
S6: 2
S7: 0
S8: 2
S10: 15
S3: 13
```

```
OK
```

2.12. AT&W Store Current AT Command Settings to User-defined Profile

This command stores the current AT command settings to a user-defined profile in non-volatile memory. The AT command settings will be automatically restored from the user-defined profile during power-up or if **ATZ** is executed. Refer to **Table 19** for the list of supported AT commands.

AT&W Store Current AT Command Settings to User-defined Profile	
Execution Command AT&W[<n>]	Response OK
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

Parameter

<n> Integer type.
0 Profile number to store the current AT command settings

2.13. ATZ Restore All AT Command Settings from User-defined Profile

This command first resets the AT command settings to factory settings, which is similar to **AT&F**. Afterwards, the AT command settings are restored from the user-defined profile in the non-volatile memory if they have been stored with **AT&W** before.

Any additional AT command on the same command line may be ignored.

Refer to **Table 20** for the list of supported AT commands.

ATZ Restore All AT Command Settings from User-defined Profile	
Execution Command ATZ[<value>]	Response OK
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

Parameter

<value>	Integer type.
<u>0</u>	Reset to profile number 0

2.14. ATQ Set Result Code Presentation Mode

This command controls whether the result code is transmitted to the TE. Other information text transmitted as response is not affected by this setting.

ATQ Set Result Code Presentation Mode	
Execution Command ATQ<n>	Response If <n>=0: OK If <n>=1: (none)
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W .
Reference V.25ter	

Parameter

<n>	Integer type.
<u>0</u>	TA transmits result code
<u>1</u>	Result codes are suppressed and not transmitted

2.15. ATV TA Response Format

This command determines the contents of header and trailer transmitted with AT command result codes and information responses.

The numeric equivalents and brief descriptions of the use of result code are listed in the following table.

ATV TA Response Format	
Execution Command ATV<value>	Response When <value>=0 : 0 When <value>=1 : OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W .
Reference V.25ter	

Parameter

<value>	Integer type.
<u>0</u>	Information response: <text><CR><LF> Short result code format: <numeric code><CR>
<u>1</u>	Information response: <CR><LF><text><CR><LF> Long result code format: <CR><LF><verbose code><CR><LF>

Example

```

ATV1                                     //Set <value>=1.
OK
AT+CSQ
+CSQ: 30,99

```

```

OK                                     //When <value>=1, the result code is OK.
ATV0                                  //Set <value>=0.
0
AT+CSQ
+CSQ: 30,99
0                                     //When <value>=0, the result code is 0.

```

Table 4: The Numeric Equivalents and Brief Description of ATV0 and ATV1 Result Codes

ATV1	ATV0	Description
OK	0	Acknowledges execution of a command.
CONNECT	1	A connection has been established. The DCE is switching from command mode to data mode.
RING	2	The DCE has detected an incoming call signal from network.
NO CARRIER	3	The connection has been terminated or the attempt to establish a connection failed.
ERROR	4	Command not recognized, command line maximum length exceeded, parameter value invalid, or other problem with processing the command line.
NO DIALTONE	6	No dial tone detected.
BUSY	7	Engaged (busy) signal detected.
NO ANSWER	8	@ (Wait for Quiet Answer) dial modifier was used, but remote ringing followed by five seconds of silence was not detected before expiration of the connection timer (S7).

2.16. ATE Set Command Echo Mode

This command controls whether or not the module echoes characters received from TE during AT command mode.

ATE Set Command Echo Mode	
Execution Command ATE<value>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W .

Reference
V.25ter

Parameter

<value>	Integer type. Whether to echo the characters received from TE.
0	Echo mode OFF
<u>1</u>	Echo mode ON

2.17. A/ Repeat Previous Command Line

This command repeats previous AT command line, and “/” acts as the line termination character.

A/ Repeat Previous Command Line

Execution Command	Response
A/	Repeat the previous command
Characteristics	-
Reference	
V.25ter	

Example

```

ATI
Qectel
BG95M2
Revision: BG95M2LAR01A01

OK
A/                                //Repeat the previous command.
Qectel
BG95M2
Revision: BG95M2LAR01A01

OK

```

2.18. ATS3 Set Command Line Termination Character

This command determines the character recognized by the module to terminate an incoming command line. It is also generated for result codes and information text, along with character value set via **ATS4**.

ATS3 Set Command Line Termination Character	
Read Command ATS3?	Response <n> OK
Write Command ATS3=<n>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference V.25ter	

Parameter

<n> Integer type. Command line termination character.
Range: 0–127. Default value: 13 (13=<CR>).

2.19. ATS4 Set Response Formatting Character

This command determines the character generated by the module for result code and information text, along with the command line termination character set via **ATS3**.

ATS4 Set Response Formatting Character	
Read Command ATS4?	Response <n> OK
Write Command ATS4=<n>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	

V.25ter

Parameter

<n> Integer type. Response formatting character.
Range: 0–127. Default value: 10 (10=<LF>).

2.20. ATS5 Set Command Line Editing Character

This command determines the character value used by the module to delete the immediately preceding character from the AT command line (i.e. equates to backspace key).

ATS5 Set Command Line Editing Character	
Read Command ATS5?	Response <n> OK
Write Command ATS5=<n>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference V.25ter	

Parameter

<n> Integer type. Command line editing character
Range: 0–127. Default value: 8 (8=<Backspace>).

2.21. ATX Set CONNECT Result Code Format and Monitor Call Progress

This command determines whether or not the module transmits particular result codes to the TE. It also controls whether or not the module detects the presence of a dial tone when it begins dialing and the engaged tone (busy signal).

ATX Set CONNECT Result Code Format and Monitor Call Progress

Execution Command ATX<value>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W .
Reference V.25ter	

Parameter

<value>	Integer type.
0	CONNECT result code is returned only. Dial tone and busy signal detection are both disabled.
1	CONNECT<text> result code is returned only. Dial tone and busy signal detection are both disabled.
2	CONNECT<text> result code is returned. Dial tone detection is enabled, while busy signal detection is disabled.
3	CONNECT<text> result code is returned. Dial tone detection is disabled, while busy signal detection is enabled.
4	CONNECT<text> result code is returned. Dial tone and busy signal detection are both enabled.

2.22. AT+CFUN Set UE Functionality

This command controls the functionality level of the UE. It can also be used to reset the UE.

AT+CFUN Set UE Functionality	
Test Command AT+CFUN=?	Response +CFUN: (list of supported <fun>s),(list of supported <rst>s) OK
Read Command AT+CFUN?	Response +CFUN: <fun> OK
Write Command AT+CFUN=<fun>[,<rst>]	Response OK If there is an error related to ME functionality: +CME ERROR: <err>

	If there is any other error: ERROR
Maximum Response Time	15 s, determined by the network.
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<fun>	Integer type. 0 Minimum functionality <u>1</u> Full functionality 4 Disable the UE from both transmitting and receiving RF signals
<rst>	Integer type. <u>0</u> Do not reset the UE before setting it to <fun> functionality level. 1 Reset the UE before setting it to <fun> functionality level. The device is fully functional after the reset. This value is available only for <fun> =1.
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

Example

```

AT+CFUN=0                                //Switch the UE to minimum functionality.
OK
AT+COPS?
+COPS: 2                                //No operator is registered.

OK
AT+CPIN?
+CME ERROR: 13                          //(U)SIM failure.
AT+CFUN=1                                //Switch the UE to full functionality.
OK

+CPIN: SIM PIN
AT+CPIN=1234
OK

+CPIN: READY

+QUSIM: 1

+QIND: SMS DONE

```

AT+CPIN?

+CPIN: READY

OK

AT+COPS?

+COPS: 0,0,"CHINA MOBILE CMCC",8 //Operator is registered.

OK

2.23. AT+CMEE Error Message Format

This command controls the format of error result codes: **ERROR**, error numbers or verbose messages as **+CME ERROR: <err>** and **+CMS ERROR: <err>**.

AT+CMEE Error Message Format	
Test Command AT+CMEE=?	Response +CMEE: (list of supported <n>s) OK
Read Command AT+CMEE?	Response +CMEE: <n> OK
Write Command AT+CMEE=<n>	Response TA disables or enables the use of result code +CME ERROR: <err> or +CMS ERROR: <err> as an indication of an error related to the functionality of the ME. OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	3GPP TS 27.007

Parameter

<n>	Integer type.
0	Disable result code and use ERROR instead
<u>1</u>	Enable result code and use numeric values
2	Enable result code and use verbose values

<err> Integer type. Error code. Refer to **Table 21** and **Table 22** for possible **<err>** values.

Example

```

AT+CMEE=0                                //Disable result code.
OK
AT+CPIN?
ERROR                                    //Only ERROR will be displayed.
AT+CMEE=1                                //Enable error result code with numeric values.
OK
AT+CPIN?
+CME ERROR: 10
AT+CMEE=2                                //Enable error result code with verbose (string) values.
OK
AT+CPIN?
+CME ERROR: SIM not inserted
    
```

2.24. AT+CSCS Select TE Character Set

The Write Command informs the module which character set is used by the TE. This enables the UE to convert character strings correctly between TE and UE character sets.

AT+CSCS Select TE Character Set	
Test Command AT+CSCS=?	Response +CSCS: (list of supported <chset>s) OK
Read Command AT+CSCS?	Response +CSCS: <chset> OK
Write Command AT+CSCS=<chset>	Response OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately.

	The configuration is not saved.
Reference 3GPP TS 27.007	

Parameter

<chset>	String type. Character set
"GSM"	GSM default alphabet
"IRA"	International reference alphabet
"UCS2"	UCS2 alphabet

Example

```

AT+CSCS?                                     //Query the current character set.
+CSCS: "GSM"

OK

AT+CSCS="UCS2"                               //Set the character set to UCS2.
OK

AT+CSCS?
+CSCS: "UCS2"

OK

```

2.25. AT+QURCCFG Configure URC Indication Option

This command configures the output port of URC.

AT+QURCCFG Configure URC Indication Option	
Test Command AT+QURCCFG=?	Response +QURCCFG: "urcport", (list of supported <URC_port>s) OK
Write Command AT+QURCCFG="urcport", <URC_port>]	Response If the optional parameter is omitted, the command returns the current configuration. +QURCCFG: "urcport", <URC_port> OK

	If the optional parameter is specified, the command sets the URC output port. OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<URC_port>	String type. URC output port.
<u>"usbmodem"</u>	USB modem port
"uart1"	Main UART
"dam"	ATC pipe callback in QuecOpen

Example

```

AT+QURCCFG=?
+QURCCFG: "urcport",("usbmodem","uart1","dam")

OK
AT+QURCCFG="urcport","usbmodem"
OK
AT+QURCCFG="urcport"
+QURCCFG: "urcport","usbmodem"
OK

```

3 Serial Interface Control Commands

3.1. AT&C Set DCD Behavior

This command controls the behavior of the UE's DCD line. It determines how the state of circuit 109 (DCD) relates to the detection of received line signal from the distant end.

AT&C Set DCD Behavior	
Execution Command AT&C[<value>]	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W .
Reference V.25ter	

Parameter

<value>	Integer type.
0	DCD function is always ON
<u>1</u>	DCD function is ON only in the presence of data carrier

3.2. AT&D Set DTR Behavior

This command determines how the TA responds when circuit 108/2 (DTR) is changed from low to high level during data mode.

AT&D Set DTR Behavior	
Execution Command AT&D[<value>]	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W .

Reference
V.25ter

Parameter

<value>	Integer type.
0	TA ignores status on DTR.
1	Low→High on DTR: Change to command mode while remaining the connected call.
2	Low→High on DTR: Disconnect data call, and change to command mode. When DTR is in high level, auto-answer function is disabled.

3.3. AT+IFC Set TE-TA Local Flow Control

This command controls the flow control behavior of the serial port.

AT+IFC Set TE-TA Local Flow Control	
Test Command AT+IFC=?	Response +IFC: (list of supported <DCE_by_DTE>s),(list of supported <DTE_by_DCE>s) OK
Read Command AT+IFC?	Response +IFC: <DCE_by_DTE> , <DTE_by_DCE> OK
Write Command AT+IFC=<DCE_by_DTE>,<DTE_by_DCE>	Response This parameter setting determines the data flow control on the UART interface for data mode. OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference V.25ter	

Parameter

<DCE_by_DTE>	Integer type. Specifies the method to be used by TE when receiving data from TA <u>0</u> None 2 RTS flow control
<DTE_by_DCE>	Integer type. Specifies the method that will be used by TA when receiving data from TE <u>0</u> None 2 CTS flow control

Example

```

AT+IFC=2,2                                     //Enable hardware flow control.
OK
AT+IFC?
+IFC: 2,2
OK

```

3.4. AT+ICF Set TE-TA Character Framing

This command determines the serial interface character framing format and parity received by TA from TE.

AT+ICF Set TE-TA Character Framing	
Test Command AT+ICF=?	Response +ICF: (list of supported <format>s),(list of supported <parity>s) OK
Read Command AT+ICF?	Response +ICF: <format> , <parity> OK
Write Command AT+ICF=<format>[,<parity>]	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately.

	The configuration is not saved.
Reference V.25ter	

Parameter

<format>	Integer type. <u>3</u> 8 data; 0 parity; 1 stop
<parity>	Integer type. 0 Odd 1 Even 2 Mark (1) <u>3</u> Space (0)

NOTE

1. This command is valid only in command mode.
2. The **<parity>** field is ignored if no parity is specified in the **<format>** field.

3.5. AT+IPR Set TE-TA Fixed Local Rate

This command queries and sets the baud rate of the UART. The specified rate takes effect following the issuance of any result code(s) associated with the current command line.

AT+IPR Set TE-TA Fixed Local Rate	
Test Command AT+IPR=?	Response +IPR: (list of supported auto-detectable <rate>s),(list of supported fixed-only <rate>s) OK
Read Command AT+IPR?	Response +IPR: <rate> OK
Write Command AT+IPR=<rate>	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms

Characteristics	The command takes effect immediately. The configurations can be saved with AT&W .
Reference V.25ter	

Parameter

<rate>	Integer type. Baud rate per second. Unit: bps.
	4800
	9600
	19200
	38400
	57600
	115200
	230400
	460800
	921600
	2000000
	2900000
	3000000
	3200000
	3686400
	4000000

NOTE

1. If a fixed baud rate is set, please make sure that both TE (DTE, usually the external processor) and TA (DCE, Quectel module) are configured to the same rate.
2. The value of **AT+IPR** cannot be restored with **AT&F** and **ATZ**, but it is still storable with **AT&W**.
3. In multiplex mode, the baud rate cannot be changed by the Write Command **AT+IPR=<rate>**, and the setting will be invalid and cannot be stored even if **AT&W** is executed after the Write Command.
4. A selected baud rate takes effect after the Write Command is executed and acknowledged by **OK**.

Example

```

AT+IPR=115200           //Specify the fixed baud rate as 115200 bps.
OK
AT&W                     //Store the current setting, that is, remain the default baud rate per second
                           as 115200 bps after module resetting.
OK
AT+IPR?
+IPR: 115200

```



```
OK
AT+IPR=115200;&W //Specify the fixed baud rate as 115200 bps and store the current setting.
OK
```

3.6. AT+QRIR Restore MAIN_RI Behavior to Inactive

If the MAIN_RI (ring indication signal) behavior is "always", it can be restored to be inactive by the Execution Command. The RI behavior is controlled by **AT+QCFG**. Refer to **AT+QCFG="urc/ri/ring"**, **AT+QCFG="urc/ri/smsincoming"**, and **AT+QCFG="urc/ri/other"** for more details.

AT+QRIR Restore RI Behavior to Inactive	
Test Command AT+QRIR=?	Response OK
Execution Command AT+QRIR	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	-

4 Status Control Commands

4.1. AT+CPAS Query ME Activity Status

This Execution Command queries the activity status of ME.

AT+CPAS Query ME Activity Status	
Test Command AT+CPAS=?	Response +CPAS: (list of supported <pas>s) OK
Execution Command AT+CPAS	Response TA returns the activity status of ME: +CPAS: <pas> OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<pas>	Integer type. ME activity status. 0 Ready 3 Ringing 4 Call in progress or call hold
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

Example

```

AT+CPAS
+CPAS: 0                                //ME is ready.

OK
RING
AT+CLCC
+CLCC: 1,1,4,0,0,"15695519173",161

OK
AT+CPAS
+CPAS: 3                                //ME is ringing.

OK
AT+CLCC
+CLCC: 1,0,0,0,0, "10010",129

OK
AT+CPAS
+CPAS: 4                                //Call in progress.

OK

```

4.2. AT+QINDCFG URC Indication Configuration

This command controls URC indication.

AT+QINDCFG URC Indication Configuration

Test Command	Response
AT+QINDCFG=?	+QINDCFG: "all",(list of supported <enable>s),(list of supported <save_to_NVRAM>s) +QINDCFG: "csq",(list of supported <enable>s),(list of supported <save_to_NVRAM>s) +QINDCFG: "smsfull",(list of supported <enable>s),(list of supported <save_to_NVRAM>s) +QINDCFG: "ring",(list of supported <enable>s),(list of supported <save_to_NVRAM>s) +QINDCFG: "smsincoming",(list of supported <enable>s),(list of supported <save_to_NVRAM>s) +QINDCFG: "ccinfo",(list of supported <enable>s),(list of supported <save_to_NVRAM>s)

	OK
Write Command AT+QINDCFG=<URC_type>[,<enable>[,<save_to_NVRAM>]]	Response If the optional parameters are omitted, return the current configuration: +QINDCFG: <URC_type>,<enable> OK If any of the optional parameters is specified, set the URC indication configurations: OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. <save_to_NVRAM> determines whether to save the configuration.

Parameter

<URC_type>	URC type. "all" Main switch of all URCs. <enable> is default to be 1 (ON). "csq" Indication of signal strength and channel bit error rate change. <enable> is default to be 0 (OFF). If this configuration is ON, present: +QIND: "csq",<rssi>,<ber>. See AT+CSQ for details of the URC. "smsfull" SMS storage full indication. <enable> is default to be 0 (OFF). If this configuration is ON, present: +QIND: "smsfull",<storage> <storage> String type. SMS storage location "SM" (U)SIM card "ME" ME "ring" RING indication. <enable> is default to be 1 (ON). "smsincoming" Incoming message indication. <enable> is default to be 1 (ON). Related URC list: +CMTI, +CMT, +CDS See Table 23 for more details of the URCs. "ccinfo" Indication of voice call state change. <enable> is default to be 0. If it is 1, the URC indication is enabled and +QIND: "ccinfo",<id>,<dir>,<state>,<mode>,<empty>,<number>,<type>[,<alpha>] is reported. See Chapter 4.6 of document [14] for more details of the URC
-------------------------	--

<enable>	Integer type. URC indication is ON or OFF
	0 OFF
	1 ON
<save_to_NVRAM>	Whether to save the configurations into NVRAM.
	0 Not save
	1 Save

5 (U)SIM Related Commands

5.1. AT+CIMI Request International Mobile Subscriber Identity (IMSI)

This command requests the International Mobile Subscriber Identity (IMSI) which is intended to permit the TE to identify the individual SIM card or active application in the UICC (GSM or USIM) that is attached to MT.

AT+CIMI Request International Mobile Subscriber Identity (IMSI)	
Test Command AT+CIMI=?	Response OK
Execution Command AT+CIMI	Response <IMSI> OK If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<IMSI>	International Mobile Subscriber Identity (string without double quotes).
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

Example

```

AT+CIMI                                //Query IMSI number of the (U)SIM attached to MT.
460023210226023                        //The IMSI number of the (U)SIM attached to MT.

OK
```

5.2. AT+CLCK Facility Lock

This command locks, unlocks or interrogates an MT or a network facility **<fac>**. Password is normally needed to do such actions. When querying the status of a network service (**<mode>=2**) the response line for “not active” case (**<status>=0**) should be returned only if service is not active for any **<class>**. The command can be aborted when network facilities are being set or interrogated. The factory default password of PF, PN, PU, PP and PC lock is "12341234".

AT+CLCK Facility Lock	
Test Command AT+CLCK=?	Response +CLCK: (list of supported <fac>s) OK
Write Command AT+CLCK=<fac>,<mode>[,<passwd>[,<class>]]	Response If <mode> is not 2 and the command is set successfully: OK If <mode>=2 and the command is set successfully: +CLCK: <status>[,<class>] [+CLCK: <status>[,<class>]] [...] OK
Maximum Response Time	5 s
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference 3GPP TS 27.007	

Parameter

<fac>	String type. Facility lock type.
"SC"	(U)SIM (lock SIM/UICC card installed in the currently selected card slot) (SIM/UICC asks password in MT power-up and when this lock command is issued).
"AO"	BAOC (Barr All Outgoing Calls) (see 3GPP TS 22.088 [6] clause 1).
"OI"	BOIC (Barr Outgoing International Calls) (see 3GPP TS 22.088 [6] clause 1).
"OX"	BOIC-exHC (Barr Outgoing International Calls except to Home Country) (see 3GPP TS 22.088 [6] clause 1).
"AI"	BAIC (Barr All Incoming Calls) (see 3GPP TS 22.088 [6] clause 2).
"IR"	BIC-Roam (Barr Incoming Calls when Roaming outside the home country) (see 3GPP TS 22.088 [6] clause 2).

"AB"	All Barring services (see 3GPP TS 22.030 [19]) (applicable only for <mode>=0).
"AG"	All outGoing barring services (see 3GPP TS 22.030 [19]) (applicable only for <mode>=0).
"AC"	All inComing barring services (see 3GPP TS 22.030 [19]) (applicable only for <mode>=0).
"FD"	SIM card or active application in the UICC (GSM or USIM) fixed dialing memory feature (if PIN2 authentication has not been done during the current session, PIN2 is required as <passwd>).
"PF"	Lock Phone to the very First inserted SIM/UICC card (also referred in the present document as PH-FSIM) (MT asks password when other SIM/UICC cards are inserted).
"PN"	Network Personalization (see 3GPP TS 22.022 [33]).
"PU"	Network sUbset Personalization (see 3GPP TS 22.022 [33]).
"PP"	Service Provider Personalization (see 3GPP TS 22.022 [33]).
"PC"	Corporate Personalization (see 3GPP TS 22.022 [33]).
<mode>	Integer type. Operation mode.
0	Unlock
1	Lock
2	Query status
<passwd>	String type. Password. This parameter can be omitted when <mode>=2 .
<class>	Integer type. A sum of integers each representing a class of information.
1	Voice
2	Data
4	Fax
7	All telephony except SMS
8	Short message service
16	Data circuit synchronization
32	Data circuit asynchronization
<status>	Integer type. Current status of the specified <class> .
0	OFF
1	ON

NOTE

Only "SC" lock is supported currently.

Example

```

AT+CLCK="SC",2           //Query the status of (U)SIM card.
+CLCK: 0                 //The (U)SIM card is unlocked (OFF).

OK
AT+CLCK="SC",1,"1234"    //Lock (U)SIM card, and the password is 1234.

```



```

OK
AT+CLCK="SC",2           //Query the status of (U)SIM card.
+CLCK: 1                 //The (U)SIM card is locked (ON).

OK
AT+CLCK="SC",0,"1234"    //Unlock (U)SIM card.
OK

```

5.3. AT+CPIN Enter PIN

This command sends to the MT a password which is necessary before it can be operated, or queries whether the MT requires a password or not before it can be operated. The password may be (U)SIM PIN, (U)SIM PUK, PH-SIM PIN, etc.

After the Write Command is executed, the TA stores the password, such as (U)SIM PIN, (U)SIM PUK, etc., which is necessary before it can be operated. If the PIN is to be entered twice, the TA automatically repeats the PIN. If no PIN request is pending, no action is taken and an error message, **+CME ERROR**, is returned to TE.

If the PIN required is (U)SIM PUK or (U)SIM PUK2, the second pin is required. This second pin, **<newpin>**, is used to replace the old pin in the (U)SIM.

AT+CPIN Enter PIN	
Test Command AT+CPIN=?	Response OK
Read Command AT+CPIN?	Response +CPIN: <code> OK
Write Command AT+CPIN=<pin>[,<newpin>]	Response OK +CPIN: READY If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	5 s
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<code>	String without double quotes. Indicates whether or not a password is required.
READY	MT is not pending for any password
SIM PIN	MT is waiting (U)SIM PIN to be given
SIM PUK	MT is waiting (U)SIM PUK to be given
SIM PIN2	MT is waiting (U)SIM PIN2 to be given
SIM PUK2	MT is waiting (U)SIM PUK2 to be given
PH-NET PIN	MT is waiting network personalization password to be given
PH-NET PUK	MT is waiting network personalization unblocking password to be given
PH-NETSUB PIN	MT is waiting network subset personalization password to be given
PH-NETSUB PUK	MT is waiting network subset personalization unblocking password to be given
PH-SP PIN	MT is waiting service provider personalization password to be given
PH-SP PUK	MT is waiting service provider personalization unblocking password to be given
PH-CORP PIN	MT is waiting corporate personalization password to be given
PH-CORP PUK	MT is waiting corporate personalization unblocking password to be given
<pin>	String type. Password. If the requested password was a PUK, such as (U)SIM PUK1, PH-FSIM PUK or another password, then <pin> must be followed by <newpin> .
<newpin>	String type. New password required if the requested code was a PUK.
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

Example

```
//Enter PIN
AT+CPIN?
+CPIN: SIM PIN           //Waiting for (U)SIM PIN to be given

OK
AT+CPIN="1234"           //Enter PIN
OK

+CPIN: READY
AT+CPIN?
+CPIN: READY           //PIN has already been entered

OK

//Enter PUK and PIN
```

AT+CPIN?

+CPIN: SIM PUK

//Waiting for (U)SIM PUK to be given

OK

AT+CPIN="26601934","1234"

//Enter PUK and the new password

OK

+CPIN: READY

AT+CPIN?

+CPIN: READY

//PUK has already been entered

OK

5.4. AT+CPWD Change Password

The Write Command sets a new password for the facility lock function defined by **AT+CLK**.

The Test Command returns a list of pairs which present the available facilities and the maximum length of their passwords.

AT+CPWD Change Password	
Test Command AT+CPWD=?	Response +CPWD: (list of supported <fac>s),<pwdlength> OK
Write Command AT+CPWD=<fac>,<oldpwd>,<newpwd>	Response OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	5 s
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<fac>	String type. Facility lock type.
"SC"	(U)SIM (lock SIM/UICC card) (SIM/UICC asks password in MT power-up and when this lock command is issued)
"AO"	BAOC (Bar All Outgoing Calls) (see <i>3GPP TS 22.088 [6] clause 1</i>)
"OI"	BOIC (Bar Outgoing International Calls) (see <i>3GPP TS 22.088 [6] clause 1</i>).
"OX"	BOIC-exHC (Bar Outgoing International Calls except to Home Country) (see <i>3GPP TS 22.088 [6] clause 1</i>).
"AI"	BAIC (Bar All Incoming Calls) (see <i>3GPP TS 22.088 [6] clause 2</i>).
"IR"	BIC-Roam (Bar Incoming Calls when Roaming outside the home country) (see <i>3GPP TS 22.088 [6] clause 2</i>).
"AB"	All Barring services (see <i>3GPP TS 22.030 [19]</i>) (applicable only for <mode>=0).
"AG"	All outGoing barring services (see <i>3GPP TS 22.030 [19]</i>) (applicable only for <mode>=0).
"AC"	All inComing barring services (see <i>3GPP TS 22.030 [19]</i>) (applicable only for <mode>=0)
"P2"	(U)SIM PIN2
<pwdlength>	Integer type. Maximum length of password.
<oldpwd>	String type. Password specified for the facility from the user interface or with command.
<newpwd>	String type. New password.

NOTE

Only "SC" lock is supported currently.

Example

```

AT+CPIN?
+CPIN: READY

OK
AT+CPWD="SC","1234","4321"           //Change (U)SIM card password to "4321"
OK
//Restart the module or re-activate the (U)SIM card
AT+CPIN?
+CPIN: SIM PIN                       //Waiting (U)SIM PIN to be given

OK
AT+CPIN="4321"                       //PIN must be entered to define a new password "4321"
OK

```

+CPIN: READY

5.5. AT+CRSM Restricted (U)SIM Access

This command offers easy and limited access to the (U)SIM database. It transmits the (U)SIM command number (**<command>**) and its required parameters to the MT.

AT+CRSM Restricted (U)SIM Access	
Test Command AT+CRSM=?	Response OK
Write Command AT+CRSM=<command>[,<fileId>[,<P1>,<P2>,<P3>[,<data>][,<pathId>]]]	Response +CRSM: <sw1>,<sw2>[,<response>] OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	-
Reference <i>3GPP TS 27.007</i>	

Parameter

<command>	Integer type. (U)SIM command number. 176 READ BINARY 178 READ RECORD 192 GET RESPONSE 214 UPDATE BINARY 220 UPDATE RECORD 242 STATUS
<fileId>	Integer type. Identifier for an elementary data file on (U)SIM, if used by <command> .
<P1>/<P2>/<P3>	Integer type. Parameters transferred by the MT to the (U)SIM. These parameters are mandatory for every command, except GET RESPONSE and STATUS. The values are described in <i>3GPP TS 51.011 [28]</i> .
<data>	Information which shall be written to the (U)SIM (hexadecimal character

	format; refer to AT+CSCS).
<pathId>	String type. The directory path of an elementary file on the SIM/UICC in hexadecimal format.
<sw1>/<sw2>	Integer type. Information from the (U)SIM about the execution of the actual command. These parameters are delivered to the TE in both cases, on successful or failed execution of the command.
<response>	Response of a successful completion of the command previously issued (hexadecimal character format; refer to AT+CSCS). STATUS and GET RESPONSE return data, which gives information about the current elementary data field. The information includes the type of file and its size (refer to 3GPP TS 51.011 [28]). After READ BINARY, READ RECORD or RETRIEVE DATA command, the requested data will be returned. <response> will not be returned after a successful UPDATE BINARY, UPDATE RECORD or SET DATA command.
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

5.6. AT+QCCID Show ICCID

This command returns the ICCID (Integrated Circuit Card Identifier) number of the (U)SIM card.

AT+QCCID Show ICCID	
Test Command AT+QCCID=?	Response OK
Execution Command AT+QCCID	Response +QCCID: <ICCID> OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	-

Parameter

<ICCID>	The ICCID number of the current (U)SIM card.
----------------------	--

Example

```

AT+QCCID                                     //Query ICCID of the (U)SIM card
+QCCID: 89860025128306012474

OK

```

5.7. AT+QPINC Display PIN Remainder Counter

This command queries the number of attempts left to enter the password of (U)SIM PIN/PUK.

AT+QPINC Display PIN Remainder Counter	
Test Command AT+QPINC=?	Response +QPINC: (list of supported <facility>s) OK
Read Command AT+QPINC?	Response +QPINC: "SC",<PIN_counter>,<PUK_counter> +QPINC: "P2",<PIN_counter>,<PUK_counter> OK
Write Command AT+QPINC=<facility>	Response +QPINC: <facility>,<PIN_counter>,<PUK_counter> OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	-

Parameter

<facility>	String type. "SC" (U)SIM PIN "P2" (U)SIM PIN2
<PIN_counter>	Number of attempts left to enter the password of PIN.
<PUK_counter>	Number of attempts left to enter the password of PUK.

<err> Integer type. Error code. Refer to **Table 21** for possible <err> values.

5.8. AT+QINISTAT Query Initialization Status of (U)SIM Card

This command queries the initialization status of (U)SIM card.

AT+QINISTAT Query Initialization Status of (U)SIM Card	
Test Command AT+QINISTAT=?	Response +QINISTAT: (list of supported <status>s) OK
Execution Command AT+QINISTAT	Response +QINISTAT: <status> OK
Maximum Response Time	300 ms
Characteristics	-

Parameter

<status>	Integer type. Initialization status of (U)SIM card. Actual value is the sum of several of the following three kinds (3 = 1 + 2 means CPIN READY & SMS initialization completed).
0	Initial state
1	CPIN READY. Operation like lock/unlock PIN is allowed
2	SMS initialization completed

5.9. AT+QSIMDET (U)SIM Card Detection

This command enables (U)SIM card hot-swap function. (U)SIM card is detected by GPIO interrupt. The level of (U)SIM card detection pin should also be set when the (U)SIM card is inserted.

AT+QSIMDET (U)SIM Card Detection	
Test Command AT+QSIMDET=?	Response +QSIMDET: (list of supported <enable>s),(list of supported <insert_level>s) OK
Read Command	Response

AT+QSIMDET?	+QSIMDET: <enable>,<insert_level> OK
Write Command AT+QSIMDET=<enable>,<insert_level> >	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	This command takes effect after rebooting. The configuration is saved automatically.

Parameter

<enable>	Integer type. Enables or disables (U)SIM card detection. 0 Disable 1 Enable
<insert_level>	Integer type. The level of (U)SIM card detection pin when a (U)SIM card is inserted. 0 Low level 1 High level

NOTE

Hot-swap function is invalid if the configured value of <insert_level> is inconsistent with hardware design.

Example

```

AT+QSIMDET=1,0           //Set (U)SIM card detection pin level as low when (U)SIM card is inserted
OK
//Remove (U)SIM card
+CPIN: NOT READY
//Insert (U)SIM card and if PIN1 of the (U)SIM card is unlocked
+CPIN: READY

```

5.10. AT+QSIMSTAT (U)SIM Card Insertion Status Report

This command queries (U)SIM card insertion status or determines whether (U)SIM card insertion status report is enabled.

AT+QSIMSTAT (U)SIM Card Insertion Status Report	
Test Command AT+QSIMSTAT=?	Response +QSIMSTAT: (list of supported <enable>s) OK
Read Command AT+QSIMSTAT?	Response +QSIMSTAT: <enable>,<inserted_status> OK
Write Command AT+QSIMSTAT=<enable>	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after rebooting; The configuration is saved automatically.

Parameter

<enable>	Integer type. Enables or disables (U)SIM card insertion status report. If it is enabled, the URC +QSIMSTAT: <enable>,<inserted_status> will be reported when (U)SIM card is removed or inserted. 0 Disable 1 Enable
<inserted_status>	Integer type. (U)SIM card is inserted or removed. This argument is not allowed to be set. 0 Removed 1 Inserted 2 Unknown, before (U)SIM initialization

Example

```
AT+QSIMSTAT?           //Query (U)SIM card insertion status
+QSIMSTAT: 0,1
```

```
OK
AT+QSIMDET=1,0
OK
AT+QSIMSTAT=1           //Enable (U)SIM card insertion status report
OK
AT+QSIMSTAT?
+QSIMSTAT: 1,1

OK
<Remove (U)SIM card>
+QSIMSTAT: 1,0           //Report of (U)SIM card insertion status: removed

+CPIN: NOT READY
AT+QSIMSTAT?
+QSIMSTAT: 1,0

OK
<Insert (U)SIM card>
+QSIMSTAT: 1,1           //Report of (U)SIM card insertion status: inserted

+CPIN: READY
```

6 Network Service Commands

6.1. AT+CREG Network Registration Status

The Write Command controls the presentation of an unsolicited result code **+CREG: <stat>** when **<n>=1** and there is a change in the MT's circuit mode network registration status in GERAN/E-UTRAN, or unsolicited result code **+CREG: <stat>[,<lac>],[<ci>],[<AcT>]]** when **<n>=2** and there is a change of the network cell in GERAN/E-UTRAN.

AT+CREG Network Registration Status	
Test Command AT+CREG=?	Response +CREG: (list of supported <n>s) OK
Read Command AT+CREG?	Response +CREG: <n>,<stat>[,<lac>,<ci>[,<AcT>]] OK
Write Command AT+CREG[=<n>]	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W .
Reference	3GPP TS 27.007

Parameter

<n>	Integer type.
0	Disable network registration unsolicited result code
1	Enable network registration unsolicited result code: +CREG:<stat>
2	Enable network registration and location information unsolicited result code: +CREG: <stat>[,<lac>],[<ci>],[<AcT>]]

<stat>	Integer type. Circuit mode registration status.
0	Not registered. MT is not currently searching an operator to register to
1	Registered, home network
2	Not registered, but MT is currently trying to attach the network or searching an operator to register to
3	Registration denied
4	Unknown
5	Registered, roaming
<lac>	String type. Two-byte location area code in hexadecimal format.
<ci>	String type. Four-byte GERAN/E-UTRAN cell ID in hexadecimal format.
<AcT>	Integer type. Access technology of the serving cell.
0	GSM
8	eMTC
9	NB-IoT

6.2. AT+COPS Operator Selection

This command returns the current operators and their status, and allows automatic or manual network selection.

The Test Command returns a set of five parameters, each representing an operator presenting in the network. The set consists of an integer indicating the availability of the operator **<stat>**, long and short alphanumeric format of the name of the operator, numeric format representation of the operator and access technology. Any of the formats may be unavailable and should then be an empty field. The list of operators shall be in the order of: home network, networks referenced in (U)SIM and other networks.

The Read Command returns the current mode and the currently selected operator. If no operator is selected, then **<format>**, **<oper>** and **<Act>** are omitted.

The Write Command forces an attempt to select and register the GSM/LTE network operator. If the selected operator is not available, no other operator shall be selected (except **<mode>=4**). The format of selected operator name shall apply to further Read Commands (**AT+COPS?**).

AT+COPS Operator Selection	
Test Command AT+COPS=?	Response +COPS: [(list of supported <stat>s, long alphanumeric <oper>s, short alphanumeric <oper>, numeric <oper>[, <Act>])s][, [(list of supported <mode>s), (list of supported <format>s)] OK If there is an error related to ME functionality:

	+CME ERROR: <err> If there is any other error: ERROR
Read Command AT+COPS?	Response +COPS: <mode>[,<format>[,<oper>][,<Act>]] OK If there is an error related to ME functionality: +CME ERROR: <err>
Write Command AT+COPS=<mode>[,<format>[,<oper>[,<Act>]]]	Response OK If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	180 s, determined by the network.
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference 3GPP TS 27.007	

Parameter

<stat>	Integer type. 0 Unknown 1 Operator available 2 Current operator 3 Operator forbidden
<oper>	String type. Operator in format as per <mode>
<mode>	Integer type. 0 Automatic mode. <oper> field can be ignored. 1 Manual operator selection. <oper> field shall be presented and <Act> optionally. 2 Manual deregister from network. 3 Set only <format> (for AT+COPS? Read Command), and do not attempt to register/deregister (<oper> and <Act> fields are ignored). This value is invalid in the response of the Read Command. 4 Manual/automatic selection. <oper> field shall be presented. If manual selection fails, automatic mode (<mode> =0) is entered.
<format>	Integer type. 0 Long format alphanumeric <oper> which can be up to 16 characters. 1 Short format alphanumeric <oper> 2 Numeric <oper> . GSM location area identification number.

<Act>	Integer type. Access technology selected.
0	GSM
8	eMTC
9	NB-IoT
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

NOTE

When executing **AT+COPS=1[,<format>[,<oper>[,<Act>]]]** to manually select the operator network (PLMN is locked), if the selected operator network is abnormal and unavailable, the module is unable to complete the network registration. Therefore, it is recommended to design an exception handling mechanism, for example, switching to COPS mode 0 through **AT+COPS=0** to automatically search available operator network in such an abnormal case; or directly use **AT+COPS=4** (if manual selection fails, automatic mode is entered) instead of **AT+COPS=1**.

Example

```

AT+COPS=?                                //List all current network operators
+COPS: (3,"CHN-UNICOM","UNICOM","46001",0),(3,"CHINA MOBILE","CMCC","46000",0),(1,"CH
N-CT","CT","46011",9),,(0,1,2,3,4),(0,1,2)

OK
AT+COPS?                                //Query the currently selected network operator
+COPS: 0,0,"CHN-UNICOM",0

OK

```

6.3. AT+CSQ Signal Quality Report

The Execution Command returns the received signal strength indication **<rssi>** and the channel bit error rate **<ber>** from the ME.

AT+CSQ Signal Quality Report	
Test Command AT+CSQ=?	Response +CSQ: (list of supported <rssi>s),(list of supported <ber>s) OK
Execution Command AT+CSQ	Response +CSQ: <rssi>,<ber> OK

	If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	-
Reference	
3GPP TS 27.007	

Parameter

<rsqi>	Integer type. Received signal strength level.
0	-113 dBm or less
1	-111 dBm
2–30	-109 to -53 dBm
31	-51 dBm or greater
99	Not known or not detectable
<ber>	Integer type. Channel bit error rate (in percent)
0–7	As RxQual values in the table in 3GPP TS 45.008 subclause 8.2.4
99	Not known or not detectable
<err>	Integer type. Error code. Refer to Table 21 or possible <err> values.

Example

```

AT+CSQ=?
+CSQ: (0-31,99),(0-7,99)

OK
AT+CSQ
+CSQ: 28,99           //The current signal strength indication is 28 (-57 dBm) and channel bit error
                        rate is 99 (not known or not detectable).

OK

```

NOTE

After using the network related commands, it is recommended to wait for 3 seconds before entering **AT+CSQ** so as to ensure that any network access required by the preceding command has been finished.

6.4. AT+CPOL Preferred Operator List

This command edits and queries the list of preferred operators.

AT+CPOL Preferred Operator List	
Test Command AT+CPOL=?	Response +CPOL: (list of supported <index>s),(list of supported <format>s) OK
Read Command AT+CPOL?	Response [+CPOL: <index>,<format>,<oper>[,<GSM>,<GSM_compact>,<UTRAN>,<E-UTRAN>] [+CPOL: <index>,<format>,<oper>[,<GSM>,<GSM_compact>,<UTRAN>,<E-UTRAN>] [...]]] OK
Write Command AT+CPOL=<index>[,<format>[,<oper>[,<GSM>,<GSM_compact>,<UTRAN>,<E-UTRAN>]]]	Response If all parameters after <index> are omitted, delete the specified entry: OK If specified all parameters, edit the list of preferred operators: OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<index>	Integer type. The order number of operator in the (U)SIM preferred operator list.
<format>	Integer type. Format of operator name.
0	Long format alphanumeric <oper>

	1	Short format alphanumeric <oper>
	2	Numeric <oper>
<oper>		String type. Operation name. <format> indicates the format is alphanumeric or numeric (see AT+COPS)
<GSM>		Integer type. GSM access technology.
	0	Access technology is not selected
	1	Access technology is selected
<GSM_compact>		Integer type. GSM compact access technology.
	0	Access technology is not selected
	1	Access technology is selected
<UTRAN>		Integer type. UTRAN access technology.
	0	Access technology is not selected
	1	Access technology is selected
<E-UTRAN>		Integer type. E-UTRAN access technology.
	0	Access technology is not selected
	1	Access technology is selected

NOTE

1. The access technology selection parameters **<GSM>**, **<GSM_compact>**, **<UTRAN>** and **<E-UTRAN>** are required for SIM cards or UICCs containing PLMN selector with access technology.
2. The parameter **<UTRAN>** is invalid.

6.5. AT+COPN Read Operator Names

This command returns the list of operator names from the MT. Each operator code **<numericn>** that has an alphanumeric equivalent **<alphan>** in the MT memory is returned.

AT+COPN Read Operator Names	
Test Command AT+COPN=?	Response OK
Execution Command AT+COPN	Response +COPN: <numeric1>,<alpha1> [+COPN: <numeric2>,<alpha2> [...]] OK If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	Depends on the number of operator names.

Characteristics	-
Reference	
3GPP TS 27.007	

Parameter

<numeric>	String type. Operator in numeric format (see AT+COPS).
<alphan>	String type. Operator in long alphanumeric format (see AT+COPS).
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

6.6. AT+CTZU Automatic Time Zone Update

This command enables/disables automatic time zone update via NITZ.

AT+CTZU Automatic Time Zone Update	
Test Command AT+CTZU=?	Response +CTZU: (list of supported <onoff>s) OK
Read Command AT+CTZU?	Response +CTZU: <onoff> OK
Write Command AT+CTZU=<onoff>	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	
3GPP TS 27.007	

Parameter

<onoff>	Integer type. The mode of automatic time zone update.
0	Disable automatic time zone update via NITZ
<u>1</u>	Enable automatic time zone update via NITZ
3	Enable automatic time zone update via NITZ and update LOCAL time to RTC

Example

```

AT+CTZU?
+CTZU: 0

OK
AT+CTZU=?
+CTZU: (0,1,3)

OK
AT+CTZU=1
OK
AT+CTZU?
+CTZU: 1

OK

```

6.7. AT+CPSMS Power Saving Mode Setting

This command controls the setting of the UE's Power Saving Mode (PSM) parameters.

AT+CPSMS Power Saving Mode Setting	
Test Command AT+CPSMS=?	Response +CPSMS: (list of supported <mode>s),(list of supported <Requested_Periodic-RAU>s),(list of supported <Requested_GPRS-READY-timer>s),(list of supported <Requested_Periodic-TAU>s),(list of supported <Requested_Active-Time>s) OK
Read Command AT+CPSMS?	Response +CPSMS: <mode> ,[<Requested_Periodic-RAU>],[<Requested_GPRS-READY-timer>],[<Requested_Periodic-TAU>],[<Requested_Active-Time>] OK
Write Command AT+CPSMS=[<mode>[,<Requested_Periodic-RAU>[,<Requested_GPRS-READY-timer>[,<Requested_Periodic-TAU>[,<Requested_Active-Time>]]]]]	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms

Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference 3GPP TS 27.007	

Parameter

<mode>	Integer type. Disable or enable the use of PSM in the UE. <u>0</u> Disable the use of PSM 1 Enable the use of PSM
<Requested_Periodic-RAU>	String type. One byte in an 8-bit format. Requested extended periodic RAU value (T3312) to be allocated to the UE in GERAN. (e.g. "01000111" equals 70 hours) Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6 0 0 0 value is incremented in multiples of 10 minutes 0 0 1 value is incremented in multiples of 1 hour 0 1 0 value is incremented in multiples of 10 hours 0 1 1 value is incremented in multiples of 2 seconds 1 0 0 value is incremented in multiples of 30 seconds 1 0 1 value is incremented in multiples of 1 minute
<Requested_GPRS-READY-timer>	String type. One byte in an 8-bit format. Requested GPRS READY timer value (T3314) to be allocated to the UE in GERAN. (e.g. "01001010" equals 1 hours) Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6 0 0 0 value is incremented in multiples of 2 seconds 0 0 1 value is incremented in multiples of 1 minute 0 1 0 value is incremented in multiples of decihours 1 1 1 value indicates that the timer is deactivated.
<Requested_Periodic-TAU>	String type. One byte in an 8-bit format. Requested extended periodic TAU value (T3412) to be allocated to the UE in E-UTRAN. (e.g. "00001010" equals 100 minutes) Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6 0 0 0 value is incremented in multiples of 10 minutes 0 0 1 value is incremented in multiples of 1 hour 0 1 0 value is incremented in multiples of 10 hours 0 1 1 value is incremented in multiples of 2 seconds 1 0 0 value is incremented in multiples of 30 seconds

	1 0 1 value is incremented in multiples of 1 minute
<Requested_Active-Time>	String type. One byte in an 8-bit format. Requested Active Time value (T3324) to be allocated to the UE. (e.g. "00001111" equals 30 seconds) Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6 0 0 0 value is incremented in multiples of 2 seconds 0 0 1 value is incremented in multiples of 1 minute 0 1 0 value is incremented in multiples of decihours 1 1 1 value indicates that the timer is deactivated.

Example

```
AT+CPSMS=1,,"0000100","00001111" //Set the requested T3412 value to 40 minutes, and set the
requested T3324 value to 30 seconds.
OK
```

6.8. AT+QPSMS Power Saving Mode Setting

Quectel extended AT command for PSM setting. The Write Command controls the setting of the module's Power Saving Mode (PSM) parameters. It is similar with **AT+CPSMS**.

AT+QPSMS Power Saving Mode Setting	
Test Command AT+QPSMS=?	Response +QPSMS: (list of supported <mode>s),(list of supported <Requested_Periodic-RAU>s),(list of supported <Requested_GPRS-READY-timer>s),(list of supported <Requested_Periodic-TAU>s),(list of supported <Requested_Active-Time>s) OK
Read Command AT+QPSMS?	Response +QPSMS: <mode>,[<Network_Periodic-RAU>],[<Network_GPRS-READY-timer>],[<Network_Periodic-TAU>],[<Network_Active-Time>] OK
Write Command AT+QPSMS=[<mode>],[<Requested_Periodic-RAU>],[<Requested_GPRS-READY-timer>],[<Requested_Periodic-	Response OK If there is any other error:

TAU>[,<Requested_Active-Time>]]]]]	ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<mode>	Integer type. Disable or enable the use of PSM in the UE. 0 Disable the use of PSM 1 Enable the use of PSM
<Requested_Periodic-RAU>	String type. One byte in an 8-bit format. Requested extended periodic RAU value (T3312) to be allocated to the UE in GERAN. (e.g. "01000111" equals 70 hours) Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6 0 0 0 value is incremented in multiples of 10 minutes 0 0 1 value is incremented in multiples of 1 hour 0 1 0 value is incremented in multiples of 10 hours 0 1 1 value is incremented in multiples of 2 seconds 1 0 0 value is incremented in multiples of 30 seconds 1 0 1 value is incremented in multiples of 1 minute
<Requested_GPRS-READY-timer>	String type. One byte in an 8-bit format. Requested GPRS READY timer value (T3314) to be allocated to the UE in GERAN. (e.g. "01001010" equals 1 hours) Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6 0 0 0 value is incremented in multiples of 2 seconds 0 0 1 value is incremented in multiples of 1 minute 0 1 0 value is incremented in multiples of decihours 1 1 1 value indicates that the timer is deactivated.
<Requested_Periodic-TAU>	String type. One byte in an 8-bit format. Requested extended periodic TAU value (T3412) to be allocated to the UE in E-UTRAN. (e.g. "00001010" equals 100 minutes) Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6 0 0 0 value is incremented in multiples of 10 minutes 0 0 1 value is incremented in multiples of 1 hour 0 1 0 value is incremented in multiples of 10 hours 0 1 1 value is incremented in multiples of 2 seconds

	1 0 0 value is incremented in multiples of 30 seconds
	1 0 1 value is incremented in multiples of 1 minute
<Requested_Active-Time>	String type. One byte in an 8-bit format. Requested Active Time value (T3324) to be allocated to the UE. (e.g. "00001111" equals 1 minute) Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6 0 0 0 value is incremented in multiples of 2 seconds 0 0 1 value is incremented in multiples of 1 minute 0 1 0 value is incremented in multiples of decihours 1 1 1 value indicates that the timer is deactivated.
<Network_Periodic-RAU>	Integer type. Extended periodic RAU value (T3312) to be allocated to the UE in GERAN, and the value is specified by network.
<Network_GPRS-READY-timer>	Integer type. GPRS READY timer value (T3314) to be allocated to the UE in GERAN, and the value is specified by network.
<Network_Periodic-TAU>	Integer type. Extended periodic TAU value (T3412) to be allocated to the UE in E-UTRAN, and the value is specified by network.
<Network_Active-Time>	Integer type. Active timer value (T3324) to be allocated to the UE in E-UTRAN, and the value is specified by network.

NOTE

AT+QPSMS? can read the timer value only after the value is allocated by the network. If the value is not allocated by the network, **+QPSMS: 1,,,** will be returned.

Example

```

AT+QPSMS=1,,"00000100","00001111" //Set the requested T3412 value to 40 minutes, and set the
                                     requested T3324 value to 30 seconds.
OK

AT+QPSMS?                             //Query the PSM mode and the periodic-TAU and active
                                     time specified by the network.
+QPSMS: 1,,"86400","2"
OK

```


6.9. AT+QPSMCFG PSM Feature and Minimum Threshold Value Setting

This command sets NV#73769 (PSM configuration) parameters. You can use this AT command to enable or disable PSM function and set the minimum threshold value to enter PSM.

AT+QPSMCFG PSM Feature and Minimum Threshold Value Setting	
Test Command AT+QPSMCFG=?	Response +QPSMCFG: (list of supported <threshold>s),(list of supported <PSM_version>s) OK
Read Command AT+QPSMCFG?	Response +QPSMCFG: <threshold>,<PSM_version> OK
Write Command AT+QPSMCFG=[<threshold>[,<PSM_version>]]	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<threshold>	Integer type. Minimum threshold value to enter PSM. Range: 20–4294967295. Unit: second.
<PSM_version>	Integer type. Bitmask to indicate PSM modes (1: Enable; 0: Disable). Each bit is configured independently. Range: 0–15. Default value: 4. Bit 0 – PSM without network coordination Bit 1 – Rel-12 PSM without context retention Bit 2 – Rel-12 PSM with context retention Bit 3 – PSM in between eDRX cycles

Example

```

AT+QPSMCFG=100           //Set the threshold to 100 seconds.
OK
AT+QPSMCFG?               //Query the threshold value and PSM mode.
+QPSMCFG: 100,5

```

OK

6.10. AT+QPSMEXTCFG Modem Optimization

This command configures PSM, and it is mainly used to set extended parameters for modem optimizations.

AT+QPSMEXTCFG Modem Optimization	
Test Command AT+QPSMEXTCFG=?	Response +QPSMEXTCFG: (list of supported <PSM_opt_mask>s),(list of supported <max_oos_full_scans>s),(list of supported <PSM_duration_due_to_oos>s),(list of supported <PSM_randomization_window>s),(list of supported <max_oos_time>s),(list of supported <eMTC_early_wake_up_time>s) OK
Write Command AT+QPSMEXTCFG=[<PSM_opt_mask>[,<max_oos_full_scans>[,<PSM_duration_due_to_oos>[,<PSM_randomization_window>[,<max_oos_time>[,<eMTC_early_wake_up_time>]]]]]]	Response OK If there is any other error: ERROR
Read Command AT+QPSMEXTCFG?	Response +QPSMEXTCFG: <PSM_opt_mask>,<max_oos_full_scans>,<PSM_duration_due_to_oos>,<PSM_randomization_window>,<max_oos_time>,<eMTC_early_wake_up_time> OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<PSM_opt_mask>	Integer type. Range: 0–15. Default value: 14. 1 st bit of the parameter is used to enable/disable (0: disable; 1: enable) PSM ENTER request without sending PSM_READY_REQ to NAS. This is a quick PSM operation.
----------------	--

	2nd bit of the parameter is used to enable/disable (0: disable; 1: enable) Out of Service (OoS) status indication from Modem to AP. 3rd bit of the parameter is used to enable/disable (0: disable; 1: enable) limited service status indication from Modem to AP. 4th bit the parameter is used to enable/disable (0: disable; 1: enable) deep-sleep mode if PSM cycle is less than the threshold value. If enabled, it puts the device in deep-sleep mode, if PSM is not entered due to not meeting threshold value.
<max_oos_full_scans>	Integer type. Maximum number of full scans to wait before modem declares SYS_PSM_STATUS_OOS to clients. Range: 1–100. Default value: 2.
<PSM_duration_due_to_oos>	Integer type. PSM cycle used by PSM daemon upon OOS/Limited Service indication, due to service outage. Range: 120–4294967295. Default value: 120. Unit: second.
<PSM_randomization_window>	Integer type. PSM wakeup randomization window to avoid network congestion due to all the PSM devices waking up at the same time. Range: 1–1000. Default value: 5. Unit: second.
<max_oos_time>	Integer type. Maximum time in seconds to wait before declaring SYS_PSM_STATUS_OOS to clients. Range: 1–65535. Default value: 120. Unit: second.
<eMTC_early_wakeup_time>	Integer type. Device wakes up early to account for boot-up and acquisition delay. While programming PMIC, PSM daemon reduces PSM cycle by this duration. Range: 1–1000. Default value: 3. Unit: second.

NOTE

If there is no SIM card inserted in the module, the PSM function cannot be supported.

Example

```

AT+QPSMEXTCFG=14,2,120
OK
AT+QPSMEXTCFG?
+QPSMEXTCFG: 14,2,120,5,120,3
OK

```

6.11. AT+CEDRXS e-I-DRX Setting

This command controls the setting of the UE's e-I-DRX (extended Idle-mode DRX) parameters.

AT+CEDRXS e-I-DRX Setting	
Test Command AT+CEDRXS=?	Response +CEDRXS: (list of supported <mode>s),(list of supported <AcT-type>s),(list of supported <Requested_eDRX_value>s) OK
Write Command AT+CEDRXS=<mode>[,<AcT-type>[,<Requested_eDRX_value>]]	Response OK If there is any other error: ERROR
Read Command AT+CEDRXS?	Response [+CEDRXS: <AcT-type>,<Requested_eDRX_value>[+CEDRXS: <AcT-type>,<Requested_eDRX_value>[...]]] OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference 3GPP TS 27.007	

Parameter

<mode>	Integer type. Disable or enable the use of e-I-DRX in the UE. <u>0</u> Disable the use of e-I-DRX 1 Enable the use of e-I-DRX 2 Enable the use of e-I-DRX and enable the unsolicited result code +CEDRXP: <AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]] 3 Disable the use of e-I-DRX and discard all parameters for e-I-DRX or, reset to the default values
<AcT-type>	Integer type. The type of access technology. 0 Access technology is not using eDRX. This parameter value is only used in the unsolicited result code 4 eMTC 5 NB-IoT

<Requested_eDRX_value>	String type. Half a byte in a 4-bit format.				
	Bit				
	4	3	2	1	E-UTRAN e-I-DRX cycle length duration
	0	0	0	0	5.12 seconds
	0	0	0	1	10.24 seconds
	0	0	1	0	20.48 seconds
	0	0	1	1	40.96 seconds
	0	1	0	0	61.44 seconds
	0	1	0	1	81.92 seconds
	0	1	1	0	102.4 seconds
	0	1	1	1	122.88 seconds
	1	0	0	0	143.36 seconds
	1	0	0	1	163.84 seconds
	1	0	1	0	327.68 seconds
	1	0	1	1	655,36 seconds
	1	1	0	0	1310.72 seconds
	1	1	0	1	2621.44 seconds
	1	1	1	0	5242.88 seconds
	1	1	1	1	10485.76 seconds
	<NW-provided_eDRX_value>	String type. Half a byte in a 4-bit format.			
Bit					
4		3	2	1	E-UTRAN e-I-DRX cycle length duration
0		0	0	0	5.12 seconds
0		0	0	1	10.24 seconds
0		0	1	0	20.48 seconds
0		0	1	1	40.96 seconds
0		1	0	0	61.44 seconds
0		1	0	1	81.92 seconds
0		1	1	0	102.4 seconds
0		1	1	1	122.88 seconds
1		0	0	0	143.36 seconds
1		0	0	1	163.84 seconds
1		0	1	0	327.68 seconds
1		0	1	1	655,36 seconds
1		1	0	0	1310.72 seconds
1		1	0	1	2621.44 seconds
1		1	1	0	5242.88 seconds
1		1	1	1	10485.76 seconds
<Paging_time_window>		String type. Half a byte in a 4-bit format.			
	eMTC mode				
	Bit				
	4	3	2	1	Paging Time Window length
	0	0	0	0	1.28 seconds
	0	0	0	1	2.56 seconds

0	0	1	0	3.84 seconds
0	0	1	1	5.12 seconds
0	1	0	0	6.4 seconds
0	1	0	1	7.68 seconds
0	1	1	0	8.96 seconds
0	1	1	1	10.24 seconds
1	0	0	0	11.52 seconds
1	0	0	1	12.8 seconds
1	0	1	0	14.08 seconds
1	0	1	1	15.36 seconds
1	1	0	0	16.64 seconds
1	1	0	1	17.92 seconds
1	1	1	0	19.20 seconds
1	1	1	1	20.48 seconds

NB-IoT mode

Bit

4	3	2	1	Paging Time Window length
0	0	0	0	2.56 seconds
0	0	0	1	5.12 seconds
0	0	1	0	7.68 seconds
0	0	1	1	10.24 seconds
0	1	0	0	12.8 seconds
0	1	0	1	15.36 seconds
0	1	1	0	17.92 seconds
0	1	1	1	20.48 seconds
1	0	0	0	23.04 seconds
1	0	0	1	25.6 seconds
1	0	1	0	28.16 seconds
1	0	1	1	30.72 seconds
1	1	0	0	33.28 seconds
1	1	0	1	35.84 seconds
1	1	1	0	38.4 seconds
1	1	1	1	40.96 seconds

Example

AT+CEDRXS=1,5,"0000"

//Set the requested e-I-DRX value to 5.12 seconds.

OK

6.12. AT+QPTWEDRXS Paging Time Window Value and eDRX Setting

This command controls the setting of the UE's paging time window (PTW) value and eDRX parameters, and whether the UE wants to apply PTW and eDRX or not, as well as the requested PTW and eDRX cycle for each specified type of access technology.

It also controls the presentation of the URC **+QPTWEDRXP: <AcT-type>[,<Requested_paging_time_window>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]]]** when **<mode>=2** and there is a change in the paging time window and eDRX parameters provided by the network.

A special form of the command can be given as **AT+QPTWEDRXS=3**. In this form, paging time window and eDRX will be disabled and data for all parameters in **AT+QPTWEDRXS** will be removed or, if available, set to the default values.

The Read Command returns the current settings for each defined value of **<AcT-type>**.

The Test Command returns the supported **<mode>**s and the value ranges for the access technology and the requested paging time window and requested eDRX value as compound values.

AT+QPTWEDRXS Paging Time Window Value and eDRX Setting	
Test Command AT+QPTWEDRXS=?	Response +QPTWEDRXS: (list of supported <mode>s),(list of supported <AcT-type>s),(list of supported <Requested_paging_time_window>s),(list of supported <Requested_eDRX_value>s) OK
Read Command AT+QPTWEDRXS?	Response +QPTWEDRXS: <AcT-type>,<Requested_paging_time_window>,<Requested_eDRX_value>[,<NW-provided_eDRX_value>],<Paging_time_window>]] OK If there is any error: +CME ERROR:<err> If there is any other error: ERROR
Write Command AT+QPTWEDRXS=<mode>[,<AcT-type>[,<Requested_paging_time_window>[,<Re	Response OK

quested_eDRX_value>]]]	If there is any error: +CME ERROR:<err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	

Parameter

<mode>	Integer type. Indicates to disable or enable the use of requested paging time window and eDRX in the UE. This parameter is applicable to all specified types of access technology, i.e. the most recent setting of <mode> will take effect for all specified values of <AcT> returned by AT+QNWINFO. 0 Disable the use of requested paging time window and eDRX 1 Enable the use of requested paging time window and eDRX 2 Enable the use of requested paging time window and eDRX, and enable the URC: +QPTWEDRXP: <AcT-type>[,<Requested_paging_time_window>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]]] 3 Disable the use of eDRX and discard all parameters for eDRX or, if available, reset to the default values.														
<AcT-type>	Integer type. Indicates the type of access technology. This AT command is used to specify the relationship between the type of access technology and the requested eDRX value. 0 Access technology is not using eDRX. This parameter value is only used in the unsolicited result code. 4 eMTC 5 NB-IoT														
<Requested_paging_time_window>	String type. Half a byte in a 4-bit format. eMTC mode Bit <table> <tr> <td>4 3 2 1</td><td>Paging Time Window length</td></tr> <tr> <td>0 0 0 0</td><td>1.28 seconds</td></tr> <tr> <td>0 0 0 1</td><td>2.56 seconds</td></tr> <tr> <td>0 0 1 0</td><td>3.84 seconds</td></tr> <tr> <td>0 0 1 1</td><td>5.12 seconds</td></tr> <tr> <td>0 1 0 0</td><td>6.4 seconds</td></tr> <tr> <td>0 1 0 1</td><td>7.68 seconds</td></tr> </table>	4 3 2 1	Paging Time Window length	0 0 0 0	1.28 seconds	0 0 0 1	2.56 seconds	0 0 1 0	3.84 seconds	0 0 1 1	5.12 seconds	0 1 0 0	6.4 seconds	0 1 0 1	7.68 seconds
4 3 2 1	Paging Time Window length														
0 0 0 0	1.28 seconds														
0 0 0 1	2.56 seconds														
0 0 1 0	3.84 seconds														
0 0 1 1	5.12 seconds														
0 1 0 0	6.4 seconds														
0 1 0 1	7.68 seconds														

	0 1 1 0	8.96 seconds
	0 1 1 1	10.24 seconds
	1 0 0 0	11.52 seconds
	1 0 0 1	12.8 seconds
	1 0 1 0	14.08 seconds
	1 0 1 1	15.36 seconds
	1 1 0 0	16.64 seconds
	1 1 0 1	17.92 seconds
	1 1 1 0	19.20 seconds
	1 1 1 1	20.48 seconds
	NB-IoT mode	
	Bit	
	4 3 2 1	Paging Time Window length
	0 0 0 0	2.56 seconds
	0 0 0 1	5.12 seconds
	0 0 1 0	7.68 seconds
	0 0 1 1	10.24 seconds
	0 1 0 0	12.8 seconds
	0 1 0 1	15.36 seconds
	0 1 1 0	17.92 seconds
	0 1 1 1	20.48 seconds
	1 0 0 0	23.04 seconds
	1 0 0 1	25.6 seconds
	1 0 1 0	28.16 seconds
	1 0 1 1	30.72 seconds
	1 1 0 0	33.28 seconds
	1 1 0 1	35.84 seconds
	1 1 1 0	38.4 seconds
	1 1 1 1	40.96 seconds
<Requested_eDRX_value>	String type. Half a byte in a 4-bit format.	
	Bit	
	4 3 2 1	E-UTRAN eDRX cycle length duration
	0 0 0 0	5.12 seconds
	0 0 0 1	10.24 seconds
	0 0 1 0	20.48 seconds
	0 0 1 1	40.96 seconds
	0 1 0 0	61.44 seconds
	0 1 0 1	81.92 seconds
	0 1 1 0	102.4 seconds
	0 1 1 1	122.88 seconds
	1 0 0 0	143.36 seconds
	1 0 0 1	163.84 seconds
	1 0 1 0	327.68 seconds
	1 0 1 1	655.36 seconds

	1 1 0 0	1310.72 seconds
	1 1 0 1	2621.44 seconds
	1 1 1 0	5242.88 seconds
	1 1 1 1	10485.76 seconds
<NW-provided_eDRX_value> String type. Half a byte in a 4-bit format.		
Bit		
	4 3 2 1	E-UTRAN eDRX cycle length duration
	0 0 0 0	5.12 seconds
	0 0 0 1	10.24 seconds
	0 0 1 0	20.48 seconds
	0 0 1 1	40.96 seconds
	0 1 0 0	61.44 seconds
	0 1 0 1	81.92 seconds
	0 1 1 0	102.4 seconds
	0 1 1 1	122.88 seconds
	1 0 0 0	143.36 seconds
	1 0 0 1	163.84 seconds
	1 0 1 0	327.68 seconds
	1 0 1 1	655.36 seconds
	1 1 0 0	1310.72 seconds
	1 1 0 1	2621.44 seconds
	1 1 1 0	5242.88 seconds
	1 1 1 1	10485.76 seconds
<Paging_time_window> String type. Half a byte in a 4-bit format.		
eMTC mode		
Bit		
	4 3 2 1	Paging Time Window length
	0 0 0 0	1.28 seconds
	0 0 0 1	2.56 seconds
	0 0 1 0	3.84 seconds
	0 0 1 1	5.12 seconds
	0 1 0 0	6.4 seconds
	0 1 0 1	7.68 seconds
	0 1 1 0	8.96 seconds
	0 1 1 1	10.24 seconds
	1 0 0 0	11.52 seconds
	1 0 0 1	12.8 seconds
	1 0 1 0	14.08 seconds
	1 0 1 1	15.36 seconds
	1 1 0 0	16.64 seconds
	1 1 0 1	17.92 seconds
	1 1 1 0	19.20 seconds
	1 1 1 1	20.48 seconds
NB-IoT mode		

Bit	
4 3 2 1	Paging Time Window length
0 0 0 0	2.56 seconds
0 0 0 1	5.12 seconds
0 0 1 0	7.68 seconds
0 0 1 1	10.24 seconds
0 1 0 0	12.8 seconds
0 1 0 1	15.36 seconds
0 1 1 0	17.92 seconds
0 1 1 1	20.48 seconds
1 0 0 0	23.04 seconds
1 0 0 1	25.6 seconds
1 0 1 0	28.16 seconds
1 0 1 1	30.72 seconds
1 1 0 0	33.28 seconds
1 1 0 1	35.84 seconds
1 1 1 0	38.4 seconds
1 1 1 1	40.96 seconds
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

6.13. AT+CEDRXRDP Read Dynamic Parameters

The Execution Command returns <AcT-type>, <Requested_eDRX_value>, <NW-provided_eDRX_value> and <Paging_time_window> if e-I-DRX is used for the cell that the MS is currently registered to.

AT+CEDRXRDP Read Dynamic Parameters	
Test Command AT+CEDRXRDP=?	Response OK
Execution Command AT+CEDRXRDP	Response +CEDRXRDP: <AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]] OK
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<AcT-type> Integer type. The type of access technology.

- 0 Access technology is not using eDRX
- 4 eMTC
- 5 NB-IoT

<Requested_eDRX_value> String type. Half a byte in a 4-bit format.

Bit

4	3	2	1	E-UTRAN e-I-DRX cycle length duration
0	0	0	0	5.12 seconds
0	0	0	1	10.24 seconds
0	0	1	0	20.48 seconds
0	0	1	1	40.96 seconds
0	1	0	0	61.44 seconds
0	1	0	1	81.92 seconds
0	1	1	0	102.4 seconds
0	1	1	1	122.88 seconds
1	0	0	0	143.36 seconds
1	0	0	1	163.84 seconds
1	0	1	0	327.68 seconds
1	0	1	1	655.36 seconds
1	1	0	0	1310.72 seconds
1	1	0	1	2621.44 seconds
1	1	1	0	5242.88 seconds
1	1	1	1	10485.76 seconds

<NW-provided_eDRX_value> String type. Half a byte in a 4-bit format.

Bit

4	3	2	1	E-UTRAN e-I-DRX cycle length duration
0	0	0	0	5.12 seconds
0	0	0	1	10.24 seconds
0	0	1	0	20.48 seconds
0	0	1	1	40.96 seconds
0	1	0	0	61.44 seconds
0	1	0	1	81.92 seconds
0	1	1	0	102.4 seconds
0	1	1	1	122.88 seconds
1	0	0	0	143.36 seconds
1	0	0	1	163.84 seconds
1	0	1	0	327.68 seconds
1	0	1	1	655.36 seconds
1	1	0	0	1310.72 seconds
1	1	0	1	2621.44 seconds
1	1	1	0	5242.88 seconds
1	1	1	1	10485.76 seconds

<Paging_time_window> String type. Half a byte in a 4-bit format.

eMTC mode

Bit

4	3	2	1	Paging Time Window length
0	0	0	0	1.28 seconds
0	0	0	1	2.56 seconds
0	0	1	0	3.84 seconds
0	0	1	1	5.12 seconds
0	1	0	0	6.4 seconds
0	1	0	1	7.68 seconds
0	1	1	0	8.96 seconds
0	1	1	1	10.24 seconds
1	0	0	0	11.52 seconds
1	0	0	1	12.8 seconds
1	0	1	0	14.08 seconds
1	0	1	1	15.36 seconds
1	1	0	0	16.64 seconds
1	1	0	1	17.92 seconds
1	1	1	0	19.20 seconds
1	1	1	1	20.48 seconds

NB-IoT mode

Bit

4	3	2	1	Paging Time Window length
0	0	0	0	2.56 seconds
0	0	0	1	5.12 seconds
0	0	1	0	7.68 seconds
0	0	1	1	10.24 seconds
0	1	0	0	12.8 seconds
0	1	0	1	15.36 seconds
0	1	1	0	17.92 seconds
0	1	1	1	20.48 seconds
1	0	0	0	23.04 seconds
1	0	0	1	25.6 seconds
1	0	1	0	28.16 seconds
1	0	1	1	30.72 seconds
1	1	0	0	33.28 seconds
1	1	0	1	35.84 seconds
1	1	1	0	38.4 seconds
1	1	1	1	40.96 seconds

6.14. AT+CTZR Time Zone Reporting

This command controls the time zone change event reporting. If reporting is enabled, the MT returns the unsolicited result code **+CTZV: <tz>** or **+CTZE: <tz>,<dst>,<time>** whenever the time zone is changed.

AT+CTZR Time Zone Reporting	
Test Command AT+CTZR=?	Response +CTZR: (list of supported <reporting>s) OK
Write Command AT+CTZR=<reporting>	Response OK If there is any other error: ERROR
Read Command AT+CTZR?	Response +CTZR: <reporting> OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference 3GPP TS 27.007	

Parameter

<reporting>	Integer type. Indicates the mode of time zone reporting. 0 Disable time zone change event reporting 1 Enable time zone change event reporting by unsolicited result code +CTZV: <tz> 2 Enable extended time zone and local time reporting by unsolicited result code: +CTZE: <tz>,<dst>,<time>
<tz>	String type. Represents the sum of the local time zone (difference between the local time and GMT is expressed in quarters of an hour) plus daylight saving time. The format is " ±zz ", expressed as a fixed width, two-digit integer within the range -48 to +56. To maintain a fixed width, numbers in the range -9 to +9 are expressed with a leading zero, e.g. "-09", "+00" and "+09".
<dst>	Integer type. Indicates whether <tz> includes daylight savings adjustment. 0 <tz> includes no adjustment for daylight saving time 1 <tz> includes +1 hour (equals 4 quarters in <tz>) adjustment for daylight saving time 2 <tz> includes +2 hours (equals 8 quarters in <tz>) adjustment for daylight saving

	time
<time>	String type. Represents the local time. The format is "YYYY/MM/DD,hh:mm:ss", expressed as integers representing year (YYYY), month (MM), date (DD), hour (hh), minute (mm) and second (ss). The local time can be derived by the MT from information provided by the network at the time of delivering time zone information and will be present in the unsolicited result code for extended time zone and local time reporting if the universal time is provided by the network.

Example

```

AT+CTZR=2
OK
AT+CTZR?
+CTZR: 2

OK

+CTZE: "+32",0,"2013/08/23,06:51:13"

```

6.15. AT+QNWINFO Query Network Information

This command indicates network information such as the access technology selected, the operator, and the band selected.

AT+QNWINFO Query Network Information	
Test Command AT+QNWINFO=?	Response OK
Execution Command AT+QNWINFO	Response +QNWINFO: <AcT>,<oper>,<band>,<channel> OK
Maximum Response Time	300 ms
Characteristics	-

Parameter

<AcT>	String type. Access technology selected. "No Service" "GSM" "GPRS"
-------	---

	"EDGE"
	"eMTC"
	"NBIoT"
<oper>	String type. Operator in numeric format.
<band>	String type. Band selected.
	"GSM 850"
	"GSM 900"
	"GSM 1800"
	"GSM 1900"
	"LTE BAND 1" – "LTE BAND 85"
<channel>	Integer type. Channel ID.

Example

```
AT+QNWINFO=?
OK
AT+QNWINFO
+QNWINFO: "EDGE","46001","GSM 1800",653
OK
```

6.16. AT+QCSQ Query and Report Signal Strength

This command queries and reports the signal strength of the current service network. If the MT is registered on multiple networks in different service modes, you can query the signal strength of networks in each mode. No matter whether the MT is registered on a network or not, the command can be run to query the signal strength or allow the MT to report the URC indicating the detected signal strength if the MT camps on the network. If the MT is not using any service network or the service mode is uncertain, "NOSERVICE" will be returned as the query result.

AT+QCSQ Query and Report Signal Strength	
Execution Command AT+QCSQ	Response +QCSQ: <sysmode>[,<value1>[,<value2>[,<value3>[,<value4>]]]] OK
Maximum Response Time	300 ms
Characteristics	-

Parameter

<sysmode>	A string type value indicating the service mode in which the MT will unsolicited report the signal strength. "NOSERVICE" NO SERVICE mode "GSM" GSM/GPRS/EDGE mode "eMTC" eMTC mode "NBIoT" NB-IoT mode				
<value1>/ <value2>/ <value3>/ <value4>	The following table lists the signal strength type corresponding to each service mode.				
	<sysmdoe>	<value1>	<value2>	<value3>	<value4>
	"NOSERVICE"				
	"GSM"	<GSM_RSSI>			
	"eMTC"	<LTE_RSSI>	<LTE_RSRP>	<LTE_SINR>	<LTE_RSRQ>
	"NBIoT"	<LTE_RSSI>	<LTE_RSRP>	<LTE_SINR>	<LTE_RSRQ>
<GSM_RSSI>/ <LTE_RSSI>	An integer indicating the received signal strength. These parameters are available for GSM and LTE mode respectively.				
<LTE_RSRP>	An integer indicating the reference signal received power (RSRP). This parameter is available for LTE mode.				
<LTE_SINR>	An integer indicating the signal to interference plus noise ratio (SINR). Logarithmic value of SINR. Values are in 1/5th of a dB. Range: 0–250 which translates to -20 dB to +30 dB.				
<LTE_RSRQ>	An integer indicating the reference signal received quality (RSRQ) in dB.				

Example

```

AT+QCSQ //Execute the command to query signal
+QCSQ: "eMTC",-52,-81,195,-10

OK

AT+QCSQ=? //List of supported <sysmode>s
+QCSQ: "NOSERVICE","GSM","eMTC","NBIoT"

OK

```

6.17. AT+QCSCON Signaling Connection Status

This command gives details of the terminal's perceived radio connection status. It returns an indication of the current state. Note that this state is only updated when radio events, such as sending and receiving, take place. This means that the current state may be out of date. The terminal may think it is "Connected"

yet cannot currently use a base station due to a change in the link quality.

AT+QCSCON Signalling Connection Status	
Test Command AT+QCSCON=?	Response +QCSCON: (list of supported <n>s) OK
Read Command AT+QCSCON?	Response +QCSCON: <n>,<mode> OK If there is any error: +CME ERROR: <err>
Write Command AT+QCSCON=<n>	Response OK If there is any error: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<n>	Integer type. Enables or disables the report of URC +QCSCON: <n>,<mode>. 0 Disable 1 Enable
<mode>	Integer type. indicates the signaling connection status. 0 Idle 1 Connected
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

Example

```

AT+QCSCON=?
+QCSCON: (0,1)

OK
AT+QCSCON?
+QCSCON: 0,0

```

```

OK
AT+QCSCON=1
OK
AT+QIOPEN=1,0,"TCP","192.0.2.2",8433,0,1
OK

+QCSCON: 1,1                                //RRC connection setup

+QIOPEN: 0,0

+QCSCON: 1,0                                //RRC connection release

```

6.18. AT+QLTS Obtain the Latest Time Synchronized Through Network

The Execution Command returns the latest time synchronized through network.

AT+QLTS Obtain the Latest Time Synchronized Through Network	
Test Command AT+QLTS=?	Response +QLTS: (list of supported <mode>s) OK
Execution Command AT+QLTS	Response +QLTS: <time>,<dst> OK
Write Command AT+QLTS=<mode>	Response +QLTS: <time>,<dst> OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	-

Parameter

<mode>	Integer type. Query network time mode
0	Query the latest time that has been synchronized through network
1	Query the current GMT time calculated from the latest time that has been synchronized through network
2	Query the current LOCAL time calculated from the latest time that has been synchronized through network
<time>	String type. Format: "yy/MM/dd, hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; range -48...+48). E.g. 6th of May 2004, 22:10:00 GMT+2 hours equals "04/05/06,22:10:00+08"
<dst>	Integer type. Daylight saving time.

NOTE

If the time has not been synchronized through network, the command will return a null time string: +QLTS: "".

Example

```

AT+QLTS=?           //Query supported network time modes
+QLTS: (0-2)

OK
AT+QLTS             //Query the latest time synchronized through network
+QLTS: "2020/06/02,01:47:33+32,0"

OK
AT+QLTS=0           //Query the latest time synchronized through network. It offers the same function
                    //as Execution Command AT+QLTS.
+QLTS: "2020/06/02,01:47:33+32,0"

OK
AT+QLTS=1           //Query the current GMT time calculated from the latest time that has been
                    //synchronized through network.
+QLTS: "2020/06/02,01:48:36+32,0"

OK
AT+QLTS=2           //Query the current LOCAL time calculated from the latest time that has been
                    //synchronized through network.
+QLTS: "2020/06/02,09:48:51+32,0"

OK

```

6.19. AT+QCOPS Scan Current Available Networks

This command triggers carrier scan, scanning a list of network information for all available carriers at the current physical location, regardless of whether SIM card is inserted.

AT+QCOPS Scan Current Available Network	
Test Command AT+QCOPS=?	Response +QCOPS: (list of supported <scan_mode>s) OK If there is any error: ERROR
Write Command AT+QCOPS=<scan_mode>	Response If a network is detected, the number of cells is displayed. +QCOPS: <num> If <scan_mode>=0 (in the automatic mode): OK +QCOPS: <num> [+QCOPS: "GSM",<MCC>,<MNC>,<ARFCN>,<LAC>,<cell_ID>,<BSIC>,<rx_lev>,<cell_is_barred>,<GPRS_is_supported>] [+QCOPS: "eMTC",<MCC>,<MNC>,<TAC>,<EARFCN>,<PCI>,<cell_ID>,<RSRP>,<RSRQ>,<RSSI>,<cell_is_barred>,<bandwidth>] [+QCOPS: "NBIoT",<MCC>,<MNC>,<TAC>,<EARFCN>,<PCI>,<cell_ID>,<RSRP>,<RSRQ>,<RSSI>,<cell_is_barred>] [...] If <scan_mode>=1 (in the GSM network mode): OK +QCOPS: <num> [+QCOPS: "GSM",<MCC>,<MNC>,<ARFCN>,<LAC>,<cell_ID>,<BSIC>,<rx_lev>,<cell_is_barred>,<GPRS_is_supported>]

	rted>] [...] If <scan_mode>=2 (in the eMTC network mode): OK +QCOPS: <num> [+QCOPS: "eMTC",<MCC>,<MNC>,<TAC>,<EARFCN>,<PCI>,<cell_ID>,<RSRP>,<RSRQ>,<RSSI>,<cell_is_barred>,<bandwidth>] [...] If <scan_mode>=3 (in the NB-IoT network mode): OK +QCOPS: <num> [+QCOPS: "NB-IoT",<MCC>,<MNC>,<TAC>,<EARFCN>,<PCI>,<cell_ID>,<RSRP>,<RSRQ>,<RSSI>,<cell_is_barred>] [...] If <scan_mode>=4 (in the LTE only mode): OK +QCOPS: <num> [+QCOPS: "eMTC",<MCC>,<MNC>,<TAC>,<EARFCN>,<PCI>,<cell_ID>,<RSRP>,<RSRQ>,<RSSI>,<cell_is_barred>,<bandwidth>] [+QCOPS: "NB-IoT",<MCC>,<MNC>,<TAC>,<EARFCN>,<PCI>,<cell_ID>,<RSRP>,<RSRQ>,<RSSI>,<cell_is_barred>] [...] If there is any error: ERROR
Maximum Response Time	300 ms

Characteristics

-

Parameter

<scan_mode>	Integer type. The mode of scanning surrounding cell. 0 Automatic mode 1 GSM network mode 2 eMTC network mode 3 NB-IoT network mode 4 LTE only mode
<num>	Integer type. Number of detected network cells.
<MCC>	Integer type. A three-digit value indicating mobile country code.
<MNC>	Integer type. A two-digit or three-digit value indicating the mobile network code.
<ARFCN>	Integer type. Absolute radio frequency channel number. The parameter determines the ARFCN of the cell that was scanned. Range: 0–1023.
<LAC>	Integer type. Two-byte location area code in hexadecimal format.
<cell_ID>	Integer type. Cell ID in hexadecimal format.
<BSIC>	Integer type. Base station identification code.
<rx_lev>	Integer type. Received signal strength level.
<TAC>	Integer type. Three-byte tracking area code in hexadecimal format.
<EARFCN>	Integer type. E-UTRA absolute radio frequency channel number.
<PCI>	Integer type. Physical cell identity.
<RSRP>	Integer type. Reference signal received power.
<RSRQ>	Integer type. Reference signal received quality.
<RSSI>	Integer type. Received signal strength indication.
<cell_is_barred>	Integer type. This parameter indicates whether the cell is barred or not for camping. 0 Not barred 1 Barred
<GPRS_is_supported>	Integer type. This parameter indicates whether the cell supports GPRS. 0 Not supported 1 Supported 2 Unknown
<bandwidth>	Integer type. Current network bandwidth. 0 1.4 Mbps 1 3 Mbps 2 5 Mbps 3 10 Mbps 4 15 Mbps 5 20 Mbps

NOTE

1. The scan results will be presented in the form of URC. If one scan is not completed, the next scan cannot be performed.
2. `<scan_mode>` is specified based on the configurations of `AT+QCFG="nwscanmode"`, `AT+QCFG="iotopmode"` and `AT+QCFG="band"`. In addition, these commands can also be used to stop scanning. See *document [12]* for details.
3. Do not execute data services during network scanning.
4. If no network is available, **+QCOPS: No Service** is reported.
5. There is a guard timer for every RAT scan to control scan time. For example, the guard timer for Cat M is 5 minutes, for NB-IoT is 6 minutes, and for GSM is 3 minutes.
6. The scan result displays a maximum of 8 available networks for each RAT.
7. The module cannot process downlink paging message from network during network scanning.

Example

```

AT+QCOPS=1
OK

+QCOPS: No Service
AT+QCOPS=2
OK

+QCOPS: 1

+QCOPS: eMTC,460,00,1,6300,31,1A2E0A6,-96,-5,-78,0,3
AT+QCOPS=3
OK

+QCOPS: 2

+QCOPS: NBIoT,460,00,4C10,3686,207,84845B2,-127,-17,-110,0

+QCOPS: NBIoT,505,01,2,9510,51,1A2D01,-131,-16,-114,0
    
```


7 Call Related Commands*

All commands in this chapter are still under development.

7.1. ATD Mobile Originated Call to Dial a Number

This command sets up outgoing voice and data or fax calls. Supplementary services can also be controlled with this command.

ATD Mobile Originated Call to Dial a Number	
Execution Command ATD<n>[<mgs>][:]	Response If no dial tone and ATX2 or ATX4 is set: NO DIALTONE If busy and ATX3 or ATX4 is set: BUSY If a connection cannot be established: NO CARRIER If the connection is established successfully and a non-voice call is to be set up: CONNECT<text> And TA switches to data mode. <text> outputs only when <value> is greater than 0 in ATX<value> parameter setting. When TA returns to command mode after the call release: OK If the connection is established successfully and a voice call is set up: OK
Maximum Response Time	5 s, determined by the network.
Characteristics	-
Reference	

V.25ter

Parameter

<n>	String of dialing digits and optionally V.25ter modifiers Dialing digits: 0-9, *, #, +, A, B, C Following V.25ter, modifiers are ignored: , (comma), T, P, !, W, @
<mgsn>	String of GSM modifiers: I Activates CLIR (Disable presentation of own number to called party) i Deactivates CLIR (Enable presentation of own number to called party) G Activates closed user group invocation for this call only g Deactivates closed user group invocation for this call only
<;>	It is required when setting up voice call, and will return to command state after the call.

NOTE

1. This command may be aborted generally by receiving an **ATH** command or a character during execution. The aborting is not possible during some states of connection establishment such as handshaking.
2. Parameters **I** and **i** can be omitted only when there is no ***** or **#** code within the dial string.
3. See **ATX** command for setting result code and call monitoring parameters.
4. Responses returned after dialing with **ATD**:
For voice calls, two different response modes can be determined. TA returns **OK** immediately either after dialing was completed or after the call was established
5. Using **ATD** during an active voice call:
 - When a user originates a second voice call while there is already an active voice call, the first call will be automatically put on hold.
 - The current states of all calls can be easily checked at any time with **AT+CLCC**.

Example

```
ATD10086;           //Dialing out the party's number
OK
```

7.2. ATH Disconnect Existing Connection

This command disconnects circuit switched data calls or voice calls. **AT+CHUP** is also used to disconnect voice calls.

ATH Disconnect Existing Connection	
Execution Command ATH[n]	Response OK
Maximum Response Time	90 s, determined by the network.
Characteristics	-
Reference V.25ter	

Parameter

<n>	Integer type.
0	Disconnect existing call from command line and terminate the call.

7.3. AT+CVHU Voice Hang up Control

This command controls whether **ATH** can be used to disconnect the voice call.

AT+CVHU Voice Hang up Control	
Test Command AT+CVHU=?	Response +CVHU: (list of supported <mode>s) OK
Read Command AT+CVHU?	Response +CVHU: <mode> OK
Write Command AT+CVHU=<mode>	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Reference
3GPP TS 27.007

Parameter

<mode>	Integer type.
0	ATH can be used to disconnect the voice call
<u>1</u>	ATH is ignored with the response OK returned only

7.4. AT+CHUP Hang up a Call

This command cancels all voice calls in the state of Active, Waiting and Held. For data connections, please use **ATH**.

AT+CHUP Hang up a Call	
Test Command AT+CHUP=?	Response OK
Execution Command AT+CHUP	Response OK If there is any other error: ERROR
Maximum Response Time	90 s, determined by the network.
Characteristics	-
Reference 3GPP 27.007	

Example

```

RING                //A call is incoming
AT+CHUP             //Hang up the call
OK

```

7.5. +++ Switch from Data Mode to Command Mode

The +++ character sequence causes the TA to cancel the data flow over the AT interface and switch to command mode. It allows inputting AT commands while maintaining the data connection with the remote device.

This command is only available when TA is in data mode.

+++ Switch from Data Mode to Command Mode

Execution Command +++	Response OK
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

NOTE

- To prevent the +++ escape sequence from being misinterpreted as data, the following sequence should be followed:
 - Do not input any character within 1 s before inputting +++.
 - Input +++ within 1 s, and no other characters can be inputted during the time.
 - Do not input any character within 1 s after +++ has been inputted.
 - Switch to command mode; otherwise return to step 1).
- To return back to data mode from command mode, please enter **ATO0**.
- Another way to switch to command mode is through DTR level change, and see **AT&D** for details.

7.6. ATO Switch from Command Mode to Data Mode

This command resumes the connection and switches back to data mode from command mode.

ATO Switch from Command Mode to Data Mode

Execution Command ATO[n]	Response If connection is not successfully resumed: NO CARRIER If connection is successfully resumed, TA returns to data mode from command mode: CONNECT <text>
Maximum Response Time	300 ms
Characteristics	-
Reference V.25ter	

Parameter

<n>	Integer type.
0	Switch from command mode to data mode

NOTE

When TA returns to data mode from command mode successfully, **CONNECT <text>** is returned. Note that <text> outputs only when <value> is greater than 0 in **ATX<value>** parameter setting.

7.7. AT50 Set Number of Rings before Automatic Answering

This command controls automatic answering mode for the incoming calls.

AT50 Set Number of Rings before Automatic Answering

Read Command AT50?	Response <n> OK
Write Command AT50=<n>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W .
Reference V.25ter	

Parameter

<n>	Integer type. This parameter determines the number of rings before automatic answering.
0	Automatic answering is disabled
1-255	Enable automatic answering on the ring number specified

NOTE

If <n> is set too high, the calling party may hang up before the call is answered automatically.

Example

```

ATS0=3           //Set three rings before automatically answering a call
OK

RING             //A call is incoming

RING

RING             //Automatically answer the call after three rings
    
```

7.8. ATS6 Set Pause before Blind Dialing

This command is implemented for compatibility reasons only, and has no effect.

ATS6 Set Pause before Blind Dialing	
Read Command ATS6?	Response <n> OK
Write Command ATS6=<n>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference V.25ter	

Parameter

<n>	Integer type. Number of seconds to wait before blind dialing. Range: 0–10. Default value: 2. Unit: second.
------------------	---

7.9. ATS7 Set the Time to Wait for Connection Completion

This command specifies the amount of time (unit: second) to wait for the connection completion in case of answering or originating a call. If no connection is established during the time, the module will be disconnected from the line.

ATS7 Set the Time to Wait for Connection Completion

Read Command ATS7?	Response <n> OK
Write Command ATS7=<n>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W .
Reference V.25ter	

Parameter

<n>	Integer type. This parameter determines the amount of time (unit: second) to wait for the connection completion in case of answering or originating a call.
0	Disabled
1-255	Number of seconds to wait for connection completion

7.10. ATS8 Set the Time to Wait for Comma Dial Modifier

This command is implemented for compatibility reasons only, and has no effect.

ATS8 Set the Time to Wait for Comma Dial Modifier

Read Command ATS8?	Response <n> OK
Write Command ATS8=<n>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference V.25ter	

Parameter

<n>	Integer type.
0	No pause when comma encountered in dial string
1-2-255	Number of seconds to wait for comma dial modifier

7.11. ATS10 Set Disconnection Delay after Indicating the Absence of Data Carrier

This command determines the amount of time (unit: tenths of a second) during which the UE remains connected in absence of a data carrier.

ATS10 Set Disconnection Delay after Indicating the Absence of Data Carrier

Read Command ATS10?	Response <n> OK
Write Command ATS10=<n>	Response OK
Maximum Response Time	300ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W.
Reference V.25ter	

Parameter

<n>	Integer type. This parameter determines the amount of time (unit: tenths of a second) during which the TA will remain connected in absence of a data carrier. If the data carrier is once more detected before disconnection, the TA remains connected. Default value: 15.
1-254	Number of tenths of a second to wait before disconnecting after UE has indicated the absence of received line signal

7.12. AT+CRING Set Cellular Result Codes for Incoming Call Indication

This command controls whether or not to use the extended format of incoming call indication. When enabled, an incoming call is indicated to the TE with unsolicited result code **+CRING: <type>** instead of the normal **RING**.

AT+CRC Set Cellular Result Codes for Incoming Call Indication

Test Command AT+CRC=?	Response +CRC: (list of supported <mode>s) OK
Read Command AT+CRC?	Response +CRC: <mode> OK
Write Command AT+CRC=<mode>	Response OK
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<mode>	Integer type. Disables or enables the extended format of incoming call URC +CRING: <type>	
	0	Disable
	1	Enable
<type>	String type.	
	ASYN	Asynchronous transparent
	SYNC	Synchronous transparent
	REL ASYN	Asynchronous non-transparent
	REL SYNC	Synchronous non-transparent
	FAX	Facsimile
	VOICE	Voice

Example

```

AT+CRC=1                                     //Enable extended format
OK

+CRING: VOICE                                //Indicate incoming call to the TE
ATH
OK
AT+CRC=0                                     //Disable extended format
OK

```

RING	//Indicate incoming call to the TE
ATH	
OK	

8 Short Message Service Commands

8.1. AT+CSMS Select Message Service

This command selects message service and returns the types of messages supported by the MT.

AT+CSMS Select Message Service	
Test Command AT+CSMS=?	Response +CSMS: (list of supported <service>s) OK
Read Command AT+CSMS?	Response +CSMS: <service>,<mt>,<mo>,<bm> OK
Write Command AT+CSMS=<service>	Response +CSMS: <mt>,<mo>,<bm> OK If there is an error related to ME functionality: +CMS ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference <i>3GPP TS 27.005</i>	

Parameter

<service>	Integer type. Type of message service. <u>0</u> <i>3GPP TS 23.040 and 3GPP TS 23.041</i> (the syntax of SMS AT commands is compatible with <i>3GPP TS 27.005 Phase 2 version 4.7.0</i> ; Phase 2+ features
------------------------	---

		which do not require new command syntax may be supported, e.g. correct routing of messages with new Phase 2+ data coding schemes).
	1	3GPP TS 23.040 and 3GPP TS 23.041 (the syntax of SMS AT commands is compatible with 3GPP TS 27.005 Phase 2+ version; the requirement of <service> setting 1 is mentioned under corresponding command descriptions).
<mt>	Integer type. Mobile terminated messages.	
	0	Type not supported
	<u>1</u>	Type supported
<mo>	Integer type. Mobile originated messages.	
	0	Type not supported
	<u>1</u>	Type supported
<bm>	Integer type. Broadcast type messages.	
	0	Type not supported
	<u>1</u>	Type supported
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values.	

Example

```

AT+CSMS=?           //Query the type of message services supported by the module
+CSMS: (0,1)

OK
AT+CSMS=1           //Set the type of message service to 1.
+CSMS: 1,1,1

OK
AT+CSMS?           //Read the current setting.
+CSMS: 1,1,1,1

OK

```

8.2. AT+CMGF Message Format

This command specifies the input and output formats of short messages. **<mode>** indicates the format of messages used with send, list, read and write commands and unsolicited result codes resulting from received messages.

The format of messages can be either PDU mode (entire TP data units used) or text mode (headers and body of the messages given as separate parameters). Text mode uses the value of **<chset>** specified by **AT+CSCS** to inform the character set to be used in the message body in the TA-TE interface.

AT+CMGF Message Format

Test Command AT+CMGF=?	Response +CMGF: (list of supported <mode> s) OK
Read Command AT+CMGF?	Response +CMGF: <mode> OK
Write Command AT+CMGF[=<mode>]	Response OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference 3GPP TS 27.005	

Parameter

<mode>	Integer type.
<u>0</u>	PDU mode
1	Text mode

8.3. AT+CSCA Service Center Address

The Write Command updates the SMSC address when mobile originated SMS are transmitted. In text mode, the setting is used by Write Command. In PDU mode, setting is used by the same command, but only when the length of the SMSC address is coded into the **<pdu>** parameter which equals to zero.

AT+CSCA Service Center Address

Test Command AT+CSCA=?	Response OK
Read Command	Response

AT+CSCA?	+CSCA: <sca>,<tosca> OK
Write Command AT+CSCA=<sca>[,<tosca>]	Response OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference 3GPP TS 27.005	

Parameter

<sca>	Service center address. 3GPP TS 24.011 RP SC address Address-Value field in string format. BCD numbers (or GSM 7 bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to AT+CSCS in 3GPP TS 27.007); type of address is given by <tosca>.
<tosca>	Type of service center address. 3GPP TS 24.011 RP SC address Type-of-Address octet in integer format (default refer to <toda>).
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

Example

```

AT+CSCA="+8613800210500",145           //Set SMSC address
OK
AT+CSCA?                                //Query SMSC address
+CSCA: "+8613800210500",145
OK

```

8.4. AT+CPMS Preferred Message Storage

This command selects the memory storages <mem1>, <mem2> and <mem3> to be used for reading, writing, etc.

AT+CPMS Preferred Message Storage	
Test Command AT+CPMS=?	Response +CPMS: (list of supported <mem1>s),(list of supported <mem2>s),(list of supported <mem3>s) OK
Read Command AT+CPMS?	Response +CPMS: <mem1>,<used1>,<total1>,<mem2>,<used2>,<total2>,<mem3>,<used3>,<total3> OK
Write Command AT+CPMS=<mem1>[,<mem2>[,<mem3>]]	Response +CPMS: <used1>,<total1>,<used2>,<total2>,<used3>,<total3> OK If there is an error related to ME functionality: +CMS ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference 3GPP TS 27.005	

Parameter

<mem1>	String Type. Messages to be read and deleted from this memory storage.
	"SM" (U)SIM message storage
	"ME" Mobile equipment message storage
	"MT" The same as "ME" storage
<mem2>	String Type. Messages will be written and sent to this memory storage.
	"SM" (U)SIM message storage
	"ME" Mobile equipment message storage
	"MT" Same as "ME" storage
<mem3>	String Type. Received messages will be placed in this memory storage if routing to PC is not set (AT+CNMI).
	"SR" Status report storage

"SM"	(U)SIM message storage
"ME"	Mobile equipment message storage
"MT"	Same as "ME" storage
"SR"	Status report storage
<usedx>	Integer type. Number of current messages in <memx>.
<totalx>	Integer type. Total number of messages which can be stored in <memx>.
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values.

Example

```

AT+CPMS?                                     //Query the current SMS message storage
+CPMS: "ME",0,23,"ME",0,23,"ME",0,23

OK
AT+CPMS="SM","SM","SM"                       //Set SMS message storage as "SM"
+CPMS: 0,50,0,50,0,50

OK
AT+CPMS?                                     //Query the current SMS message storage
+CPMS: "SM",0,50,"SM",0,50,"SM",0,50

OK

```

8.5. AT+CMGD Delete Messages

This command deletes short messages from the preferred message storage <mem1> location <index>. If <delflag> is presented and not set to 0, the ME shall ignore <index> and follow the rules of <delflag> shown as below.

AT+CMGD Delete Messages	
Test Command AT+CMGD=?	Response +CMGD: (list of supported <index>s),(list of supported <delflag>s) OK
Write Command AT+CMGD=<index>[,<delflag>]	Response OK If there is an error related to ME functionality: +CMS ERROR:<err> If there is any other error:

	ERROR
Maximum Response Time	300ms. Note: Operation of <delflag> depends on the storage of deleted messages.
Characteristics	-
Reference	
3GPP TS 27.005	

Parameter

<index>	Integer type value in the range of location numbers supported by the associated memory.
<delflag>	Integer type. Delete flag.
0	Delete the message specified in <index>
1	Delete all read messages from <mem1> storage
2	Delete all read messages from <mem1> storage and sent mobile originated messages
3	Delete all read messages from <mem1> storage, sent and unsent mobile originated messages
4	Delete all messages from <mem1> storage
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values.

Example

```

AT+CMGD=1 //Delete the message specified in <index>=1
OK
AT+CMGD=1,4 //Delete all messages from <mem1> storage
OK

```

8.6. AT+CMGL List Messages

The Write Command returns messages with status value **<stat>** from preferred message storage **<mem1>** to the TE. If the status of the message is "REC UNREAD", the status in the storage changes to "REC READ". When executing **AT+CMGL** without status value **<stat>**, it will report the list of SMS with "REC UNREAD" status.

AT+CMGL List Messages

Test Command	Response
AT+CMGL=?	+CMGL: (list of supported <stat> s)
	OK

Write Command
AT+CMGL[=<stat>]

Response

If in text mode (**AT+CMGF=1**) and the command is executed successfully:

For SMS-SUBMITs and/or SMS-DELIVERs:

+CMGL: <index>,<stat>,<oa/da>,<[alpha]>,<[scts]>,<[to a/toda>,<length><CR><LF><data>
[+CMGL: <index>,<stat>,<da/oa>,<[alpha]>,<[scts]>,<[to oa/toda>,<length><CR><LF><data>
[...]]

OK

For SMS-STATUS-REPORTs:

+CMGL: <index>,<stat>,<fo>,<mr>,<[ra]>,<[tora]>,<sct s>,<dt>,<st>
[+CMGL: <index>,<stat>,<fo>,<mr>,<[ra]>,<[tora]>,<sct s>,<dt>,<st>
[...]]

OK

For SMS-COMMANDs:

+CMGL: <index>,<stat>,<fo>,<ct>
[+CMGL: <index>,<stat>,<fo>,<ct>
[...]]

OK

For CBM storage:

+CMGL:<index>,<stat>,<sn>,<mid>,<page>,<pages><C R><LF><data>
[+CMGL: <index>,<stat>,<sn>,<mid>,<page>,<pages><C R><LF><data>
[...]]

OK

If in PDU mode (**AT+CMGF=0**) and the command is executed successfully:

+CMGL: <index>,<stat>,<[alpha]>,<length><CR><LF><p du>
[+CMGL: <index>,<stat>,<[alpha]>,<length><CR><LF><p du>
[...]]

	OK If there is an error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	300 ms. Note: Operation of <stat> depends on the storage of listed messages.
Characteristics	-
Reference	
3GPP TS 27.005	

Parameter

<stat>	Integer type in PDU mode, or string type in text mode. The status of message in memory; Defined values:		
	PDU mode	Text mode	Explanation
	<u>0</u>	<u>"REC UNREAD"</u>	Received unread messages
	1	"REC READ"	Received read messages
	2	"STO UNSENT"	Stored unsent messages
	3	"STO SENT"	Stored sent messages
	4	"ALL"	All messages
<index>	Integer type. In the range of location numbers supported by the associated memory.		
<da>	Destination Address. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to AT+CSCS in 3GPP TS 27.007). Type of address is given by <toda> .		
<oa>	Originating address. 3GPP TS 23.040 TP-Originating-Address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to AT+CSCS in 3GPP TS 27.007). The type of address is given by <tooa> .		
<alpha>	String type alphanumeric representation of <da> or <oa> corresponding to the entry found in MT phonebook. Implementation of this feature is manufacturer specified. The used character set should be the one selected with AT+CSCS command (see definition of this command in 3GPP TS 27.007).		
<scts>	Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (refer to <dt>).		
<toda>	Type of destination address. 3GPP TS 24.011 TP-Destination-Address Type-of-Address octet in integer format.		
<tooa>	Type of originating address. 3GPP TS 24.011 TP-Originating-Address Type-of-Address octet in integer format (default refer to <toda>).		
<length>	Integer type. Message length. In the text mode (AT+CMGF=1) the length of the message body <data> ; or in PDU mode (AT+CMGF=0) the length of the actual TP		

	data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<data>	In the case of SMS: 3GPP TS 23.040 TP-User-Data in text mode responses; format: - If <dc>, indicates that 3GPP TS 23.038 GSM 7-bit default alphabet is used and <fo> indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set. - If TE character set other than "HEX" (refer to AT+CSCS command in 3GPP TS 27.007): ME/TA converts GSM alphabet into current TE character set according to rules of in 3GPP TS 27.007 Annex A. - If TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7-bit default alphabet into two IRA character long hexadecimal number (e.g. character Π (GSM 7-bit default alphabet 23) is presented as 17 (IRA 49 and 55)). - If <dc>, indicates that 8-bit or UCS2 data coding scheme is used, or <fo> indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: 3GPP TS 23.041 CBM Content of Message in text mode responses; format: - If <dc>, indicates that 3GPP TS 23.038 GSM 7-bit default alphabet is used. - If TE character set other than "HEX" (refer to AT+CSCS in 3GPP TS 27.007): ME/TA converts GSM alphabet into current TE character set according to rules of 3GPP TS 27.007 Annex A. - If TE character set is "HEX": ME/TA converts each 7-bit character of the GSM 7-bit default alphabet into two IRA character long hexadecimal number. - If <dc>, indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number.
<pdu>	In the case of SMS: 3GPP TS 24.011 SC address followed by 3GPP TS 23.040 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).
<fo>	Depending on the command or result code: First octet of 3GPP TS 23.040 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, SMS-COMMAND in integer format. If a valid value has been entered once, the parameter can be omitted.
<mr>	3GPP TS 23.040 TP-Message-Reference in integer format.
<ra>	3GPP TS 23.040 TP-Recipient-Address Address-Value field in string format. BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (refer to AT+CSCS).
<tora>	The type of address is given by <tora> . 3GPP TS 24.011 TP-Recipient-Address Type-of-Address octet in integer format (default refer to <toda>).
<scts>	Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (refer to <dt>).
<dt>	3GPP TS 23.040 [3] TP-Discharge-Time in time-string format:

	"yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. E.g. 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08".
<st>	3GPP TS 23.040 [3] TP-Status in integer format.
<ct>	3GPP TS 23.040 [3] TP-Command-Type in integer format (default 0).
<sn>	3GPP TS 23.041 [4] CBM Serial Number in integer format.
<mid>	3GPP TS 23.041 [4] CBM Message Identifier in integer format.
<page>	3GPP TS 23.041 [4] CBM Page Parameter bits 4–7 in integer format.
<pages>	3GPP TS 23.041 [4] CBM Page Parameter bits 0–3 in integer format.
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values.

Example

```

AT+CMGF=1                                //Set SMS message format as text mode
OK
AT+CMGL="ALL"                             //List all messages from message storage
+CMGL: 1,"STO UNSENT","",,
<This is a test from Quectel>
+CMGL: 2,"STO UNSENT","",,
<This is a test from Quectel>
OK

```

8.7. AT+CMGR Read Messages

The Write Command returns SMS messages with location value <index> from message storage <mem1> to the TE. If status of the message is "REC UNREAD", status in the storage changes to "REC READ".

AT+CMGR Read Messages	
Test Command AT+CMGR=?	Response OK
Write Command AT+CMGR=<index>	Response If in text mode (AT+CMGF=1) and the command is executed successfully: For SMS-DELIVER: +CMGR: <stat>,<oa>,<[alpha]>,<scts>,<[tooa>,<fo>,<pi d>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data> OK For SMS-SUBMIT:

	+CMGR: <stat>,<da>,[<alpha>][,<toda>,<fo>,<pid>,<dc s>,<vp>],<sca>,<tosca>,<length>]<CR><LF><data> OK For SMS-STATUS-REPORTs: +CMGR: <stat>,<fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<s t> OK For SMS-COMMANDs: +CMGR: <stat>,<fo>,<ct>,<pid>,<mn>,<da>,<toda>,<length>]<CR><LF><cdata>] OK For CBM storage: +CMGR: <stat>,<sn>,<mid>,<dc s>,<page>,<pages>]<CR><LF><data> OK If in PDU mode (AT+CMGF=0) and the command is executed successfully: +CMGR: <stat>,<alpha>,<length>]<CR><LF><pdu> OK If there is an error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	Depends on the length of message content.
Characteristics	-
Reference	3GPP TS 27.005

Parameter

<index>	Integer type. In the range of location numbers supported by the associated memory.		
<stat>	Integer type in PDU mode, or string type in text mode. The status of message in memory; Defined values:		
	PDU mode	Text mode	Explanation

	0	"REC UNREAD"	Received unread messages
	1	"REC READ"	Received read messages
	2	"STO UNSENT"	Stored unsent messages
	3	"STO SENT"	Stored sent messages
	4	"ALL"	All messages
<alpha>	String type alphanumeric representation of <da> or <oa> corresponding to the entry found in MT phonebook. Implementation of this feature is manufacturer specified. The used character set should be the one selected with AT+CSCS command (see definition of this command in <i>3GPP TS 27.007</i>).		
<da>	Destination address. <i>3GPP TS 23.040</i> TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to AT+CSCS command in <i>3GPP TS 27.007</i>). The type of address is given by <toda>.		
<oa>	Originating address. <i>3GPP TS 23.040</i> TP-Originating-Address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to AT+CSCS command in <i>3GPP TS 27.007</i>). The type of address is given by <toa>.		
<scts>	Service center time stamp. <i>3GPP TS 23.040</i> TP-Service-Centre-Time-Stamp in time-string format (refer to <dt>).		
<fo>	First octet. Depending on the command or result code: First octet of <i>3GPP TS 23.040</i> SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND in integer format. If a valid value has been entered once, the parameter can be omitted.		
<pid>	Protocol identifier. <i>3GPP TS 23.040</i> TP-Protocol-Identifier in integer format (default 0).		
<dc>	Data coding scheme. Depending on the command or result code: <i>3GPP TS 23.038</i> SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme in integer format.		
<vp>	Validity period. Depending on SMS-SUBMIT <fo> setting: <i>3GPP TS 23.040</i> TP-Validity-Period either in integer format or in time-string format (refer to <dt>).		
<mn>	Message number. <i>3GPP TS 23.040</i> TP-Message-Number in integer format.		
<mr>	Message reference. <i>3GPP TS 23.040</i> TP-Message-Reference in integer format.		
<ra>	Recipient address. <i>3GPP TS 23.040</i> TP-Recipient-Address Address-Value field in string format. BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (refer to AT+CSCS command). The type of address is given by <tora>.		
<tora>	Type of recipient address. <i>3GPP TS 24.011</i> TP-Recipient-Address Type-of-Address octet in integer format (default refer to <toda>).		
<toda>	Type of destination address. <i>3GPP TS 24.011</i> TP-Destination-Address Type-of-Address octet in integer format.		
<toa>	Type of originating address. <i>3GPP TS 24.011</i> TP-Originating-Address Type-of-Address octet in integer format (default refer to <toda>).		
<sca>	Service center address. <i>3GPP TS 24.011</i> RP SC address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to		

	characters of the currently selected TE character set (refer to AT+CSCS command in <i>3GPP TS 27.007</i>). The type of address is given by <tosca> .
<tosca>	Type of service center address. <i>3GPP TS 24.011</i> RP SC address Type-of-Address octet in integer format (default refer to <toda>).
<length>	Integer type. Message length. In the text mode (AT+CMGF=1) the length of the message body <data> (or <cdata>) in characters; or in PDU mode (AT+CMGF=0) the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<data>	In the case of SMS: <i>3GPP TS 23.040</i> TP-User-Data in text mode responses; format: - If <dcsc>, indicates that <i>3GPP TS 23.038</i> GSM 7-bit default alphabet is used and <fo> indicates that <i>3GPP TS 23.040</i> TP-User-Data-Header-Indication is not set. - If TE character set other than "HEX" (refer to AT+CSCS command in <i>3GPP TS 27.007</i>): ME/TA converts GSM alphabet into current TE character set according to rules of in <i>3GPP TS 27.007 Annex A</i>. - If TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7-bit default alphabet into two IRA character long hexadecimal number (e.g. character II (GSM 7 bit default alphabet 23) is presented as 17 (IRA 49 and 55)). - If <dcsc>, indicates that 8-bit or UCS2 data coding scheme is used, or <fo> indicates that <i>3GPP TS 23.040</i> TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: <i>3GPP TS 23.041</i> CBM Content of Message in text mode responses; format: - If <dcsc>, indicates that <i>3GPP TS 23.038</i> GSM 7-bit default alphabet is used. - If TE character set other than "HEX" (refer to AT+CSCS in <i>3GPP TS 27.007</i>): ME/TA converts GSM alphabet into current TE character set according to rules of <i>3GPP TS 27.007 Annex A</i>. - If TE character set is "HEX": ME/TA converts each 7-bit character of the GSM 7-bit default alphabet into two IRA character long hexadecimal number. - If <dcsc>, indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number.
<pdu>	In the case of SMS: <i>3GPP TS 24.011</i> SC address followed by <i>3GPP TS 23.040</i> TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).
<dt>	<i>3GPP TS 23.040 [3]</i> TP-Discharge-Time in time-string format: "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. E.g. 6th of May 1994, 22:10:00 GMT+2 hours equals to "94/05/06,22:10:00+08".
<st>	<i>3GPP TS 23.040 [3]</i> TP-Status in integer format.
<ct>	<i>3GPP TS 23.040 [3]</i> TP-Command-Type in integer format (default 0).
<cdata>	<i>3GPP TS 23.040 [3]</i> TP-Command-Data in text mode responses; ME/TA converts each 8-bit octet into two IRA character long hexadecimal number (e.g. octet with integer

	value 42 is presented to TE as two characters 2A (IRA 50 and 65))
<sn>	3GPP TS 23.041 [4] CBM Serial Number in integer format
<mid>	3GPP TS 23.041 [4] CBM Message Identifier in integer format
<page>	3GPP TS 23.041 [4] CBM Page Parameter bits 4-7 in integer format
<pages>	3GPP TS 23.041 [4] CBM Page Parameter bits 0-3 in integer format
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values.

Example

```
+CMTI: "SM",3 //Indicate that a new message has been received and
                saved to <index>=3 of "SM"

AT+CSDH=1
OK
AT+CMGR=3 //Read the message
+CMGR: "REC UNREAD","+8615021012496",,"13/12/13,15:06:37+32",145,4,0,0,"+861380021050
0",145,27

<This is a test from Quectel>

OK
```

8.8. AT+CMGS Send Messages

This Write Command sends a short message from TE to network (SMS-SUBMIT). The message reference <mr> is returned to the TE on successful message delivery. Optionally (when **AT+CSMS** <service> value is 1 and network supports) <scts> is returned. The values can be used to identify message upon unsolicited delivery status report result code.

AT+CMGS Send Messages	
Test Command AT+CMGS=?	Response OK
Write Command If in text mode (AT+CMGF=1): AT+CMGS=<da>[,<toda>] After > is repoded, input the text message. After that, tap ctrl-Z to send the message. Sending can be cancelled by tapping ESC , and the abortion is acknowledged with OK , though the message will not be sent.	Response If the message is sent successfully: +CMGS: <mr>[,<scts>] OK If there is an error related to ME functionality: +CMS ERROR: <err>
Write Command If in PDU mode (AT+CMGF=0):	Response If the message is sent successfully:

AT+CMGS=<length> After > is repoded, input the PDU. After that, tap ctrl-Z to indicate the ending of PDU and begin to send the message. Sending can be cancelled by tapping ESC , and the abortion is acknowledged with OK , though the message will not be sent.	+CMGS: <mr>[,<scts>] OK If there is an error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	240 s, determined by the network.
Characteristics	-
Reference	
3GPP TS 27.005	

Parameter

<da>	Destination address. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to command AT+CSCS in 3GPP TS 27.007). The type of address is given by <toda> .
<toda>	Type of destination address. 3GPP TS 24.011 TP-Destination-Address Type-of-Address octet in integer format.
<length>	Integer type. Message length. In the text mode (AT+CMGF=1) the length of the text message in characters; or in PDU mode (AT+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<mr>	Message reference. 3GPP TS 23.040 TP-Message-Reference in integer format.
<scts>	Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (refer to <dt> in AT+CMGL).
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values. Refer to AT+CMGR for Other parameters.

Example

```

AT+CMGF=1                                //Set SMS message format as text mode
OK
AT+CSCS="GSM"                            //Set character set as GSM which is used by the TE
OK
AT+CMGS="15021012496"

> <This is a test from Quectel>           //Enter in text. Tap ctrl-Z to send message, or ESC to
                                           quit without sending.

+CMGS: 247

```

OK

8.9. AT+CMMS Send More Messages

This command controls the continuity of SMS relay protocol link. When the feature is enabled (and supported by the network) multiple messages can be sent much faster as the link is kept open.

AT+CMMS Send More Messages

Test Command AT+CMMS=?	Response +CMMS: (list of supported<n>s) OK
Read Command AT+CMMS?	Response +CMMS: <n> OK
Write Command AT+CMMS=<n>	Response OK If there is an error related to ME functionality: +CMS ERROR: <err> If there is any other error: ERROR
Maximum Response Time	120 s, determined by the network.
Characteristics	-
Reference 3GPP TS 27.005	

Parameter

<n>	Integer type
0	Feature disabled
1	Keep enabled until the time between the response of the latest message sending command (AT+CMGS , AT+CMSS , etc.) and the next sending command exceeds 1-5 s (the exact value is up to ME implementation); then ME shall close the link and TA switches <n> back to 0 automatically.
2	Feature enabled. If the time between the response of the latest message sending command and the next sending command exceeds 1-5 s (the exact value is up to ME implementation), the ME shall close the link but TA will not switch <n> back to 0

automatically.

<err> Integer type. Error code. Refer to **Table 22** for possible **<err>** values.

NOTE

After the execution of Read Command, a delay of 5-10 s is required before issuing the Write Command. Otherwise **+CMS ERROR: 500** may appear.

8.10. AT+CMGW Write Messages to Memory

This command stores short messages (either SMS-DELIVER or SMS-SUBMIT) to memory storage **<mem2>** (refer to **AT+CPMS** for details), and then the memory location **<index>** of the stored message is returned. The message status will be set to 'stored unsent' by default, but the parameter **<stat>** also allows other status values to be given.

The entering of text is done similarly as specified in **AT+CMGS** Write Command.

AT+CMGW Write Messages to Memory

Test Command	Response
AT+CMGW=?	OK
Write Command 1) If in text mode (AT+CMGF=1): AT+CMGW=[<oa/da>[,<tooa/toda>[,<stat>]]] After > is reponded, input the text message. After that, tap ctrl-Z to transmit the message to memory storage <mem2>. Transmitting can be cancelled by tapping ESC, and the abortion is acknowledged with OK, though the message will not be transmitted. 2) If in PDU mode (AT+CMGF=0): AT+CMGW=<length>[,<stat>] After > is reponded, input the PDU. After that, tap ctrl-Z to indicate the ending of PDU and begin to transmit the message to memory storage <mem2>. Transmitting can be cancelled by tapping ESC, and the abortion is acknowledged with OK, though the	Response If message writing is successful: +CMGW: <index> OK If there is an error related to ME functionality: +CMS ERROR: <err>

message will not be transmitted.	
Maximum Response Time	300 ms
Characteristics	-
Reference	
3GPP TS 27.005	

Parameter

<da>	Destination address. <i>3GPP TS 23.040</i> TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to AT+CSCS command in <i>3GPP TS 27.007</i>). The type of address is given by <toda> .		
<oa>	Originating address. <i>3GPP TS 23.040</i> TP-Originating-Address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to AT+CSCS command in <i>3GPP TS 27.007</i>). The type of address is given by <tooa> .		
<tooa>	Type of originating address. <i>3GPP TS 24.011</i> TP-Originating-Address Type-of-Address octet in integer format (default refer to <toda>).		
<stat>	Integer type in PDU mode, or string type in text mode. The status of message in memory; Defined values:		
	PDU mode	Text mode	Explanation
	0	<u>"REC UNREAD"</u>	Received unread messages
	1	"REC READ"	Received read messages
	2	"STO UNSENT"	Stored unsent messages
	3	"STO SENT"	Stored sent messages
	4	"ALL"	All messages
<toda>	Type of destination address. <i>3GPP TS 24.011</i> TP-Destination-Address Type-of-Address octet in integer format.		
<length>	Integer type. Message length. In the text mode (AT+CMGF=1) the length of the text message in characters; or in PDU mode (AT+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).		
<pdu>	In the case of SMS: <i>3GPP TS 24.011</i> SC address followed by <i>3GPP TS 23.04</i> TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).		
<index>	Integer type. Index of message in selected storage <mem2> .		
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values.		

Example

```
AT+CMGF=1 //Set SMS message format to text mode
OK
```

```

AT+CSCS="GSM" //Set character set as GSM which is used by the TE
OK
AT+CMGW="15021012496"
> <This is a test from Quectel> //Enter in text. Tap ctrl-Z to transmit the message to
                                memory storage <mem2>.
+CMGW: 4

OK
AT+CMGF=0 //Set SMS message format as PDU mode
OK
AT+CMGW=18
> 0051FF00000008000A0500030002016D4B8BD5
+CMGW: 5

OK

```

8.11. AT+CMSS Send Messages from Storage

This command sends messages with location value **<index>** from message storage **<mem2>** to the network (SMS-SUBMIT or SMS-COMMAND). If a new destination address **<da>** is given for SMS-SUBMIT, it shall be used instead of the one stored with the message. Reference value **<mr>** is returned to the TE on successful message delivery. Values can be used to identify message upon unsolicited delivery status report result code.

AT+CMSS Send Messages from Storage

Test Command	Response
AT+CMSS=?	OK
Write Command	Response
AT+CMSS=<index>[,<da>[,<toda>]]	If in text mode (AT+CMGF=1) and the message is sent successfully: +CMSS: <mr>[,<scts>] OK If in PDU mode (AT+CMGF=0) and the message is sent successfully: +CMSS: <mr> [,<ackpdu>] OK If there is an error related to ME functionality: +CMS ERROR: <err>

Maximum Response Time	120 s, determined by the network.
Characteristics	-
Reference 3GPP TS 27.005	

Parameter

<index>	Integer type. In the range of location numbers supported by the associated memory.
<da>	Destination Address. 3GPP TS 23.040 TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to AT+CSCS command in 3GPP TS 27.007). The type of address is given by <toda>.
<toda>	Type of destination address. 3GPP TS 24.011 TP-Destination-Address Type-of-Address octet in integer format.
<mr>	Message reference. 3GPP TS 23.040 TP-Message-Reference in integer format.
<scts>	Service center time stamp. 3GPP TS 23.040 TP-Service-Centre-Time-Stamp in time-string format (refer to <dt>).
<ackpdu>	The format is same as <pdu> in case of SMS, but without 3GPP TS 24.011 SC address field and parameter shall be bounded by double quote characters like a normal string type parameter.
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values.

Example

```

AT+CMGF=1                                //Set SMS message format to text mode
OK
AT+CSCS="GSM"                             //Set character set to GSM which is used by the TE
OK
AT+CMGW="15021012496"
> Hello                                    //Enter in text. Tap ctrl-Z to send message.
+CMGW: 4

OK
AT+CMSS=4                                  //Send the message of index 4 from memory storage.
+CMSS: 54

OK

```


8.12. AT+CNMA New Message Acknowledgement to UE/TE

The Write and Execution Commands confirm successful receipt of a new message (SMS-DELIVER or SMS-STATUS-REPORT) routed directly to the TE. If the UE does not receive acknowledgement within required time (network timeout), it sends an **RP-ERROR** message to the network. The UE will automatically disable routing to the TE by setting both **<mt>** and **<ds>** values of **AT+CNMI** to 0.

AT+CNMA New Message Acknowledgement to UE/TE	
Test Command AT+CNMA=?	Response +CNMA: (list of supported <n>s) OK
Execution Command AT+CNMA	Response OK If there is an error related to ME functionality: +CMS ERROR: <err> If there is any other error: ERROR
Write Command AT+CNMA=<n>	Response OK If there is an error related to ME functionality: +CMS ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.005	

Parameter

<n>	Integer type. Parameter required only for PDU mode
0	Command operates similarly as in text mode
1	Send positive (RP-ACK) acknowledgement to the network. Accepted only in PDU mode.
2	Send negative (RP-ERROR) acknowledgement to the network. Accepted only in PDU mode.
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values.

NOTE

The Execution and Write Commands shall only be used when **AT+CSMS** parameter **<service>** equals to 1 (phase 2+) and an appropriate URC has been issued by the module, i.e.:

+CMT for **<mt>**=2 incoming message classes 0, 1, 3 and none;

+CMT for **<mt>**=3 incoming message classes 0 and 3;

+CDS for **<ds>**=1.

Example

```
AT+CSMS=1
+CSMS:1,1,1

OK
AT+CNMI=1,2,0,0,0
OK

+CMT: "+8615021012496",,"13/03/18,17:07:21+32",145,4,0,0,"+8613800551500",145,28
This is a test from Quectel.           //A short message is outputted directly when SMS is incoming.
AT+CNMA                               //Send ACK to the network
OK
AT+CNMA
+CMS ERROR: 340                       //The second time return error. It needs ACK only once.
```

8.13. AT+CNMI New Message Indications to TE

This command selects the procedure on how receiving of new messages from the network is indicated to the TE when TE is active, e.g. DTR is at low level (ON). If TE is inactive (e.g. DTR is at high level (OFF)), message receiving should be done as specified in *3GPP TS 23.038 [2]*.

AT+CNMI New Message Indications to TE

Test Command AT+CNMI=?	Response +CNMI: (list of supported <mode> s),(list of supported <mt> s),(list of supported <bm> s),(list of supported <ds> s),(list of supported <bfr> s) OK
Read Command AT+CNMI?	Response +CNMI: <mode> , <mt> , <bm> , <ds> , <bfr> OK

Write Command AT+CNMI[=<mode>[,<mt>[,<bm>[,<ds>[,<bfr>]]]]]	Response OK If there is an error related to ME functionality: +CMS ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference <i>3GPP TS 27.005</i>	

Parameter

<mode>	Integer type. 0 Buffer unsolicited result codes in the TA. If TA result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications. 1 Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in data mode). Otherwise forward them directly to the TE. <u>2</u> Buffer unsolicited result codes in the TA when TA-TE link is reserved (e.g. in data mode) and flush them to the TE after reservation. Otherwise forward them directly to the TE.
<mt>	Integer type. The rules for storing received SMSs depend on its data coding scheme (refer to <i>3GPP TS 23.038 [2]</i>), preferred memory storage (AT+CPMS) setting and this value. 0 No SMS-DELIVER indications are routed to the TE. <u>1</u> If SMS-DELIVER is stored into ME/TA, indication of the memory location is routed to the TE by using unsolicited result code: +CMTI: <mem>,<index> 2 SMS-DELIVERs (except class 2) are routed directly to the TE using unsolicited result code: +CMT: [<alpha>,<length><CR><LF><pdu> (PDU mode enabled) or +CMT: <oa>,<alpha>,<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data> (text mode enabled; about parameters in italics, refer to AT+CSDH). Class 2 messages result in indication as defined in <mt>=1. 3 Class 3 SMS-DELIVERs are routed directly to TE by using unsolicited result codes defined in <mt>=2. Messages of other classes result in indication as defined in <mt>=1.
<bm>	Integer type. The rules for storing received CBMs depend on its data coding scheme (refer to <i>3GPP TS 23.038 [2]</i>), the setting of Select CBM Types (AT+CSCB) and this value. <u>0</u> No CBM indications are routed to the TE. 2 New CBMs are routed directly to the TE using unsolicited result code:

		+CBM: <length><CR><LF><pdu> (PDU mode); or +CBM: <sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data> (text mode)
<ds>	Integer type.	
	<u>0</u>	No SMS-STATUS-REPORTs are routed to the TE.
	<u>1</u>	SMS-STATUS-REPORTs are routed to the TE using unsolicited result code: +CDS: <length><CR><LF><pdu> (PDU mode) +CDS: <fo>,<mr>,<ra>,<tora>,<scts>,<st> (text mode)
	<u>2</u>	If SMS-STATUS-REPORT is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CDSI: <mem>,<index>
<bfr>	Integer type.	
	<u>0</u>	TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1 or 2 is entered (OK response shall be given before flushing the codes).
	<u>1</u>	TA buffer of unsolicited result codes defined within this command is cleared when <mode> 1 or 2 is entered.
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values.	

NOTE

Unsolicited result code:

+CMTI: <mem>,<index>	Indicates that a new message has been received
+CMT: [<alpha>],<length><CR><LF><pdu>	A short message is outputted directly
+CBM: <length><CR><LF><pdu>	Cell broadcast message is outputted directly

Example

```

AT+CMGF=1 //Set SMS message format as text mode
OK
AT+CSCS="GSM" //Set character set as GSM which is used by the TE
OK
AT+CNMI=1,2,0,1,0 //Set SMS-DELIVERs are routed directly to the TE
OK

+CMT: "+8615021012496",,"13/03/18,17:07:21+32",145,4,0,0,"+8613800551500",145,28
This is a test from Quectel. //A short message is outputted directly when SMS is incoming.

```

8.14. AT+CSDH Show Text Mode Parameters

This command controls whether detailed header information is shown in text mode result codes.

AT+CSDH Show Text Mode Parameters	
Test Command AT+CSDH=?	Response +CSDH: (list of supported <show>s) OK
Read Command AT+CSDH?	Response +CSDH: <show> OK
Write Command AT+CSDH[=<show>]	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference <i>3GPP TS 27.005</i>	

Parameter

<show>	Integer type.
	<u>0</u> Do not show header values defined in commands AT+CSCA, AT+CSMP (<sca>, <tosca>, <fo>, <vp>, <pid>, <dcs>) and <length>, <toda> or <tooa> in +CMT, +CMGL, +CMGR result codes for SMS-DELIVERs and SMS-SUBMITs in text mode; for SMS-COMMANDs, in +CMGR result code, do not show <pid>, <mn>, <da>, <toda>, <length> or <cdata>. <u>1</u> Show the values in result codes.

Example

```

AT+CSDH=0                //Set to disable the presenting of text mode parameters
OK
AT+CMGR=2
+CMGR: "STO UNSENT", "",
<This is a test from Quectel>
OK
AT+CSDH=1                //Set to enable the presenting of text mode parameters

```

```
OK
AT+CMGR=2
+CMGR: "STO UNSENT","",128,17,0,0,143,"+8613800551500",145,18
<This is a test from Quectel>
OK
```

8.15. AT+CSMP Set Text Mode Parameters

This command selects values for additional parameters needed when SM is sent to the network or placed in a storage when text mode is selected (**AT+CMGF=1**). It is possible to set the validity period starting from when the SM is received by the SMSC (**<vp>** is in range 0 to 255) or define the absolute time of the validity period termination (**<vp>** is a string).

AT+CSMP Set Text Mode Parameters

Test Command AT+CSMP=?	Response OK
Read Command AT+CSMP?	Response +CSMP: <fo>,<vp>,<pid>,<dc> OK
Write Command AT+CSMP=<fo>,<vp>,<pid>,<dc>]]]	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference <i>3GPP TS 27.005</i>	

Parameter

<fo>	First octet. Depending on the command or result code: first octet of <i>3GPP TS 23.040 [3]</i> SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, SMS-COMMAND in integer format. If a valid value has been entered once, the parameter can be omitted.
<vp>	Validity period. Depending on SMS-SUBMIT <fo> setting: <i>3GPP TS 23.040 [3]</i> TP-Validity-Period either in integer format or in time-string format (refer to <dt>).
<pid>	Protocol identifier. <i>3GPP TS 23.040 [3]</i> TP-Protocol-Identifier in integer format (default 0).
<dc>	Data coding scheme. Depending on the command or result code: <i>3GPP TS 23.038 [2]</i> SMS Data Coding Scheme (default 240), or Cell Broadcast Data Coding Scheme in integer format.

8.16. AT+QCMGS Send Concatenated Messages

This command sends concatenated messages. Different from **AT+CMGS**, when sending a concatenated message via this command, each segment of the concatenated message must be identified by the additional parameters **<uid>**, **<msg_seg>** and **<msg_total>**. When sending all segments of the message one by one, **AT+QCMGS** must be executed multiple times (equal to **<msg_total>**) for each segment. This command is only applicable in text mode (**AT+CMGF=1**).

AT+QCMGS Send Concatenated Messages

Test Command AT+QCMGS=?	Response OK
Write Command If in text mode (AT+CMGF=1): AT+QCMGS=<da>[,<toda>][,<uid>,<msg_seg>,<msg_total>]<CR> text is entered <ctrl-Z/ESC>	Response If in text mode (AT+CMGF=1) and the message is sent successfully: +QCMGS: <mr> OK If there is an error related to ME functionality: +CMS ERROR: <err> If there is any other error: ERROR
Maximum Response Time	120 s, determined by the network.
Characteristics	-

Parameter

<uid>	Integer type. Message identification in the user data header (UDH). Range: 0–255. This parameter is defined and inputted by the user. All segments of a same concatenated message must have the same <uid> . Different concatenated messages should have different <uid> .
<msg_seg>	Integer type. Sequence number of a concatenated message. Range: 0–7. <msg_seg>=0 means: ignore the value and regarded it as a non-concatenated message.
<msg_total>	Integer type. The total number of the segments of one concatenated message. Range: 0–7. <msg_total>=0 or 1 means: ignore the value and regard it as a non-concatenated message.
<da>,<toda>,<mr>	Refer to AT+CMGS .
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values.

NOTE

- For concatenated messages, the maximum length will be reduced by the length of the user data header (UDH). 3GPP TS 23.040 defines two kinds of UDH length: 6 bytes and 7 bytes, so the two kinds of **<uid>** are 8 bit (6 bytes) and 16 bit (7 bytes). **AT+QCMGS** uses 8 bit **<uid>**.
 - In the case of GSM 7 bit default alphabet data coding scheme, the maximum length of each segment of a concatenated message is $(140 \text{ octets} - 6) * 8 / 7 = 153$ characters.
 - In the case of 16-bit UCS2 data coding scheme, the maximum length of each segment is $(140 - 6) / 2 = 67$ characters.
 - In the case of 8-bit data coding scheme, the maximum length of each segment is $140 - 6 = 134$ characters.
- <mr>**, Message-Reference field gives an integer representation of a reference number of the SMS-SUBMIT or SMS-COMMAND submitted to the SC by the MS, and it is used to confirm whether the SMS-DELIVER has been received from SC duplicate or not. **<uid>**, the field of UDH, is message identification of the concatenated SMS, which is different from **<mr>**. Each segment in a concatenated message should have the same **<uid>**, but **<mr>** must be incremented for each segment of a concatenated message.
- AT+QCMGS** does not support sending messages in PDU mode (**AT+CMGF=0**).

Example

```

AT+CMGF=1 //Set SMS message format as text mode
OK
AT+CSCS="GSM" //Set character set as GSM which is used by the TE
OK
AT+QCMGS="15056913384",120,1,2 <CR> //Input 120 for <uid>, send the first segment of the
                                     concatenated SMS
>ABCD<ctrl-Z>
+QCMGS: 190

OK
AT+QCMGS="15056913384",120,2,2 <CR> //Send the second segment of the concatenated SMS.
>EFGH<ctrl-Z>
+QCMGS: 191

OK
    
```

8.17. AT+QCMGR Read Concatenated Messages

The function of this command is similar to **AT+CMGR**, except that the message to be read is a segment of concatenated messages, and parameters **<uid>**, **<msg_seg>** and **<msg_total>** would be shown in the result. Several segments should be concatenated to a whole concatenated message according to these

three parameters. Similar to **AT+QCMGS**, **AT+QCMGR** is only used in text mode (**AT+CMGF=1**).

AT+QCMGR Read Concatenated Messages

Test Command AT+QCMGR=?	Response OK
Write Command AT+QCMGR=<index>	Response If in text mode (AT+CMGF=1) and the command is executed successfully: For SMS-DELIVER: +QCMGR: <stat>,<oa>,[<alpha>],<scts>[,<tooa>,<fo>,<pid>,<dc>,<sca>,<tosca>,<length>][,<uid>,<msg_seg>,<msg_total>]<CR><LF><data> OK For SMS-SUBMIT: +QCMGR: <stat>,<da>,[<alpha>][,<toda>,<fo>,<pid>,<dc>,<vp>],<sca>,<tosca>,<length>][,<uid>,<msg_seg>,<msg_total>]<CR><LF><data> OK For SMS-STATUS-REPORTS: +QCMGR: <stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st> OK For SMS-COMMANDS: +QCMGR: <stat>,<fo>,<ct>[,<pid>,[<mn>],[<da>],[<toda>],<length>]<CR><LF><cdata> OK If there is an error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	Depends on the length of message content.
Characteristics	-

Parameter

<uid>	Integer type. Message identification in the user data header (UDH). Range: 0–65535 (see NOTES). All segments of a same concatenated message have same <uid> .
--------------------	--

	Different concatenated messages should have different <uid> .
<msg_seg>	Integer type. Sequence number of a concatenated message. Range: 1–7.
<msg_total>	Integer type. The total number of the segments of one concatenated message. Range: 2–7.
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values. Other parameters, please refer to AT+CMGR .

NOTE

1. The **<uid>** in **AT+QCMGR** is different from the **<uid>** in **AT+QCMGS**. It is possible that UE receives concatenated messages with 8 bits or 16 bits **<uid>**. So its maximal value is 255 with 8 bits and 65535 with 16 bits.
2. If the message to be read is not a concatenated message, then **<uid>**, **<msg_seg>** and **<msg_total>** would not be shown in the result.

Example

```
+CMTI: "SM",3           //The first segment of a concatenated message comes

+CMTI: "SM",4           //The second segment of a concatenated message comes

AT+QCMGR=3              //Read the first segment of the concatenated message
+QCMGR: "REC UNREAD","+8615056913384","13/07/30,14:44:37+32",120,1,2
ABCD

OK

AT+QCMGR=4              //Read the second segment of the concatenated message
+QCMGR: "REC UNREAD","+8615056913384","13/07/30,14:44:37+32",120,2,2
EFGH

OK
```

8.18. AT+QSMSCONCAS Send Long Messages

This command sends a long message from TE to network (SMS-SUBMIT). The message reference **<mr>** is returned to the TE on successful message delivery. Optionally (when **AT+CSMS <service>** value is 1 and network supports) **<scts>** is returned. The values can be used to identify message upon unsolicited delivery status report result code.

AT+QSMSCONCAS Send Long Messages

Test Command	Response
AT+QSMSCONCAS=?	OK

Write Command If in text mode (AT+CMGF=1): AT+QSMSCONCAS=<da>[,<toda>] After > is repounded, input the text message. After that, tap Ctrl and Z to send the message. Sending can be cancelled by tapping Esc, and the abortion is acknowledged with OK, but the message will not be sent.	Response If the message is sent successfully: +QSMSCONCAS: <mr>[,<scts>] OK If there is an error related to ME functionality: +CMS ERROR: <err>
Write Command If in PDU mode (AT+CMGF=0): AT+QSMSCONCAS=<length> After > is repounded, input the PDU. After that, tap Ctrl and Z to indicate the ending of PDU and begin to send the message. Sending can be cancelled by tapping Esc, and the abortion is acknowledged with OK, but the message will not be sent.	Response If the message is sent successfully: +QSMSCONCAS: <mr>[,<scts>] OK If there is an error related to ME functionality: +CMS ERROR: <err>
Maximum Response Time	120 s, determined by the network.
Characteristics	-
Reference	
3GPP TS 27.005	

Parameter

<da>	Destination address. <i>3GPP TS 23.040</i> TP-Destination-Address Address-Value field in string format. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (refer to command AT+CSCS in <i>3GPP TS 27.007</i>). The type of address is given by <toda> .
<toda>	Type of destination address. <i>3GPP TS 24.011</i> TP-Destination-Address Type-of-Address octet in integer format.
<length>	Integer type. Message length. In the text mode (AT+CMGF=1) the length of the text message in characters; or in PDU mode (AT+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).
<mr>	Message reference. <i>3GPP TS 23.040</i> TP-Message-Reference in integer format.
<scts>	Service center time stamp. <i>3GPP TS 23.040</i> TP-Service-Centre-Time-Stamp in time-string format (refer to <dt> in AT+CMGL).
<err>	Integer type. Error code. Refer to Table 22 for possible <err> values. See AT+CMGR for other parameters.

NOTE

The maximum number of characters that can be entered in a long message is: 153×10 (GSM 7-bit encoding), 134×5 (8-bit encoding) and 67×5 (UCS2 encoding).

Example

```

AT+CMGF=1                                //Set SMS message format as text mode
OK
AT+CSCS="GSM"                             //Set character set as GSM which is used by the TE
OK
AT+QSMSCONCAS="15021012496"
> <This is a test from Quectel>           //Enter text message. Tap Ctrl and Z to send
                                           message, or tap Esc to quit without sending.
+QSMSCONCAS: 247
OK

```

9 Packet Domain Commands

9.1. AT+CGATT PS Attach or Detach

This command attaches the MT to, or detaches the MT from, the Packet Domain service. After the command has completed, the MT remains in V.250 command state. If the MT is already in the requested state, the command is ignored and the **OK** response is returned. If the requested state cannot be achieved, an **ERROR** or **+CME ERROR** response is returned.

AT+CGATT PS Attach or Detach	
Test Command AT+CGATT=?	Response +CGATT: (list of supported <state>s) OK
Read Command AT+CGATT?	Response +CGATT: <state> OK
Write Command AT+CGATT=<state>	Response OK If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	140 s, determined by the network.
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<state>	Integer type. The state of PS attachment.
	0 Detached
	1 Attached
	Other values are reserved and will result in an ERROR response to the Write Command.
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

Example

```

AT+CGATT=1           //Attach to PS service
OK
AT+CGATT=0           //Detach from PS service
OK
AT+CGATT?             //Query the current PS service state
+CGATT: 0
OK

```

9.2. AT+CGDCONT Define PDP Context

This command specifies PDP context parameters for a specific context **<cid>**. A special form of the Write Command (**AT+CGDCONT=<cid>**) causes the values for context **<cid>** to become undefined. It is not allowed to change the definition of an already activated context.

This Read Command returns the current settings for each defined PDP context.

AT+CGDCONT Define PDP Context

Test Command AT+CGDCONT=?	Response +CGDCONT: (list of supported <cid>s), <PDP_type> , <APN> , <PDP_addr> , (list of supported <data_comp>s), (list of supported <head_comp>s), (list of supported <IPv4AddrAlloc>s) OK
Read Command AT+CGDCONT?	Response +CGDCONT: <cid> , <PDP_type> , <APN> , <PDP_addr> , <da ta_comp> , <head_comp> , <IPv4AddrAlloc> [...] OK
Write Command AT+CGDCONT=<cid>[,<PDP_type>[,< APN>[,<PDP_addr>[,<data_comp>[,< head_comp>[,<IPv4AddrAlloc>]]]]]	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference <i>3GPP TS 27.007</i>	

Parameter

<cid>	Integer type. PDP context identifier, which specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. The range of permitted values (minimum value = 1) is returned by the test form of the command. Range: 1–15.
<PDP_type>	Packet data protocol type. A string parameter which specifies the type of packet data protocol. "IP" IPv4 "PPP" PPP "IPV6" IPv6 "IPV4V6" IPv4v6 "Non-IP" Non-IP
<APN>	String type. Access point name, a logical name used to select the GGSN or the external packet data network. If the value is null or omitted, then the subscription value will be requested.
<PDP_addr>	String type. Identifies the MT in the address space applicable to the PDP. If the value is null or omitted, then a value may be provided by the TE during the PDP startup procedure or, failing that, a dynamic address will be requested. The allocated address may be read using the AT+CGPADDR command.
<data_comp>	A numeric parameter that controls PDP data compression (applicable for SND CP only) (refer to 3GPP TS 44.065 [61]). 0 OFF (Default value if the parameter is omitted) 1 ON (Manufacturer preferred compression) 2 V.42bis
<head_comp>	Integer type. Controls PDP header compression (refer to 3GPP TS 44.065 [61] and 3GPP TS 25.323 [62]). 0 OFF 1 ON 2 RFC 1144 3 RFC 2507 4 RFC 3095
<IPv4AddrAlloc>	Integer type. Controls how the MT/TA requests to get the IPv4 address information. 0 IPv4 address allocation through NAS signaling

9.3. AT+CGACT PDP Context Activate or Deactivate

This command activates or deactivates the specified PDP context(s). After the command has completed, the MT remains in V.250 command state. If any PDP context is already in the requested state, the state for that context remains unchanged. If the MT is not PS attached when the activation form of the command is executed, the MT first performs a PS attach and then attempts to activate the specified contexts. If no **<cid>**s are specified, the activation/deactivation form of the command

activates/deactivates all defined contexts.

AT+CGACT PDP Context Activate or Deactivate

Test Command AT+CGACT=?	Response +CGACT: (list of supported <state>s) OK
Read Command AT+CGACT?	Response +CGACT: <cid>,<state> [+CGACT: <cid>,<state> [...]] OK
Write Command AT+CGACT=<state>,<cid>	Response OK Or ERROR If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	150 s, determined by the network.
Characteristics	-
Reference <i>3GPP TS 27.007</i>	

Parameter

<state>	Integer type. Indicates the state of PDP context activation. 0 Deactivated 1 Activated Other values are reserved and will result in an ERROR response to the Write Command
<cid>	Integer type. Specifies a particular PDP context definition (see AT+CGDCONT).
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

Example

```

AT+CGDCONT=1,"IP","UNINET" //Define a PDP context
OK
AT+CGACT=1,1 //Activate the PDP
OK
AT+CGACT=0,1 //Deactivate the PDP
OK

```


9.4. AT+CGPADDR Show PDP Addresses

This command returns a list of PDP addresses for the specified context identifiers. If no **<cid>** is specified, the addresses for all defined contexts are returned.

AT+CGPADDR Show PDP Addresses	
Test Command AT+CGPADDR=?	Response +CGPADDR: (list of defined <cid> s) OK
Write Command AT+CGPADDR[=<cid>[,<cid>[,...]]]	Response +CGPADDR: <cid>,<PDP_addr> [+CGPADDR: <cid>,<PDP_addr> [...]] OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	-
Reference <i>3GPP TS 27.007</i>	

Parameter

<cid>	Integer type. Specifies a particular PDP context definition (see AT+CGDCONT).
<PDP_addr>	String type. Identifies the MT in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the AT+CGDCONT command when the context was defined. For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid> . <PDP_address> is omitted if none is available.

Example

```

AT+CGDCONT=1,"IP","UNINET"           //Define a PDP context
OK
AT+CGACT=1,1                           //Activate the PDP
OK
AT+CGPADDR=1                           //Show the PDP address
+CGPADDR: 1,10.76.51.180

```

OK

9.5. AT+CGREG EGPRS Network Registration Status

This command queries the EGPRS network registration status and controls the presentation of an unsolicited result code **+CGREG: <stat>** when **<n>=1** and there is a change in the MT's EGPRS network registration status in GERAN, or unsolicited result code **+CGREG: <stat>[,<lac>],[<ci>],[<Act>]]** when **<n>=2** and there is a change of the network cell in GERAN.

AT+CGREG EGPRS Network Registration Status

Test Command AT+CGREG=?	Response +CGREG: (list of supported <n>s) OK
Read Command AT+CGREG?	Response: When <n>=0, 1, or 2 and the command is executed successfully: +CGREG: <n>,<stat>[,<lac>],[<ci>],[<Act>]] OK When <n>=4 and the command is executed successfully: +CGREG: <n>,<stat>[,<lac>],[<ci>],[<Act>][,],[<Active-Time>],[<Periodic-RAU>],[<GPRS-READY-timer>]]] OK
Write Command AT+CGREG[=<n>]	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT&W .
Reference <i>3GPP TS 27.007</i>	

Parameter

<n>	Integer type.
<u>0</u>	Disable network registration unsolicited result code

1	Enable network registration unsolicited result code: +CGREG: <stat>
2	Enable network registration and location information unsolicited result code: +CGREG: <stat>[,<lac>[,<ci>[,<AcT>]]]
4	For a UE that wants to apply PSM, enable network registration and location information unsolicited result code: +CGREG: <stat>[,<lac>[,<ci>[,<AcT>][,],[<Active-Time>], [<Periodic-RAU>],<GPRS-READY-timer>]]]]
<stat>	Integer type. Indicates the EGPRS registration status.
0	Not registered. MT is not currently searching an operator to register to. The UE is in GMM state GMM-NULL or GMM-DEREGISTERED-INITIATED. The GPRS service is disabled, but the UE is allowed to attach for GPRS if requested by the user.
1	Registered, home network. The UE is in GMM state GMM-REGISTERED or GMM-ROUTING-AREA-UPDATING-INITIATED INITIATED on the home PLMN.
2	Not registered, but MT is currently trying to attach or searching an operator to register to. The UE is in GMM state GMM-DEREGISTERED or GMM-REGISTERED-INITIATED. The GPRS service is enabled, but an allowable PLMN is currently not available. The UE will start a GPRS attach as soon as an allowable PLMN is available.
3	Registration denied. The UE is in GMM state GMM-NULL. The GPRS service is disabled, and the UE is not allowed to attach for GPRS if requested by the user.
4	Unknown
5	Registered, roaming
<lac>	String type. Two-byte location area code in hexadecimal format (e.g. "00C3" equals 195 in decimal)
<ci>	String type. Four-byte cell ID in hexadecimal format.
<AcT>	Integer type. Access technology of the serving cell.
0	GSM
8	eMTC (Not applicable)
9	NB-IoT (Not applicable)
<Active-Time>	String type. One byte in an 8-bit format. Active Time value (T3324) to be allocated to the UE (e.g. "00001111" equals 30 seconds). Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6 0 0 0 value is incremented in multiples of 2 seconds 0 0 1 value is incremented in multiples of 1 minute 0 1 0 value is incremented in multiples of decihours 1 1 1 value indicates that the timer is deactivated.
<Periodic-RAU>	String type. One byte in an 8-bit format. Extended periodic RAU value (T3312) to be allocated to the UE in GERAN (e.g. "01000111" equals 70 hours). Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6

0 0 0	value is incremented in multiples of 10 minutes
0 0 1	value is incremented in multiples of 1 hour
0 1 0	value is incremented in multiples of 10 hours
0 1 1	value is incremented in multiples of 2 seconds
1 0 0	value is incremented in multiples of 30 seconds
1 0 1	value is incremented in multiples of 1 minute

<GPRS-READY-timer> String type. One byte in an 8-bit format. GPRS READY timer value (T3314) to be allocated to the UE in GERAN (e.g. "01001010" equals 1 hours). Bits 5 to 1 represent the binary coded timer value. Bits 6 to 8 define the timer value unit as follows:

Bits 8 7 6

0 0 0	value is incremented in multiples of 2 seconds
0 0 1	value is incremented in multiples of 1 minute
0 1 0	value is incremented in multiples of decihours
1 1 1	value indicates that the timer is deactivated

NOTE

This command is valid on BG95-M3 and BG95-M8 only.

Example

```
AT+CGREG=2
```

```
OK
```

```
AT+CGATT=0
```

```
OK
```

```
+CGREG: 2
```

```
AT+CGATT=1
```

```
OK
```

```
+CGREG: 1,"FFFE","82E76B2",9
```

9.6. AT+CGEREP Packet Domain Event Reporting

This command enables or disables sending of unsolicited result codes **+CGEV: XXX** from MT to TE in the case of certain events occurring in the packet domain MT or the network. **<mode>** controls the processing of unsolicited result codes specified within this command. **<bfr>** controls the effect on buffered codes when **<mode>** 1 or 2 is entered.

AT+CGEREP Packet Domain Event Reporting

Test Command AT+CGEREP=?	Response +CGEREP: (list of supported <mode> s),(list of supported <bfr> s) OK
Read Command AT+CGEREP?	Response +CGEREP: <mode> , <bfr> OK
Write Command AT+CGEREP=<mode>[,<bfr>]	Response OK If there is any error: ERROR
Execution Command AT+CGEREP	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference <i>3GPP TS 27.007</i>	

Parameter

<mode>	Integer type. <u>0</u> Buffer unsolicited result codes in the MT. If MT result code buffer is full, the oldest ones can be discarded. No codes are forwarded to the TE. 1 Discard unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE. 2 Buffer unsolicited result codes in the MT when MT-TE link is reserved (e.g. in data mode) and flush them to the TE when MT-TE link becomes available. Otherwise forward them directly to the TE.
<bfr>	Integer type. <u>0</u> MT buffer of unsolicited result codes defined within this command is cleared when <mode> 1 or 2 is entered. 1 MT buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1 or 2 is entered (OK response shall be given before flushing the codes).

NOTE

The unsolicited result codes and the corresponding events are defined as follows:

1. **+CGEV: REJECT <PDP_type>,<PDP_addr>**: A network request for PDP context activation occurred when the MT was unable to report it to the TE with a **+CRING** unsolicited result code and was automatically rejected.
Note: This event is not applicable for EPS.
2. **+CGEV: NW REACT <PDP_type>,<PDP_addr>,[<cid>]**: The network has requested a context reactivation. The **<cid>** used to reactivate the context is provided if known to the MT.
Note: This event is not applicable for EPS.
3. **+CGEV: NW DEACT <PDP_type>,<PDP_addr>,[<cid>]**: The network has forced a context deactivation. The **<cid>** used to activate the context is provided if known to the MT.
4. **+CGEV: ME DEACT <PDP_type>,<PDP_addr>,[<cid>]**: The mobile equipment has forced a context deactivation. The **<cid>** used to activate the context is provided if known to the MT.
5. **+CGEV: NW DETACH**: The network has forced a Packet Domain detach. This implies that all active contexts have been deactivated. These are not reported separately.
6. **+CGEV: ME DETACH**: The mobile equipment has forced a Packet Domain detach. This implies that all active contexts have been deactivated. These are not reported separately.
7. **+CGEV: NW CLASS <class>**: The network has forced a change of MS class. The highest available class is reported (see **AT+CGCLASS**).
8. **+CGEV: ME CLASS <class>**: The mobile equipment has forced a change of MS class. The highest available class is reported (see **AT+CGCLASS**).
9. **+CGEV: PDN ACT <cid>**: Activated a context. The context represents a PDN connection in LTE or a Primary PDP context in GSM.
10. **+CGEV: PDN DEACT <cid>**: Deactivated a context. The context represents a PDN connection in LTE or a primary PDP context in GSM.

Parameter

<PDP_type>	Packet data protocol type. A string parameter which specifies the type of packet data protocol. "IP" IPv4 "PPP" PPP "IPV6" IPv6 "IPV4V6" IPv4v6
<PDP_addr>	A string parameter identifies the MT in the address space applicable to the PDP. If the value is null or omitted, then a value may be provided by the TE during the PDP.
<cid>	PDP context identifier. A numeric parameter which specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. The range of permitted values (minimum value=1) is returned by the test form of AT+CGDCONT command.
<class>	A string parameter which indicates the GPRS mobile class A Class A (highest)

B	Class B
C	Class C in GPRS and circuit switched alternate mode
CG	Class C in GPRS only mode
CC	Class C in circuit switched only mode (lowest)

Example

```
AT+CGEREP=?
```

```
+CGEREP: (0-2),(0,1)
```

```
OK
```

```
AT+CGEREP?
```

```
+CGEREP: 0,0
```

```
OK
```

9.7. AT+CGSMS Select Service for MO SMS Messages

This command specifies the service or service preference that the MT will use to send MO (mobile originated) SMS messages.

AT+CGSMS Select Service for MO SMS Messages

Test Command

```
AT+CGSMS=?
```

Response

```
+CGSMS: (list of currently available <service>s)
```

```
OK
```

Read Command

```
AT+CGSMS?
```

Response

```
+CGSMS: <service>
```

```
OK
```

Write Command

```
AT+CGSMS=[<service>]
```

Response

```
OK
```

If there is an error related to ME functionality:

```
+CME ERROR: <err>
```

If there is any other error:

```
ERROR
```

Maximum Response Time

300 ms

Characteristics

The command takes effect immediately.

	The configuration is saved automatically.
Reference 3GPP TS 27.007	

Parameter

<service>	Integer type. Indicates the service or service preference to be used.
0	GPRS
<u>1</u>	Circuit switch
2	GPRS preferred (use circuit switched if GPRS is not available)
3	Circuit switch preferred (use GPRS if circuit switched is not available)
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

NOTE

The circuit switched service route is the default method.

9.8. AT+CEREG EPS Network Registration Status

This command queries the LTE network registration status and controls the presentation of an unsolicited result code **+CEREG: <stat>** when **<n>=1** and there is a change in the MT's EPS network registration status in E-UTRAN, or unsolicited result code **+CEREG: <stat>,[<tac>],[<ci>],[<AcT>]** when **<n>=2** and there is a change of the network cell in E-UTRAN.

If the UE wants to apply PSM for reducing its power consumption, see **AT+CPSMS** command and 3GPP TS 23.682 [149], this command controls the presentation of an unsolicited result code **+CEREG: <stat>,[<tac>],[<ci>],[<AcT>],[<Active-Time>],[<Periodic-TAU>]]** when **<n>=4** and there is a change of the network cell in E-UTRAN.

AT+CEREG EPS Network Registration Status

Test Command AT+CEREG=?	Response +CEREG: (list of supported <n>s) OK
Read Command AT+CEREG?	Response When <n>=0, 1, or 2 and the command is executed successfully: +CEREG: <n>,<stat>,[<tac>],[<ci>],[<AcT>]

	When <n>=4 and the command is executed successfully: +CEREG: <n>,<stat>[,<tac>],[<ci>],[<AcT>][,],[<Active-Time>],[<Periodic-TAU>]]]
	OK
Write Command AT+CEREG[=<n>]	Response OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration can be saved with AT+W .
Reference <i>3GPP TS 27.007</i>	

Parameter

<n>	Integer type. 0 Disable network registration unsolicited result code 1 Enable network registration unsolicited result code: +CEREG: <stat> 2 Enable network registration and location information unsolicited result code: +CEREG: <stat>[,<tac>],[<ci>],[<AcT>]] 4 For a UE that has applied PSM, and network assigns T3324 to UE, enable network registration and location information unsolicited result code: +CEREG: <stat>[,<tac>],[<ci>],[<AcT>][,],[<Active-Time>],[<Periodic-TAU>]]]
<stat>	Integer type. 0 Not registered. MT is not currently searching an operator to register to. 1 Registered, home network 2 Not registered, but MT is currently trying to attach or searching an operator to register to 3 Registration denied 4 Unknown 5 Registered, roaming
<tac>	String type. Two-byte tracking area code in hexadecimal format.
<ci>	String type. Four-byte E-UTRAN cell ID in hexadecimal format.
<AcT>	Access technology selected 0 GSM (Not applicable) 8 eMTC 9 NB-IoT
<Active-Time>	String type. One byte in an 8-bit format. Active Time value (T3324) to be allocated to the UE. (e.g. "00001111" equals to 1 minute)

Bits 5 to 1 represent the binary coded timer value.

Bits 6 to 8 define the timer value unit as follows:

Bits

8 7 6

0 0 0 value is incremented in multiples of 2 seconds

0 0 1 value is incremented in multiples of 1 minute

0 1 0 value is incremented in multiples of decihours

1 1 1 value indicates that the timer is deactivated.

<Periodic-TAU> String type. One byte in an 8-bit format. Extend periodic TAU value (T3412_ext) to be allocated to the UE in E-UTRAN.

(e.g. "00001010" equals to 100 minutes)

Bits 5 to 1 represent the binary coded timer value.

Bits 6 to 8 define the timer value unit as follows:

Bits

8 7 6

0 0 0 value is incremented in multiples of 10 minutes

0 0 1 value is incremented in multiples of 1 hour

0 1 0 value is incremented in multiples of 10 hours

0 1 1 value is incremented in multiples of 2 seconds

1 0 0 value is incremented in multiples of 30 seconds

1 0 1 value is incremented in multiples of 1 minute

10 Hardware Related Commands

10.1. AT+CCLK Clock

This command sets or queries the real time clock (RTC) of the module. The current setting is retained until the module is totally disconnected from power supply.

AT+CCLK Clock	
Test Command AT+CCLK=?	Response OK
Read Command AT+CCLK?	Response +CCLK: <time> OK
Write Command AT+CCLK=<time>	Response OK If there is an error related to ME functionality: +CME ERROR: <err> If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<time>	String type. The format is “yy/MM/dd, hh:mm:ss±zz”, indicating year (last two-digits), month, day, hour, minutes, seconds and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; range: -48...+56). E.g. May 6 th , 1994, 22:10:00 GMT+2 hours equals to “94/05/06,22:10:00+08”.
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

Example

```
AT+CCLK? //Query the local time
+CCLK: "08/01/04,00:19:43+00"

OK
```

10.2. AT+CBC Battery Charge

This command returns battery charge status (<bc>) and battery charge level (<bcl>) of the MT.

AT+CBC Battery Charge	
Test Command AT+CBC=?	Response +CBC: (list of supported <bc>),(list of supported <bcl>),<voltage> OK
Execution Command AT+CBC	Response +CBC: <bc>,<bcl>,<voltage> OK If there is an error related to ME functionality: +CME ERROR: <err>
Maximum Response Time	300 ms
Characteristics	-
Reference 3GPP TS 27.007	

Parameter

<bc>	Integer type. Battery charge status 0 ME is not charging 1 ME is charging 2 Charging has been finished
<bcl>	Battery charge level 0 – 100 Battery has 0 – 100 percent of capacity remaining
<voltage>	Battery voltage (mV)
<err>	Integer type. Error code. Refer to Table 21 for possible <err> values.

10.3. AT+QADC Read ADC Value

The command is used to read the voltage value of ADC channel.

AT+QADC Read ADC Value	
Test Command AT+QADC=?	Response +QADC: (list of supported <port>s) OK
Read Command AT+QADC=<port>	Response +QADC: <status>,<value> OK
Maximum Response Time	300 ms
Characteristics	-

Parameter

<port>	Channel number of the ADC. 0 ADC Channel 0
<status>	Indicate whether the ADC value is read successfully. 0 Fail 1 Success
<value>	The voltage of specified ADC channel. Unit: mV.

NOTE

For more details about the pin number, see the corresponding hardware design.

10.4. AT+QSCCLK Configure Whether or Not to Enter Sleep Mode

This command is used to control whether the module enters sleep mode. When entering sleep mode is enabled and MAIN_DTR is pulled up, the module enters sleep mode directly. If entering sleep mode is enabled and MAIN_DTR is pulled down, there is a need to pull up the MAIN_DTR pin first to make the module enter sleep mode.

AT+QSCLK Configure Whether or Not to Enter Sleep Mode

Test Command AT+QSCLK=?	Response +QSCLK: (list of supported <n>s) OK
Read Command AT+QSCLK?	Response +QSCLK: <n> OK
Write Command AT+QSCLK=<n>	Response OK If there is any other error: ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<n>	Integer type.
0	Disable sleep mode
1	Enable sleep mode. It is controlled by MAIN_DTR.

10.5. AT+QTEMP Read Temperature

This command reads the temperature of PMIC, XO, PA and baseband. (Only the firmware version on R02 baseline supports reading the temperature of baseband.)

AT+QTEMP Read Temperature

Test Command AT+QTEMP=?	Response OK
Execution Command AT+QTEMP	Response +QTEMP: <pmic_temp>,<xo_temp>,<pa_temp>,<BB_temp> OK If there is any error:

	ERROR
Maximum Response Time	300 ms
Characteristics	-

Parameter

<pmic_temp>	PMIC temperature. Unit: degrees Celsius.
<xo_temp>	XO temperature. Unit: degrees Celsius.
<pa_temp>	PA temperature. Unit: degrees Celsius.
<BB_temp>	Baseband temperature. Unit: degrees Celsius.

NOTE

<BB_temp> is only for the firmware versions on R02 baseline.

10.6. AT+QCTEMP Configure Temperature Threshold

This command configures the warning threshold for a specific temperature type and whether to enable the corresponding function of the temperature warning.

AT+QCTEMP Configure Temperature Threshold	
Test Command AT+QCTEMP=?	Response +QCTEMP: 0 ,(list of supported <threshold>s),(list of supported <state>s) +QCTEMP: 1 ,(list of supported <threshold>s),(list of supported <state>s) +QCTEMP: 2 ,(list of supported <threshold>s),(list of supported <state>s) OK
Read Command AT+QCTEMP?	Response +QCTEMP: 0 ,<threshold>,<state> +QCTEMP: 1 ,<threshold>,<state> +QCTEMP: 2 ,<threshold>,<state> OK
Write Command AT+QCTEMP=<threshold_type>[,<threshold>,<state>]	Response If the optional parameters are omitted, query the warning threshold and warning enabling state corresponding to a

	specific temperature type: +QCTEMP: <threshold_type>,<threshold>,<state> OK If the optional parameters are specified, configure the temperature threshold: OK
Maximum Response Time	200 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<threshold_type>	Integer type. Type of temperature warning threshold. 0 PMIC temperature warning threshold 1 XO temperature warning threshold 2 PA temperature warning threshold
<threshold>	Integer type. Temperature threshold. Range: 60–100. Default value: 85.
<state>	Integer type. It indicates the corresponding function of <threshold_type> is enabled or disabled. 0 Disabled. 1 Enabled. The URC is reported only once when the temperature reaches the set threshold.

NOTE

1. This command is only for the firmware versions on R02 baseline.
2. When the temperature reaches the set threshold, the URC is reported as follows:
 - **+QIND: "OVER PMIC TEMPERATURE WARNING"**
 - **+QIND: "OVER OX TEMPERATURE WARNING"**
 - **+QIND: "OVER PA TEMPERATURE WARNING"**

Example

```

AT+QCTEMP=? //Query the threshold setting range.
+QCTEMP: 0,(60-100),(0,1)
+QCTEMP: 1,(60-100),(0,1)
+QCTEMP: 2,(60-100),(0,1)

OK
AT+QCTEMP=0,70,1 //Set the PMIC temperature warning voltage to 70 ° C.
OK

```


AT+QCTEMP=0	//Query the PMIC temperature warning threshold and state.
+QCTEMP 0,70,1	//0 indicates the function type of PMIC temperature, 70 °C indicates the threshold for PMIC temperature warning, and 1 indicates that the PMIC warning function is enabled. When the temperature reaches the set threshold, the URC will be reported once.
OK	
AT+QCTEMP?	//Read command.
+QCTEMP: 0,70,1	
+QCTEMP: 1,85,1	
+QCTEMP: 2,85,1	
OK	
//Adjust the PMIC temperature to over 70 °C	
+QIND: "OVER PMIC TEMPERATURE WARNING"	
//Adjust the PMIC temperature to below 70 °C	
+QIND: "NORMAL PMIC TEMPERATURE WARNING"	
//Adjust the XO temperature to over 85 °C	
+QIND: "OVER XO TEMPERATURE WARNING"	
//Adjust the PA temperature to over 85 °C	
+QIND: "OVER PA TEMPERATURE WARNING"	
AT+QCTEMP=1,80,1	//The function of the XO temperature warning is enabled. When the temperature reaches the set threshold, the URC will be reported only once.
OK	

10.7. AT+QVBATT Configure Voltage Threshold

The command configures the high and low voltage threshold of warning and power-down.

AT+QVBATT Configure Voltage Threshold	
Test Command AT+QVBATT=?	Response +QVBATT: 0,(list of supported <threshold>s),(list of supported <state>s) +QVBATT: 1,(list of supported <threshold>s),(list of supported <state>s) +QVBATT: 2,(list of supported <threshold>s),(list of supported <state>s) +QVBATT: 3,(list of supported <threshold>s),list of supported <state>s) OK
Read Command AT+QVBATT?	Response +QVBATT: 0,<threshold>,<state> +QVBATT: 1,<threshold>,<state>

	+QVBATT: 2,<threshold>,<state> +QVBATT: 3,<threshold>,<state> OK
Read Command Read the threshold and state corresponding to each type of voltage warning AT+QVBATT=<threshold_type>	Response +QVBATT: <threshold_type>,<threshold>,<state> OK
Write Command AT+QVBATT=<threshold_type>,<threshold>,<state>	Response OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<threshold_type>	Integer type. Type of voltage threshold configuration. 0 Configure the low voltage warning threshold 1 Configure the low voltage power-down threshold 2 Configure the high voltage warning threshold 3 Configure the high voltage power-down threshold
<threshold>	Integer type. Voltage threshold. Unit: mV. When <threshold_type> =0, the range of <threshold> is from 3350 to 3500 and the default value is 3500. When <threshold_type> =1, the range of <threshold> is from 3000 to 3300 and the default value is 3300. When <threshold_type> =2, the range of <threshold> is from 4450 to 4580 and the default value is 4580. When <threshold_type> =3, the range of <threshold> is from 4600 to 4800 and the default value is 4800.
<state>	Integer type. The corresponding function of <threshold_type> is enabled or disabled. 0 The function is disabled. 1 The function is enabled. The URC is reported all the time when the voltage reaches the configured threshold. 2 The function is enabled. The URC is reported only once when the voltage reaches the configured threshold.

NOTE

- When the battery voltage reaches the configured threshold, the URC is reported as follows:
 - **+QIND: "UNDER VOLTAGE WARNING"** Low voltage warning
 - **+QIND: "UNDER VOLTAGE POWER DOWN"** Power-down due to low voltage
 - **+QIND: "OVER VOLTAGE WARNING"** High voltage warning
 - **+QIND: "OVER VOLTAGE POWER DOWN"** Power-down due to high voltage
- When the battery voltage reaches the configured threshold, the module not only reports URC, but also reboots or powers down.

Example

```

AT+QVBATT=?           //Test command.
+QVBATT: 0,(3350-3500),(0-2)
+QVBATT: 1,(3000-3300),(0-2)
+QVBATT: 2,(4450-4580),(0-2)
+QVBATT: 3,(4600-4800),(0-2)

OK
AT+QVBATT=0,3490,1    //Set the low voltage warning threshold to 3490 mV.
OK
AT+QVBATT=0           //Query the low voltage warning threshold and state.
+QVBATT: 0,3490,1     //The threshold of the low voltage warning is 3490 mV,
                      warning is enabled and the URC is reported all the time.

OK
AT+QVBATT?           //Read command.
+QVBATT: 0,3490,1
+QVBATT: 1,3300,1
+QVBATT: 2,4500,1
+QVBATT: 3,4700,1

OK

//Adjust the power voltage to below 3300 mV
+QIND : "UNDER VOLTAGE POWER DOWN"
//Adjust the power voltage to between 3300 mV and 3490 mV
+QIND : "UNDER VOLTAGE WARNING"
//Adjust the power voltage to between 4500 mV and 4700 mV
+QIND : "OVER VOLTAGE WARNING"
//Adjust the power voltage to over 4700 mV
+QIND : "OVER VOLTAGE POWER DOWN"

AT+QVBATT=1,3300,0    //The low voltage power-down is turned off.
OK
  
```

```
AT+QVBATT=1 //Query the low voltage power-down threshold and state.
+QVBATT: 1,3300,0 //The threshold of the low voltage power-down is 3300 mV and the low
                    voltage power-down is turned off.

OK
AT+QVBATT? //Read command.
+QVBATT: 0,3490,1
+QVBATT: 1,3300,0 //The low voltage power-down is turned off.
+QVBATT: 2,4500,1
+QVBATT: 3,4700,1

OK
AT+QVBATT=1,3300,2 //Set the low voltage power-down threshold to 3300 mV, turn on the
                    low voltage power-down and the URC is reported only one time.
OK
AT+QVBATT=1 //Query the low voltage warning threshold and state.
+QVBATT: 1,3300,2 //The low voltage power-down threshold is 3300 mV, the low voltage
                    power-down is turned on and the URC is reported only one time.

OK
```

11 DFOTA Related AT Command

Refer to *document [2]* for details of DFOTA function.

Table 5: DFOTA Related AT Command

Command	Description
AT+QFOTADL	Upgrade firmware via DFOTA
AT+QCFGEXT="fota_apn"	Configure IP family and APN for DFOTA
AT+QCFGEXT="fota_http_header"	Configure HTTP(S) header for DFOTA over HTTP(S)
AT+QCFGEXT="fota_wd_gpio"	Configure watch dog pin and feeding interval during DFOTA
AT+QCFGEXT="sni"	Configure Whether to enable server name indication for DFOTA

12 FTP(S) Related AT Commands

Refer to **document [3]** for details of FTP(S) function.

Table 6: FTP(S) Related AT Commands

Command	Description
AT+QFTPCFG	Configure parameters for FTP(S) server
AT+QFTPOPEN	Login to FTP(S) server
AT+QFTPCWD	Configure the current directory on FTP(S) server
AT+QFTPPWD	Get the current directory on FTP(S) server
AT+QFTPPUT	Upload a file to FTP(S) server
AT+QFTPGET	Download a file from FTP(S) server
AT+QFTPSIZE	Get the file size on FTP(S) server
AT+QFTPDEL	Delete a file on FTP(S) server
AT+QFTPMKDIR	Create a folder on FTP(S) server
AT+QFTPRMDIR	Delete a folder on FTP(S) server
AT+QFTPLIST	List content of a directory on FTP(S) server
AT+QFTPNLIST	List file names of a directory on FTP(S) server
AT+QFTPMLSD	List standardized file and directory information
AT+QFTPMDTM	Get the file modification time on FTP(S) server
AT+QFTPRENAME	Rename a file or folder on FTP(S) server
AT+QFTPLEN	Get the length of transferred data
AT+QFTPSTAT	Get the status of FTP(S) server
AT+QFTPCLOSE	Log out from FTP(S) server

13 HTTP(S) Related AT Commands

Refer to **document [4]** for details of HTTP(S) function.

Table 7: HTTP(S) Related AT Commands

Command	Description
AT+QHTTPCFG	Configure parameters for HTTP(S) server
AT+QHTTPURL	Set URL of HTTP(S) server
AT+QHTTPGET	Send GET request to HTTP(S) server
AT+QHTTPPOST	Send POST request to HTTP(S) server via UART/USB
AT+QHTTPPOSTFILE	Send POST request to HTTP(S) server via file
AT+QHTTPPUT	Send PUT request to HTTP(S) server via UART/USB
AT+QHTTPPUTFILE	Send PUT request to HTTP(S) server via File
AT+QHTTPREAD	Read response from HTTP(S) server via UART/USB
AT+QHTTPREADFILE	Store the response from HTTP(S) server to a file

14 TCP(IP) Related AT Commands

Refer to **document [5]** for details of TCP(IP) function.

Table 8: TCP/IP Related AT Commands

Command	Description
AT+QICSGP	Configure parameters of a TCP/IP context
AT+QIACT	Activate a PDP context
AT+QIDEACT	Deactivate a PDP context
AT+QIOPEN	Open a socket service
AT+QICLOSE	Close a socket service
AT+QISTATE	Query socket service status
AT+QISEND	Send data
AT+QIRD	Retrieve the received TCP/IP data
AT+QISENDEX	Send hex string data
AT+QISWTMD	Switch data access mode
AT+QPING	Ping a remote server
AT+QNTP	Synchronize local time with NTP server
AT+QIDNSCFG	Configure address of DNS server
AT+QIDNSGIP	Get IP address by domain name
AT+QICFG	Configure optional parameters
AT+QISDE	Control whether to echo the data for AT+QISEND
AT+QIGETERROR	Query the last error code

15 GNSS Related AT Commands

Refer to **document [6]** for details of GNSS function.

Table 9: GNSS Related AT Commands

Command	Description
AT+QGPSCFG	Configure GNSS
AT+QGPSDEL	Delete assistance data
AT+QGPS	Turn on GNSS
AT+QGPSEND	Turn off GNSS
AT+QGPSLOC	Acquire positioning information
AT+QGPSGNMEA	Acquire NMEA sentences
AT+QGPSXTRA	Enable gpsOneXTRA assistance function
AT+QGPSXTRATIME	Inject gpsOneXTRA time
AT+QGPSXTRADATA	Inject gpsOneXTRA data file
AT+QCFGEXT	Query and Configure Extended Settings for GNSS

16 SSL Related AT Commands

Refer to *document [7]* for details of SSL function.

Table 10: SSL Related AT Commands

Command	Description
AT+QSSLCFG	Configure parameters of an SSL context
AT+QSSLOPEN	Open an SSL socket to connect remote server
AT+QSSLEND	Send data via SSL connection
AT+QSSLRECV	Receive data via SSL connection
AT+QSSLCLOSE	Close an SSL connection
AT+QSSLSTATE	Query the state of SSL connection
AT+ QSSLCRYPT	Encrypt/Decrypt data with a specified algorithm

17 FILE Related AT Commands

Refer to **document [8]** for details of FILE function.

Table 11: FILE Related AT Commands

Command	Description
AT+QFLDS	Get the space information of storage
AT+QFLST	List file information
AT+QFDEL	Delete files
AT+QFUPL	Upload a file
AT+QFDWL	Download a file
AT+QFOPEN	Open a file
AT+QFREAD	Read a file
AT+QFWRITE	Write a file
AT+QFSEEK	Set file pointer to a position
AT+QFPOSITION	Get the offset of a file pointer
AT+QFTUCAT	Truncate a file from the file pointer
AT+QFCLOSE	Close a file
AT+QFCRC	Calculate the CRC of a specified UFS file
AT+QFCPY	Make a copy of a specified file

18 MQTT Related AT Commands

Refer to *document [9]* for details of MQTT function.

Table 12: MQTT Related AT Commands

Command	Description
AT+QMTCFG	Configure optional parameters of MQTT
AT+QMTOPEN	Open a network for MQTT client
AT+QMTCLOSE	Close a network for MQTT client
AT+QMTCONN	Connect a client to MQTT server
AT+QMTDISC	Disconnect a client from MQTT server
AT+QMTSUB	Subscribe to topics
AT+QMTUNS	Unsubscribe from topics
AT+QMT PUB	Publish messages (Data Mode)
AT+QMT PUBEX	Publish messages (Command Mode)
AT+QMTRECV	Read messages from buffers

19 CoAP Related AT Commands

Refer to **document [10]** for details of CoAP function.

Table 13: CoAP Related AT Commands

Command	Description
AT+QCOAPOPEN	Create a CoAP session
AT+QCOAPCLOSE	Disconnect from CoAP server
AT+QCOAPHEADER	Configure header of CoAP message
AT+QCOAPOPTION	Configure options of CoAP message
AT+QCOAPSEND	Send CoAP message
AT+QCOAPCFG	Configure optional parameters of CoAP client

20 LwM2M Related AT Commands

Refer to **document [11]** for details of LwM2M function.

Table 14: LwM2M Related AT Commands

Command	Description
AT+QLWCFG	Configure optional parameters of LwM2M client
AT+QLWSVC	Select LwM2M client functionality

21 Extended Configuration Commands

Refer to *document [12]&[13]* for details of the extended configuration commands.

Table 15: Extended Configuration Commands

Command	Description
AT+QCFG="nwscanmode"	Configure RAT(s) to be searched
AT+QCFG="servicedomain"	Service domain configuration
AT+QCFG="nwscanseq"	Configure RATs searching sequence
AT+QCFG="band"	Band configuration
AT+QCFG="iotopmode"	Configure network category to be searched under LTE RAT
AT+QCFG="celevel"	Query NB-IoT coverage enhancement level
AT+QCFG="nccconf"	Configure NB-IoT features
AT+QCFG="psm/enter"	Trigger the module into PSM immediately
AT+QCFG="psm/urc"	Enable/Disable PSM entering indication
AT+QCFG="simeffect"	Enable/Disable RAT search order stored in (U)SIM cards
AT+QCFG="lapiconf"	Configure low access priority indication feature
AT+QCFG="nasconfig"	Configure NAS related parameters
AT+QCFG="irat/timer"	Configure high-priority RAT search timer
AT+QCFG="nb1/bandprior"	Configure band scan priority under NB-IoT
AT+QCFG="emmcause"	Get the EMM cause value
AT+QCFG="sibinfo"	Query SIB information
AT+QCFG="emmtimer"	Query EMM timer
AT+QCFG="msclass"	Configure multislot class
AT+QCFG="ims"	Query IMS registration state

AT+QCFG="snrscan"	Configure band scan level under NB-IoT
AT+QCFG="fgiconfig"	Configure feature group indicators
AT+QCFG="sim/onchip"	Enable/Disable on-chip SIM
AT+QCFG="bandrestore"	Restore default band configuration
AT+QCFG="bip/auth"	Configure the auth type in BIP process
AT+QCFG="timer"	Query the T3402 timer
AT+QCFG="timeupdate"	Control automatic time update via NITZ or GNSS
AT+QCFG="msc"	Configure UE MSC release version
AT+QCFG="sgsn"	Configure UE SGSN release version
AT+QCFG="lte/bandprior"	Configure LTE band priority
AT+QCFG="psm_rtc_adjust_ctrl"	Enable/Disable RTC adjustment in PSM
AT+QCFG="rf/tuner_cfg"	Set the mapping between RF tuner and RF bands
AT+QCFG="timesave"	Control whether to save the NITZ timestamp automatically
AT+QCFG="urc/ri/ring"	Configure MAIN_RI behavior in case of RING URC
AT+QCFG="urc/ri/smsincoming"	Configure MAIN_RI behavior in case of incoming SMS URCs
AT+QCFG="urc/ri/other"	Configure MAIN_RI behavior in case of other URCs
AT+QCFG="risignalttype"	Configure MAIN_RI signal output carrier
AT+QCFG="urc/delay"	When to output URC
AT+QCFG="ledmode"	Configure NET_STATUS output mode
AT+QCFG="gpio"	Configure GPIO status
AT+QCFG="airplanecontrol"	Enable/disable airplane mode control via W_DISABLE#
AT+QCFG="cmux/urcport"	Configure output port of URCs in MUX Mode
AT+QCFG="apready"	Configure AP_READY behavior
AT+QCFG="psm/urc"	Enable/disable PSM entering indication
AT+QCFG="uartcfg"	Control DCD/RI/DTR/RTS/CTS function
AT+QCFG="dbgctl"	Configure log output level

AT+QCFG="cmux/flowctrl"	Configure hardware flow control for CMUX mode
AT+QCFG="fast/poweroff"	Control fast shutdown function
AT+QCFGEXT="addgeo"	Add a geo-fence
AT+QCFGEXT="deletegeo"	Delete a geo-fence
AT+QCFGEXT="querygeo"	Query the position with respect to geo-fence
AT+QCFGEXT="nipdcfg"	Configure NIDD connection
AT+QCFGEXT="nipd"	Open or close NIDD connection
AT+QCFGEXT="nipds"	Send MO non-IP data
AT+QCFGEXT="nipdr"	Retrieve MT non-IP data
AT+QCFGEXT="dump"	Enable/Disable dump mode
AT+QCFGEXT="quecopen"	Enable/Disable QuecOpen function
AT+QCFGEXT="disusb"	Enable/Disable USB function
AT+QCFGEXT="usb/event"	Get USB events
AT+QCFGEXT="pwm"	Configure PWM function
AT+QCFGEXT="usbnet"	Configure USB composition
AT+QCFGEXT="dnsc_timeout"	Configure DNS session timeout
AT+QCFGEXT="ap_os_version"	Query APPS Operation System Version

22 Appendix

22.1. References

Table 16: Related Documents

Document Name
[1] Quectel_BG95&BG77&BG600L_Series_Fast_Shutdown_Application_Note
[2] Quectel_BG95&BG77&BG600L_Series_DFOTA_Application_Note
[3] Quectel_BG95&BG77&BG600L_Series_FTP(S)_Application_Note
[4] Quectel_BG95&BG77&BG600L_Series_HTTP(S)_Application_Note
[5] Quectel_BG95&BG77&BG600L_Series_TCP(IP)_Application_Note
[6] Quectel_BG95&BG77&BG600L_Series_GNSS_Application_Note
[7] Quectel_BG95&BG77&BG600L_Series_SSL_Application_Note
[8] Quectel_BG95&BG77&BG600L_Series_FILE_Application_Note
[9] Quectel_BG95&BG77&BG600L_Series_MQTT_Application_Note
[10] Quectel_BG95&BG77&BG600L_Series_CoAP_Application_Note
[11] Quectel_BG95&BG77&BG600L_Series_LwM2M_Application_Note
[12] BG95&BG77&BG600L_Series_QCFG_AT_Commands_Manual
[13] Quectel_BG95&BG77&BG600L_Series_QCFGEXT_AT_Commands_Manual
[14] Quectel_BG95&BG77&BG600L_Series_Voice_Application_Note

Table 17: Terms and Abbreviations

Abbreviation	Description
3GPP	3rd Generation Partnership Project
AMR	Adaptive Multi-Rate
APN	Access Point Name
CBM	Cell Broadcast Message
CLIR	Calling Line Identification Restriction
CoAP	Constrained Application Protocol
CSD	Circuit Switch Data
DCD	Data Carrier Detection
DCE	Data Communication Equipment
DFOTA	Delta Firmware Upgrade Over-The-Air
DTE	Data Terminal Equipment
DTR	Data Terminal Ready
ECT	Explicit Call Transfer
Emtc	enhanced Machine Type Communication
FTP	File Transfer Protocol
FTPS	File Transfer Protocol Secure
GGSN	Gateway GPRS Support Node
GNSS	Global Navigation Satellite System
GPRS	General Packet Radio Service
HTTP	Hypertext Transfer Protocol
HTTPS	Hypertext Transfer Protocol Secure
IMS	IP Multimedia Subsystem
IRA	International Reference Alphabet

LwM2M	Lightweight Machine to Machine
ME	Mobile Equipment
MQTT	Message Queuing Telemetry Transport
MS	Mobile Station
NB-IoT	Narrowband Internet of Things
PDP	Packet Data Protocol
PSC	Primary Synchronization Code
RAT	Radio Access Technology
RRC	Radio Resource Control
RSCP	Received Signal Code Power
RSRP	Received Signal Received Power
RSRQ	Reference Signal Received Quality
RSSI	Received Signal Strength Indicator
RTS/CTS	Request To Send/Clear To Send
SGSN	Serving GPRS Support Node
SSL	Secure Sockets Layer
TA	Terminal Adapter
TCP	Transmission Control Protocol
TE	Terminal Equipment
UDP	User Datagram Protocol
UE	User Equipment
NVRAM	Non-Volatile Random Access Memory
VoLTE	Voice over LTE (Long Term Evolution)

22.2. Factory Default Settings Restorable with AT&F

Table 18: Factory Default Settings Restorable with AT&F

AT Command	Parameters	Factory Defaults
ATE	<value>	1
ATQ	<n>	0
ATS0	<n>	0
ATS3	<n>	13
ATS4	<n>	10
ATS5	<n>	8
ATS6	<n>	2
ATS7	<n>	0
ATS8	<n>	2
ATS10	<n>	15
ATV	<value>	1
ATX	<value>	4
AT&C	<value>	1
AT&D	<value>	1
AT+CREG	<n>	0
AT+CGREG	<n>	0
AT+CMEE	<n>	1
AT+CSCS	<chset>	"GSM"
AT+CSTA	<type>	129
AT+CR	<mode>	0
AT+CRC	<mode>	0

AT+CSMS	<service>	0
AT+CMGF	<mode>	0
AT+CSMP	<fo>,<vp>,<pid>,<dc>	17,167,0,0
AT+CSDH	<show>	0
AT+CSCB	<mode>	0
AT+CPMS	<mem1>,<mem2>,<mem3>	"ME","ME","ME"
AT+CNMI	<mode>,<mt>,<bm>,<ds>,<bfr>	2,1,0,0,0
AT+CMMS	<n>	0
AT+CVHU	<mode>	0
AT+CTZR	<reporting>	0
AT+CPBS	<storage>	ME
AT+CGEREP	<mode>,<brf>	0,0
AT+CEREG	<n>	0
AT+CUSD	<mode>	0
AT+CLVL	<level>	3
AT+QAUDMOD	<mode>	0
AT+QAUDLOOP	<enable>	0

22.3. AT Command Settings Storable with AT&W

Table 19: AT Command Settings Storable with AT&W

AT Command	Parameters	Display with AT&V
ATE	<value>	Yes
ATQ	<n>	Yes

ATS0	<n>	Yes
ATS7	<n>	Yes
ATS10	<n>	Yes
ATV	<value>	Yes
ATX	<value>	Yes
AT&C	<value>	Yes
AT&D	<value>	Yes
AT+IFC	<DCE_by_DTE>,<DTE_by_DCE>	No
AT+IPR	<rate>	No
AT+CREG	<n>	No
AT+CGREG	<n>	No
AT+CEREG	<n>	No

22.4. AT Command Settings Restorable with ATZ

Table 20: AT Command Settings Restorable with ATZ

AT Command	Parameters	Factory Defaults
ATE	<value>	1
ATQ	<n>	0
ATS0	<n>	0
ATS7	<n>	0
ATS10	<n>	15
ATV	<value>	1
ATX	<value>	4

AT&C	<value>	1
AT&D	<value>	1
AT+CREG	<n>	0
AT+CGREG	<n>	0
AT+CEREG	<n>	0

22.5. Summary of CME ERROR Codes

Final result code **+CME ERROR: <err>** indicates an error related to mobile equipment or network. The operation of **+CME ERROR: <err>** final result code is similar to the regular **ERROR** result code: if **+CME ERROR: <err>** is the result code for any of the commands in a command line, none of the following commands in the same command line is executed (neither **ERROR** nor **OK** result code shall be returned as a result of a completed command line execution). The format of **<err>** can be either numeric or verbose. This is set with **AT+CMEE**.

The following table lists most of general and GRPS related **ERROR** codes. For some GSM protocol failure cause described in GSM specifications, the corresponding **ERROR** codes are not included.

Table 21: Different Coding Schemes of +CME ERROR: <err>

Code of <err>	Meaning
0	Phone failure
1	No connection to phone
2	Phone-adaptor link reserved
3	Operation not allowed
4	Operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	(U)SIM not inserted

11	(U)SIM PIN required
12	(U)SIM PUK required
13	(U)SIM failure
14	(U)SIM busy
15	(U)SIM wrong
16	Incorrect password
17	(U)SIM PIN2 required
18	(U)SIM PUK2 required
20	Memory full
21	Invalid index
22	Not found
23	Memory failure
24	Text string too long
25	Invalid characters in text string
26	Dial string too long
27	Invalid characters in dial string
30	No network service
31	Network timeout
32	Network not allowed - emergency calls only
40	Network personalization PIN required
41	Network personalization PUK required
42	Network subset personalization PIN required
43	Network subset personalization PUK required
44	Service provider personalization PIN required
45	Service provider personalization PUK required

46	Corporate personalization PIN required
47	Corporate personalization PUK required

22.6. Summary of CMS ERROR Codes

Final result code **+CMS ERROR: <err>** indicates an error related to mobile equipment or network. The operation is similar to **ERROR** result code. None of the following commands in the same command line is executed. Neither **ERROR** nor **OK** result code shall be returned.

<err> values are mostly used by common message commands:

Table 22: Different Coding Schemes of +CMS ERROR: <err>

Code of <err>	Meaning
300	ME failure
301	SMS ME reserved
302	Operation not allowed
303	Operation not supported
304	Invalid PDU mode
305	Invalid text mode
310	(U)SIM not inserted
311	(U)SIM pin necessary
312	PH (U)SIM pin necessary
313	(U)SIM failure
314	(U)SIM busy
315	(U)SIM wrong
316	(U)SIM PUK required
317	(U)SIM PIN2 required

318	(U)SIM PUK2 required
320	Memory failure
321	Invalid memory index
322	Memory full
330	SMSC address unknown
331	No network
332	Network timeout
500	Unknown
512	(U)SIM not ready
513	Message length exceeds
514	Invalid request parameters
515	ME storage failure
517	Invalid service mode
528	More message to send state error
529	MO SMS is not allow
530	GPRS is suspended
531	ME storage full

22.7. Summary of URC

Table 23: Summary of URC

Index	URC Display	Meaning	Condition
1	+CREG: <stat>	Indicate registration status of the ME	AT+CREG=1
2	+CREG: <stat>[, [<lac>], [<ci>], [<AcT>]]	After cell neighborhood changing shows whether the network has currently indicated the registration of	AT+CREG=2

		the ME, with location area code	
3	+CGREG: <stat>	Indicate network registration status of the ME	AT+CGREG=1
4	+CGREG: <stat>[, [<lac>], [<ci>], [<AcT>], [<rac>]]	Indicate network registration and location information of the ME	AT+CGREG=2
5	+CTZV: <tz>	Time zone reporting	AT+CTZR=1
6	+CTZE: <tz>,<dst>,<time>	Extended time zone reporting	AT+CTZR=2
7	+CMTI: <mem>,<index>	New message is received, and saved to memory	See AT+CNMI
8	+CMT: [<alpha>],<length><CR><LF><pdu>	New short message is received and output directly to TE (PDU mode)	See AT+CNMI
9	+CMT: <oa>,<alpha>,<scts>[,<tooa>,<fo>,<pid>,<dcsc>,<sca>,<tosca>,<length>]<CR><LF><data>	New short message is received and output directly to TE (Text mode)	See AT+CNMI
10	+CBM: <length><CR><LF><pdu>	New CBM is received and output directly (PDU mode)	See AT+CNMI
11	+CBM: <sn>,<mid>,<dcsc>,<page>,<pages><CR><LF><data>	New CBM is received and output directly to TE (Text mode)	See AT+CNMI
12	+CDS: <length><CR><LF><pdu>	New CDS is received and output directly (PDU mode)	See AT+CNMI
13	+CDS: <fo>,<mr>,<ra>,<to ra>,<scts>,<st>	New CDS is received and output directly to TE (Text mode)	See AT+CNMI
14	+CDSI: <mem>,<index>	New message status report is received, and saved to memory	See AT+CNMI
15	+CRING: <type>	An incoming call is indicated to the TE with unsolicited result code instead of the normal RING	AT+CRC=1
16	APP RDY	AP core initialization is successful	N/A
17	RDY	ME initialization is successful	N/A
18	+CFUN: 1	All function of the ME is available	N/A
19	+CPIN: <state>	SIM card pin state	N/A
20	+QIND: SMS DONE	SMS initialization finished	N/A
21	POWERED DOWN	Module power down	AT+QPOWD

22	+CGEV: REJECT <PDP_type>,<PDP_addr>	A network request for PDP activation, and was automatically rejected.	AT+CGEREP=2,1
23	+CGEV: NW REACT <PDP_type>,<PDP_addr>,<cid>	The network request PDP reactivation	AT+CGEREP=2,1
24	+CGEV: NW DEACT <PDP_type>,<PDP_addr>,<cid>	The network has forced a context deactivation	AT+CGEREP=2,1
25	+CGEV: ME DEACT <PDP_type>,<PDP_addr>,<cid>	The ME has forced a context deactivation.	AT+CGEREP=2,1
26	+CGEV: NW DETACH	The network has forced a Packet Domain detach.	AT+CGEREP=2,1
27	+CGEV: ME DETACH	The mobile equipment has forced a Packet Domain detach.	AT+CGEREP=2,1
28	+CGEV: NW CLASS <class>	The network has forced a change of MS class.	AT+CGEREP=2,1
29	+CGEV: ME CLASS <class>	The mobile equipment has forced a change of MS class.	AT+CGEREP=2,1

22.8. SMS Character Sets Conversions

In 3GPP TS 23.038 DCS (Data Coding Scheme) defined three kinds of alphabets in SMS: GSM 7 bit default alphabet, 8 bit data and UCS2 (16bit). **AT+CSMP** can set the DCS in text mode (**AT+CMGF=1**). In text mode, DCS (Data Coding Scheme) and **AT+CSCS** determine the way of SMS text input or output.

Table 24: The Way of SMS Text Input or Output

DCS	AT+CSCS	The Way of SMS Text Input or Output
GSM 7 bit	GSM	Input or output GSM character sets.
GSM 7 bit	IRA	Input or output IRA character sets. Input: UE will convert IRA characters to GSM characters. Output: UE will convert GSM characters to IRA characters.
GSM 7 bit	UCS2	Input or output a hex string similar to PDU mode. So only support characters '0'-'9' and 'A'-'F'. Input: UE will convert the UCS2 hex string to GSM characters. Output: UE will convert the GSM characters to UCS2 hex string.
UCS2	-	Ignore the value of AT+CSCS, input or output a hex string similar to PDU mode. So only support characters '0'-'9' and 'A'-'F'.
8 bit	-	Ignore the value of AT+CSCS, input or output a hex string similar to PDU mode. So only support characters '0'-'9' and 'A'-'F'.

When DCS=GSM 7 bit, the input or output needs conversion. The detailed conversion tables are shown as below.

Table 25: The Input Conversions Table (DCS=GSM 7 bit and AT+CSCS="GSM")

	0	1	2	3	4	5	6	7
0	00	10	20	30	40	50	60	70
1	01	11	21	31	41	51	61	71
2	02	12	22	32	42	52	62	72
3	03	13	23	33	43	53	63	73
4	04	14	24	34	44	54	64	74
5	05	15	25	35	45	55	65	75
6	06	16	26	36	46	56	66	76
7	07	17	27	37	47	57	67	77
8	08	18	28	38	48	58	68	78
9	09	19	29	39	49	59	69	79
A	0A	Submit	2A	3A	4A	5A	6A	7A
B	0B	Cancel	2B	3B	4B	5B	6B	7B
C	0C	1C	2C	3C	4C	5C	6C	7C
D	0D	1A	2D	3D	4D	5D	6D	7D
E	0E	1E	2E	3E	4E	5E	6E	7E
F	0F	1F	2F	3F	4F	5F	6F	7F

Table 26: The Output Conversions Table (DCS=GSM 7 bit and AT+CSCS="GSM")

	0	1	2	3	4	5	6	7
0	00	10	20	30	40	50	60	70
1	01	11	21	31	41	51	61	71

2	02	12	22	32	42	52	62	72
3	03	13	23	33	43	53	63	73
4	04	14	24	34	44	54	64	74
5	05	15	25	35	45	55	65	75
6	06	16	26	36	46	56	66	76
7	07	17	27	37	47	57	67	77
8	08	18	28	38	48	58	68	78
9	09	19	29	39	49	59	69	79
A	0D0A		2A	3A	4A	5A	6A	7A
B	0B		2B	3B	4B	5B	6B	7B
C	0C	1C	2C	3C	4C	5C	6C	7C
D	0D	1A	2D	3D	4D	5D	6D	7D
E	0E	1E	2E	3E	4E	5E	6E	7E
F	0F	1F	2F	3F	4F	5F	6F	7F

Table 27: GSM Extended Characters (GSM Encode)

0	1	2	3	4	5	6	7
0				1B40			
1							
2							
3							
4		1B14					
5							
6							
7							
8			1B28				

9	1B29
A	
B	
C	1B3C
D	1B3D
E	1B3E
F	1B2F

Table 28: The Input Conversions Table (DCS=GSM 7 bit and AT+CSCS="IRA")

	0	1	2	3	4	5	6	7
0		20	20	30	00	50	20	70
1	20	20	21	31	41	51	61	71
2	20	20	22	32	42	52	62	72
3	20	20	23	33	43	53	63	73
4	20	20	02	34	44	54	64	74
5	20	20	25	35	45	55	65	75
6	20	20	26	36	46	56	66	76
7	20	20	27	37	47	57	67	77
8	Backspace	20	28	38	48	58	68	78
9	20	20	29	39	49	59	69	79
A	0A	Submit	2A	3A	4A	5A	6A	7A
B	20	Cancel	2B	3B	4B	1B3C	6B	1B28
C	20	20	2C	3C	4C	1B2F	6C	1B40
D	0D	20	2D	3D	4D	1B3E	6D	1B29
E	20	20	2E	3E	4E	1B14	6E	1B3D
F	20	20	2F	3F	4F	11	6F	20

Table 29: IRA Extended Characters

	A	B	C	D	E	F
0	20	20	20	20	7F	20
1	40	20	20	5D	20	7D
2	20	20	20	20	20	08
3	01	20	20	20	20	20
4	24	20	5B	20	7B	20
5	03	20	0E	20	0F	20
6	20	20	1C	5C	1D	7C
7	5F	20	09	20	20	20
8	20	20	20	0B	04	0C
9	20	20	1F	20	05	06
A	20	20	20	20	20	20
B	20	20	20	20	20	20
C	20	20	20	5E	07	7E
D	20	20	20	20	20	20
E	20	20	20	20	20	20
F	20	60	20	1E	20	20

Table 30: The Output Conversions Table (DCS=GSM 7 bit and AT+CSCS="IRA")

	0	1	2	3	4	5	6	7
0	40	20	20	30	A1	50	BF	70
1	A3	5F	21	31	41	51	61	71
2	24	20	22	32	42	52	62	72

3	A5	20	23	33	43	53	63	73
4	E8	20	A4	34	44	54	64	74
5	E9	20	25	35	45	55	65	75
6	F9	20	26	36	46	56	66	76
7	EC	20	27	37	47	57	67	77
8	F2	20	28	38	48	58	68	78
9	C7	20	29	39	49	59	69	79
A	0D0A		2A	3A	4A	5A	6A	7A
B	D8		2B	3B	4B	C4	6B	E4
C	F8	C6	2C	3C	4C	D6	6C	F6
D	0D	E6	2D	3D	4D	D1	6D	F1
E	C5	DF	2E	3E	4E	DC	6E	FC
F	E5	C9	2F	3F	4F	A7	6F	E0

Table 31: GSM Extended Characters (ISO-8859-1/Unicode)

0	1	2	3	4	5	6	7
0				7C			
1							
2							
3							
4		5E					
5							
6							
7							
8			7B				
9			7D				

A	
B	
C	5B
D	7E
E	5D
F	5C

Because the low 8-bit of UCS2 character is the same as the IRA character:

- The conversion table of DCS=GSM 7 bit and **AT+CSCS="UCS2"** is similar to **AT+CSCS="IRA"**.
- The conversion table of fmt=GSM 7 bit and **AT+CSCS="GSM"** is similar to **AT+CSCS="GSM"**.
- The conversion table of fmt= GSM 7 bit and **AT+CSCS="IRA"** is similar to **AT+CSCS="IRA"**.
- The conversion table of fmt=GSM 7 bit and **AT+CSCS="UCS2"** is similar to **AT+CSCS="IRA"**.